



Manuals.plus /

› NINTENDO /

› Nintendo Tomodachi Life 3DS Game Instruction Manual

## NINTENDO Tomodachi Life

# Nintendo Tomodachi Life 3DS Game Instruction Manual

Your Friends. Your Drama. Your Life.

### PRODUCT OVERVIEW

Tomodachi Life is a life simulation game developed by Nintendo for the Nintendo 3DS system. Players create and manage Mii characters, observing their daily lives, interactions, and relationships on a virtual island. The game emphasizes humor and unexpected events generated by the Mii characters' personalities and relationships.



NINTENDO 3DS™

Image: Front cover of the Tomodachi Life game for Nintendo 3DS. The cover features numerous Mii characters engaged in various activities, such as dining, dancing, flying a plane, and expressing emotions. The game's tagline "Your Friends. Your Drama. Your Life." is visible, along with the "Tomodachi Life" logo and the Nintendo 3DS branding.

## SETUP INSTRUCTIONS

1. **Insert Game Card:** Ensure your Nintendo 3DS system is powered off. Open the game card slot cover on your Nintendo 3DS system. Gently insert the Tomodachi Life game card into the slot until it clicks into place.
2. **Power On:** Close the game card slot cover. Power on your Nintendo 3DS system by pressing the POWER button.
3. **Select Game:** From the HOME Menu, locate the Tomodachi Life icon. Tap the icon on the touch screen or select it using the +Control Pad and press the A button to start the game.
4. **Initial Setup:** Follow the on-screen prompts to begin your island life, including creating your first Mii characters and setting up the island environment.

## OPERATING THE GAME

Tomodachi Life offers a unique gameplay experience centered around the lives of your Mii characters. Here's a general guide to operating the game:

- **Mii Creation:** Use the Mii Maker to create new Mii characters or import existing ones. Customize their appearance, voice, and personality traits, which will influence their behavior in the game.
- **Island Life:** Observe your Mii characters as they live their daily lives in the apartment building and around the island. They will interact with each other, form friendships, fall in love, and even have arguments.
- **Intervention:** Your role is to check in on your Mii characters and address their needs or problems. This might involve feeding them, giving them gifts, changing their clothes, or helping them resolve conflicts.
- **Special Events:** Participate in various island events, such as rap battles, concerts, festivals, and dreams. These events add variety and humor to the gameplay.
- **Shops and Facilities:** Explore the island's shops to purchase food, clothing, and interiors for your Mii characters. Unlock new facilities as your island population grows.
- **StreetPass:** If enabled, your Mii characters can interact with other players' Mii characters via StreetPass, exchanging items and information.
- **2D and 3D Modes:** The game is playable in both 2D and 3D. You can adjust the 3D depth slider on your Nintendo 3DS system to your preference. Note that the 3D mode is recommended for ages 7 and up.

## MAINTENANCE AND CARE

---

To ensure the longevity and proper functioning of your Tomodachi Life game card, please follow these guidelines:

- **Handle with Care:** Always hold the game card by its edges. Avoid touching the metallic connectors on the back of the card.
- **Keep Clean:** If the metallic connectors appear dirty, gently wipe them with a soft, dry cloth. Do not use liquids or abrasive materials.
- **Storage:** Store the game card in its original case or a protective holder when not in use to prevent dust, dirt, and physical damage.
- **Avoid Extremes:** Do not expose the game card to extreme temperatures, direct sunlight, or excessive moisture.

## TROUBLESHOOTING

---

If you encounter issues while playing Tomodachi Life, consider the following troubleshooting steps:

- **Game Not Loading:**
  - Ensure the game card is fully and correctly inserted into the Nintendo 3DS system's game card slot.
  - Power off and restart your Nintendo 3DS system.
  - Gently clean the metallic connectors on the game card with a soft, dry cloth.
  - Try inserting another Nintendo 3DS game card to confirm the system's game card reader is functioning correctly.

- **Error Messages:**

If an error message appears, note the error code or message and refer to your Nintendo 3DS system's electronic manual or the official Nintendo Support website for specific guidance.

- **Saving Issues:**

Ensure you have sufficient free space on your Nintendo 3DS system's SD card for game saves. Never power off the system or remove the game card during a save operation, as this can corrupt save data.

## SPECIFICATIONS

---

Feature	Detail
Platform	Nintendo 3DS
ESRB Rating	Everyone (E)
Playable Modes	2D and 3D (3D mode recommended for ages 7+)
Item Weight	1.44 ounces
Product Dimensions	5.5 x 5 x 0.5 inches
Manufacturer	NINTENDO
Date First Available (Renewed Product Listing)	November 26, 2024

## WARRANTY INFORMATION

---

This product is listed as "Renewed." For information regarding the warranty, please refer to the specific warranty terms provided by the seller from whom this renewed product was purchased. Typically, renewed products come with a limited warranty from the seller or a third-party refurbisher, which may differ from the original manufacturer's warranty for new products.

## CUSTOMER SUPPORT

---

For technical assistance, gameplay questions, or issues related to your Nintendo 3DS system, please visit the official Nintendo Support website. For inquiries specific to the "Renewed" condition of this product, including warranty claims or returns, please contact the seller directly through your purchase platform.

