

Manuals.plus /

› Frestec /

› Frestec 2.6 Cu.Ft Mini Fridge Model BC69 User Manual

## Frestec BC69

# Frestec 2.6 Cu.Ft Mini Fridge Model BC69 User Manual

Model: BC69 | Brand: Frestec

## 1. IMPORTANT SAFETY INFORMATION

---


Please read all instructions carefully before using your Frestec Mini Fridge. Retain this manual for future reference.

- Ensure the appliance is properly grounded.
- Do not operate if the power cord is damaged.
- Keep ventilation openings clear of obstruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Unplug the appliance before cleaning or maintenance.
- This appliance is intended for household use only.

## 2. PRODUCT OVERVIEW

---

The Frestec Model BC69 is a compact 2.6 cubic feet mini fridge designed for efficient cooling in various small spaces. It features a low-noise operation and an adjustable thermostat.



Front view of the Frestec 2.6 Cu.Ft Mini Fridge, Model BC69, in black finish.

### Key Features:

- **Energy Efficient:** Consumes approximately 0.59 kWh per day.

# ENERGY EFFICIENT DESIGN






Diagram highlighting the energy efficiency (0.57 kWh/24H), large capacity, removable shelf, and 360° circulation for fast cooling.

- **Compact Size, Large Capacity:** 2.6 Cu.Ft total capacity (2.5 Cu.Ft fresh food, 0.1 Cu.Ft freezer).  
Dimensions: 17.83"W x 16.73"D x 27.17"H.
- **Quiet Operation:** Noise level under 37dB.

# QUIET COOLING **37dB**

Almost silent, provide quiet and comfortable place for sleeping or reading



Graphic showing the Frestec mini fridge operating at 37dB, indicating a quiet environment suitable for sleeping or reading, compared to other noise levels.

- **Adjustable Temperature:** 6 settings, ranging from 28.4°F to 50°F.
- **Reversible Door:** Door can be configured to open from the left or right.
- **Adjustable Leveling Legs:** For stable placement on uneven surfaces.
- **Easy Defrosting:** One-touch defrost system.

## 3. SETUP AND INSTALLATION

### 3.1 Unpacking

1. Remove all packaging materials, including foam and adhesive tape.
2. Inspect the appliance for any damage. Report any damage to your retailer immediately.
3. Clean the interior and exterior of the appliance with a soft cloth and mild detergent.

### 3.2 Placement

- Place the refrigerator on a firm, level surface.
- Allow at least 4 inches (10 cm) of space around the back and sides for proper air circulation.

- Avoid direct sunlight or heat sources (e.g., stove, heater).
- Ensure the ambient temperature is between 50°F (10°C) and 90°F (32°C) for optimal performance.

### 3.3 Leveling the Appliance

The mini fridge is equipped with adjustable leveling legs. To level the appliance:

1. Turn the leveling leg clockwise to raise the side.
2. Turn the leveling leg counter-clockwise to lower the side.
3. Ensure the appliance is level to prevent vibrations and ensure proper door sealing.



Image showing the adjustable leveling leg, detachable door seal, removable tempered glass shelf, and simple operation dial.

### 3.4 Reversible Door Installation

The door hinges can be reversed to allow the door to open from either the left or right side, providing flexibility for placement in narrow spaces. Refer to the detailed instructions in the included user manual for the specific steps to reverse the door.

# LEFT AND RIGHT FLIP DOOR DESIGN

Left or right, the choice is yours.



## High wear-resistant hinge

Install the hinges to the left and the door will open to the left



Diagram showing how the door can be reversed to open from either the left or right, along with a detail of the wear-resistant hinge.

## 3.5 Electrical Connection

- Plug the appliance into a dedicated, grounded 115 Volt, 60 Hz AC outlet.
- Do not use extension cords or ungrounded adapters.
- Allow the refrigerator to stand upright for at least 2-4 hours before plugging it in to allow the refrigerant to settle.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Temperature Control

The refrigerator features an adjustable thermostat with 6 settings, allowing you to control the internal temperature from 28.4°F to 50°F. The dial is located inside the refrigerator compartment.

- Setting '0' turns the cooling off.
- Setting '1' is the warmest temperature.
- Setting '6' is the coldest temperature.

Adjust the dial to your desired cooling level. It may take several hours for the temperature to stabilize after adjustment.

# 6 TEMPERATURE SETTINGS

the warmest

the coldest

28.4°F to 50°F

Drinks      Fruits      Frozen Food      Ice Cream

Image showing the 6-setting temperature control dial and examples of items that can be stored at different temperatures, such as drinks, fruits, frozen food, and ice cream.

### 4.2 Food Storage

The refrigerator offers 2.5 cubic feet of fresh food capacity and a 0.1 cubic feet freezer compartment. Organize items efficiently using the removable shelves and door bins.

# COMPACT SIZE



Interior view of the Frestec mini fridge, illustrating its compact size and 2.6 cubic feet capacity, with various items stored inside.

- **Fresh Food Zone:** Ideal for beverages, vegetables, fruits, and snacks.
- **Soft Freeze Zone:** Suitable for items requiring light freezing, such as ice cream or small frozen goods.

## 5. MAINTENANCE AND CLEANING

---

### 5.1 Defrosting

This appliance features a manual defrost system with a one-touch easy defrosting button. Frost will accumulate on the freezer compartment walls. To defrost:

1. Remove all food from the freezer compartment.
2. Press the one-touch defrost button (if available, otherwise unplug the unit).
3. Allow the frost to melt naturally. Place a towel at the bottom to absorb water.
4. Once defrosted, wipe the interior dry and return food items.

*Note: Do not use sharp objects or heating devices to remove frost, as this can damage the cooling system.*

### 5.2 Cleaning the Interior

- Unplug the refrigerator before cleaning.
- Wash the interior surfaces, removable shelves, and door bins with a solution of mild detergent and warm water.
- Rinse thoroughly and dry with a soft cloth.
- The door seal is detachable for easier cleaning. Gently pull it off, clean, and press back into place.

### 5.3 Cleaning the Exterior

- Wipe the exterior with a soft cloth and mild detergent.
- Do not use abrasive cleaners or solvents.
- Regularly clean the condenser coils at the back of the unit to maintain efficiency.

## 6. TROUBLESHOOTING

---

Before contacting customer support, please check the following common issues:

Problem	Possible Cause	Solution
Refrigerator does not operate.	Not plugged in; circuit breaker tripped; power outage.	Check power cord connection; reset circuit breaker; check household power supply.
Temperature is not cold enough.	Temperature control set too warm; door opened too frequently; warm food placed inside; poor air circulation.	Adjust thermostat to a colder setting; minimize door openings; allow hot food to cool before storing; ensure adequate space around the unit.
Excessive noise.	Appliance not level; contact with wall or other objects.	Adjust leveling legs; move appliance away from walls or objects.
Door does not close properly.	Appliance not level; door seal dirty or damaged; obstruction.	Adjust leveling legs; clean or replace door seal; remove any obstructions.

## 7. SPECIFICATIONS

---

Feature	Detail
Brand	Frestec
Model Info	BC69
Item Weight	38 pounds
Product Dimensions (W x D x H)	17.83 x 16.73 x 27.17 inches
Capacity	2.6 Cubic Feet
Refrigerator Fresh Food Capacity	2.5 Cubic Feet
Freezer Capacity	0.1 Cubic Feet
Annual Energy Consumption	210 Kilowatt Hours Per Year (approx. 0.59 kWh/day)
Installation Type	Freestanding
Form Factor	Compact
Special Features	Low Noise
Color	Black
Voltage	115 Volts
Defrost System	Manual
Door Hinges	Reversible
Shelves	2 (Removable Tempered Glass)
Number Of Doors	1

## 8. WARRANTY AND SUPPORT

---

### 8.1 Warranty Information

Frestec offers a **1-YEAR QUALITY PROMISE** for this refrigerator. This warranty covers defects in materials and workmanship under normal use.

Please retain your proof of purchase for warranty claims.

### 8.2 Customer Support

If you encounter any problems or have questions regarding your Frestec Mini Fridge, please contact our customer support team. We aim to reply within 24 hours.

For support, please refer to the contact information provided with your purchase or visit the official Frestec website.