

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [MAXYOYO](#) /

> [MAXYOYO Accent Chair with Ottoman Adjustable Backrest Instruction Manual](#)

MAXYOYO 9f5ea9f8-5f09-4b11-a6e5-01a4fbcd9097

MAXYOYO Accent Chair with Ottoman Adjustable Backrest Instruction Manual

Model: 9f5ea9f8-5f09-4b11-a6e5-01a4fbcd9097

INTRODUCTION

Thank you for choosing the MAXYOYO Accent Chair with Ottoman. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read it thoroughly before use and retain it for future reference.

IMPORTANT SAFETY INFORMATION

- Always follow the assembly instructions carefully to avoid injury.
- Do not exceed the maximum weight capacity of the chair to ensure stability and safety.
- Keep all small parts and packaging materials away from children.
- Ensure all connections are secure before using the chair. Periodically check and tighten all fasteners.
- Do not stand on the chair or ottoman.
- Place the chair on a level surface to prevent tipping.

PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Accent Chair Cushion (1)
- Ottoman Cushion (1)
- Chair Wooden Base (1)
- Ottoman Wooden Base (1)
- Metal Frame Components (various)
- Assembly Hardware (screws, Allen wrench)
- Instruction Manual (this document)

DIMENSION



Figure 1: Overview of the accent chair and ottoman, showing key dimensions and available colors.

SETUP AND ASSEMBLY

The chair and ottoman are designed for straightforward assembly. All necessary tools and a detailed manual are included.

1. **Unpack Components:** Carefully remove all items from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Chair Frame:** Attach the metal frame components to the wooden chair base using the provided hardware. Ensure all screws are tightened securely.
3. **Attach Chair Cushion:** Place the accent chair cushion onto the assembled frame. Secure it using the integrated Velcro straps to the metal bars.
4. **Assemble Ottoman Frame:** Attach the metal frame components to the wooden ottoman base using the provided hardware.
5. **Attach Ottoman Cushion:** Place the ottoman cushion onto its assembled frame, securing it with Velcro straps.

6. **Allow for Rebound:** After assembly, the cushions may appear compressed. Allow approximately 48 hours for the foam to fully expand and regain its intended shape and comfort. Gently tap and shake the cushions to aid in this process.

Your browser does not support the video tag.

Video 1: Assembly demonstration of the MAXYOYO Adjustable Accent Chair with Ottoman. This video shows the unboxing, removal of compression film, and the simple steps to assemble the chair and ottoman, highlighting the quality of materials and the cushions' rebound process.



PRODUCT DETAILS



▲ Tufting Button

▼ Corded Fabric



▲ High-Density Shredded Foam

Figure 2: Illustration of the chair and ottoman cushions recovering their shape after being removed from compressed packaging. It is recommended to wait 48 hours for full expansion.

OPERATING INSTRUCTIONS

The MAXYOYO Accent Chair features an adjustable backrest for customized comfort.

Adjusting the Backrest:

1. To recline the backrest, gently push the backrest forward until you hear a click, then slowly lean back to the desired position.

2. To bring the backrest to a more upright position, push it fully forward until it clicks into the most upright position, then release and adjust to your preferred angle.
3. The backrest offers multiple adjustable positions, typically three, for activities such as reading, relaxing, or napping.

Using the Ottoman:

The matching ottoman can be used as a footrest for enhanced relaxation or as additional seating.



Figure 3: Visual guide demonstrating the multi-position adjustment feature of the chair's backrest, suitable for various activities.

Your browser does not support the video tag.

Video 2: Demonstration of the adjustable backrest feature of the MAXYOYO Accent Chair, showing how to change positions for different comfort levels.

MAINTENANCE

Proper care will extend the life and appearance of your accent chair and ottoman.

- **Cleaning Fabric:** For general cleaning, vacuum the corded fabric regularly using a soft brush attachment to remove

dust and debris. For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild fabric cleaner following the product's instructions, testing on an inconspicuous area first.

- **Cleaning Wooden Parts:** Wipe wooden bases with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Frame Inspection:** Periodically check all screws and bolts to ensure they are tight. Re-tighten as necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading.
- **Avoid Moisture:** Keep the chair and ottoman away from excessive moisture to prevent damage to the wood and fabric.

TROUBLESHOOTING

If you encounter any issues with your MAXYOYO Accent Chair, refer to the following common solutions:

Problem	Possible Cause	Solution
Chair feels unstable/wobbly	Loose fasteners; uneven surface	Check and tighten all screws and bolts. Ensure the chair is on a flat, level surface.
Backrest not adjusting smoothly	Mechanism obstruction; improper operation	Ensure no fabric or debris is obstructing the mechanism. Follow operating instructions carefully.
Cushions appear flat or lumpy	Recently unpacked; foam not fully expanded	Allow up to 48 hours for foam to fully expand. Gently tap and shake cushions to redistribute filling.
Missing parts during assembly	Packaging error	Contact MAXYOYO customer support with your purchase details.

SPECIFICATIONS

- **Brand:** MAXYOYO
- **Model Number:** 9f5ea9f8-5f09-4b11-a6e5-01a4fbcd9097
- **Color:** Corded-beige
- **Product Dimensions (Chair):** 27.1"W x 27.1"D x 15.7"H
- **Ottoman Dimensions:** 25.6"W x 15.7"D
- **Size:** Large
- **Back Style:** Tufted
- **Material:** Wood + Corded Fabric, Foam Fill
- **Item Weight:** 39.9 pounds
- **Reclining Positions:** 2
- **Indoor/Outdoor Usage:** Indoor



Figure 4: The MAXYOYO Accent Chair with Ottoman, showcasing its design and corded-beige color.

WARRANTY AND SUPPORT

For warranty information, replacement parts, or customer support, please refer to your purchase documentation or contact MAXYOYO customer service directly. Details regarding optional protection plans may also be available through your retailer.

Manufacturer: MAXYOYO

ASIN: B0DP2JRLPD