Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Logitech /
- Logitech M241 Silent Bluetooth Mouse User Manual

Logitech M241

Logitech M241 Silent Bluetooth Mouse User Manual

Model: M241

Introduction

This manual provides detailed instructions for setting up, operating, and maintaining your Logitech M241 Silent Bluetooth Mouse. The M241 is a compact, portable wireless mouse designed for quiet and efficient use across various operating systems.



Figure 1: Front view of the Logitech M241 Silent Bluetooth Mouse. The mouse is graphite-colored with a scroll wheel and two main buttons visible.

WHAT'S IN THE BOX

Verify that all items are present in the packaging:

- Logitech M241 Silent Bluetooth Mouse
- 1 AA battery (pre-installed)
- User documentation

SETUP

1. Battery Installation

The Logitech M241 mouse comes with one AA battery pre-installed. If you need to replace the battery or ensure it is correctly seated, follow these steps:

- 1. Turn the mouse over.
- 2. Locate the battery compartment cover on the underside of the mouse.
- 3. Slide the cover open.

- 4. Insert or replace the AA battery, ensuring the positive (+) and negative (-) terminals align with the indicators inside the compartment.
- 5. Close the battery compartment cover securely.



Figure 2: Side view of the Logitech M241 mouse, illustrating its ergonomic shape and the general area where the battery compartment is located on the underside.

2. Bluetooth Pairing

The M241 mouse connects wirelessly via Bluetooth. No USB dongle is required. Follow these steps to pair your mouse with your device:

- 1. Ensure the mouse is powered on. The power switch is located on the underside of the mouse.
- 2. Press and hold the **Connect button** (usually located near the optical sensor on the underside) for a few seconds until the LED indicator on the mouse starts blinking rapidly. This indicates the mouse is in pairing mode.
- 3. On your computer or tablet, open the Bluetooth settings:
 - Windows: Go to Settings > Devices > Bluetooth & other devices. Ensure Bluetooth is turned on.
 - macOS: Go to System Settings > Bluetooth. Ensure Bluetooth is turned on.

- ChromeOS: Click the time on the shelf, then selectBluetooth. Ensure Bluetooth is turned on.
- iPadOS/Android: Go to Settings > Bluetooth. Ensure Bluetooth is turned on.
- 4. In the Bluetooth settings, your device will search for available Bluetooth devices. Select"Logitech M241" from the list of discovered devices.
- 5. Follow any on-screen prompts to complete the pairing process. The LED indicator on the mouse will turn solid for a few seconds and then turn off, indicating successful pairing.

The mouse is now ready for use.

OPERATING INSTRUCTIONS

The Logitech M241 mouse features standard mouse functionality with an emphasis on quiet operation and comfortable design.

- Left Click: Primary button for selecting items, opening links, etc.
- Right Click: Secondary button for context menus and additional options.
- **Scroll Wheel:** Roll up or down to scroll through documents and web pages. The scroll wheel also functions as a middle button when pressed.
- **SilentTouch Technology:** The M241 is designed to reduce clicking noise by 90% compared to standard mice, providing a quieter user experience without compromising click feel.
- **Ambidextrous Design:** The symmetrical shape of the mouse allows for comfortable use by both right-handed and left-handed users.
- **Smooth Tracking:** The optical sensor provides precise and responsive cursor control on various surfaces.



Figure 3: Angled view of the Logitech M241 Silent Bluetooth Mouse, highlighting its compact and ambidextrous design.

MAINTENANCE

Cleaning the Mouse

To maintain optimal performance and hygiene, clean your mouse periodically:

- Turn off the mouse before cleaning.
- Use a soft, lint-free cloth lightly dampened with water or an approved electronic cleaning solution.
- Wipe the surface of the mouse gently.
- Avoid using harsh chemicals, abrasive cleaners, or submerging the mouse in liquid.
- Use a dry cotton swab to clean around the optical sensor and scroll wheel if necessary.

Battery Replacement

The M241 mouse has an approximate battery life of 18 months. When the battery is low, the LED indicator on the mouse may blink or stop illuminating. Replace the AA battery as described in the "Battery Installation" section under Setup.

Troubleshooting

Problem	Solution
Mouse does not connect or respond.	 Ensure the mouse is powered on. Check the battery level and replace if necessary. Ensure Bluetooth is enabled on your device. Re-pair the mouse with your device (refer to "Bluetooth Pairing" section). Move the mouse closer to your device to ensure it is within the 10m/33ft range. Try connecting to a different Bluetooth-enabled device to rule out device-specific issues.
Erratic cursor movement.	 Clean the optical sensor on the underside of the mouse. Ensure you are using the mouse on a suitable surface. Avoid highly reflective or transparent surfaces. Check for any obstructions between the mouse and your device. Replace the battery.
Mouse clicks are not silent.	The M241 features SilentTouch Technology for reduced click noise. If you experience unusually loud clicks, ensure the mouse is clean and free from debris. If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Logitech
Model Name	M241
Model Number	910-007416
Connectivity Technology	Bluetooth
Movement Detection Technology	Optical
Hand Orientation	Ambidextrous
Operating System Compatibility	Windows, macOS, Linux, ChromeOS, iPadOS, Android
Battery Type	1 AA battery
Battery Average Life	18 Months
Wireless Range	Up to 10 meters (33 feet)
Product Dimensions	9 x 4.4 x 0.1 cm
Item Weight	121 g

Feature	Detail
Special Features	Lightweight, Portable, Wireless, SilentTouch Technology

WARRANTY AND SUPPORT

Logitech products are manufactured to high quality standards and are covered by a limited hardware warranty. For detailed warranty information, please refer to the warranty card included with your product or visit the official Logitech website.

For technical support, frequently asked questions, and driver downloads, please visit the Logitech support website:

support.logi.com

© 2024 Logitech. All rights reserved.

Related Documents - M241



Logitech MX Anywhere 3 Mouse Setup and Features Guide

Comprehensive guide to setting up and using the Logitech MX Anywhere 3 compact performance mouse, covering quick setup, detailed setup, connection methods, software features, gestures, and charging.



Logitech M535 Bluetooth Mouse: Features, Setup, and Compatibility Guide

Discover the Logitech M535 Bluetooth Mouse. This guide covers its features, Bluetooth connection steps, customization with Logitech Options software, and compatibility with Windows, Mac OS, Chrome OS, and Android devices.



Logitech M337 Bluetooth Mouse: Features, Setup, and Compatibility Guide

A comprehensive guide to the Logitech M337 Bluetooth Mouse, detailing its features, setup process, gesture controls, power management, and system compatibility for Windows, macOS, Chrome OS, and Android devices.



Logitech M240 for Business Wireless Mouse Datasheet - Features, Specs, Compatibility

Comprehensive datasheet for the Logitech M240 for Business wireless mouse. Details features like Logi Bolt, Silent Touch, 18-month battery, product specifications, compatibility, and environmental certifications.



Logitech Marathon Mouse M705: Getting Started Guide & Features


Comprehensive guide to setting up and using the Logitech Marathon Mouse M705, including features, troubleshooting, and Unifying receiver setup.



Logitech MX Master 3S Getting Started Guide

A comprehensive guide to setting up and using the Logitech MX Master 3S wireless mouse, covering detailed setup, pairing with multiple computers, button customization, gesture controls, and battery management.

Documents - Logitech - M241



ComX-Computers & LaptopDirect Product Price Guide

A comprehensive listing of products, prices, and descriptions from ComX-Computers and LaptopDirect, including various electronics, home appliances, and accessories. Valid as of June 30, 2021.


lang:en score:13 filesize: 4.66 M page_count: 1444 document date: 2021-06-30



[pdf] User Manual

Byte Aug 1988 restored ocr bookmarks by Steve Vintage Apple Items Dump information in manually import it or use ou rpop up ence manual with extensive examples and sample pmgmms Satisfaction 198808 Magazine Vol 13 08 25mhz machines Macintosh Supplement vintageapple org byte ia802909 us archive 17 items BYTE MAGAZINE COMPLETE

lang:en score:12 filesize: 42.75 M page_count: 436 document date: 2018-08-30



Laptop Direct Price Guide - Electronics, Appliances, and Accessories

Explore the comprehensive price list from Laptop Direct, featuring a wide range of electronics, computer accessories, home appliances, personal care items, and more. Find detailed product information and competitive pricing for your needs. lang:en score:9 filesize: 5.82 M page_count: 1901 document date: 2021-06-29