

Urban Deco 455-WL-W

Urban Deco Mini Fridge Stand with Storage (Model 455-WL-W) Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Urban Deco Mini Fridge Stand with Storage, Model 455-WL-W. Please read this guide carefully before use to ensure proper setup and safe operation. Retain this manual for future reference.

SAFETY INFORMATION

Important Safety Instructions:

- Ensure all parts are properly secured before use.
- Do not allow children to play on, with, or around the cart.
- Always use caution when moving the cart, especially on uneven surfaces.
- Be careful around sharp edges during assembly and use.
- Do not exceed the maximum weight capacity of 220 lbs (100 kg) for the tabletop and 110 lbs (50 kg) for the drawer basket.

PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Top Board (1)
- Side Frames with Triangular Bracing (2)
- Connecting Bars (2)
- Drawer Basket (1)
- Swivel Wheels (4, 2 with locks)
- Adjustable Foot Pads (4)
- Drawer Handle (1)

- Assembly Hardware (screws, nuts, wrench)
- Instruction Manual (1)



Image: All components of the Urban Deco Mini Fridge Stand laid out for assembly, including the top board, metal frames, drawer basket, wheels, and hardware.

SETUP AND ASSEMBLY

Follow these steps to assemble your mini fridge stand. It is recommended to assemble on a soft, clean surface to prevent scratches.

1. **Attach Connecting Bars to Side Frames:** Align the connecting bars (F) with the pre-drilled holes on the side frames (E). Secure them using the provided screws and the included wrench. Ensure all connections are firm.
2. **Install Wheels or Foot Pads:** Decide whether to use the swivel wheels for mobility or the adjustable foot pads for stationary use. Screw the chosen components into the bottom of the assembled frame. If using wheels, ensure the two lockable wheels are installed on the same side for easy access.
3. **Place Top Board:** Carefully place the top board onto the assembled frame, aligning it with the pre-drilled holes. Secure it with the remaining screws.
4. **Assemble Drawer Basket:** Attach the handle to the front of the drawer basket using the provided

hardware.

5. **Insert Drawer Basket:** Slide the assembled drawer basket into the designated space under the top board.

Your browser does not support the video tag.

Video: Official assembly guide for the Urban Deco Mini Fridge Stand, demonstrating step-by-step construction.



Image: Detailed view of the stand's features, including the mesh drawer, handle, triangular frame, and locking wheels.

OPERATING INSTRUCTIONS

This section outlines the proper use of your Urban Deco Mini Fridge Stand.

- **Placement:** Position the stand on a flat, stable surface. Place your mini fridge, compact freezer, beverage cooler, or other appliance on the top board. Ensure the appliance's weight does not exceed 220 lbs (100 kg).
- **Using the Drawer Basket:** The slide-out metal mesh basket is designed for storing snacks, beverages, daily necessities, or household tools. It has a capacity of 110 lbs (50 kg). Pull the handle to access the contents.
- **Mobility:** If using wheels, unlock the two locking wheels to move the stand. To secure the stand in

place, engage the locks on the two locking wheels.

- **Stability with Foot Pads:** If using adjustable foot pads, rotate them to level the stand on uneven surfaces, ensuring maximum stability.

Multi-purpose Storage Stand



Compact Freezer



Mini Fridge



Beverage Refrigerator



Freestanding Wine Cabinet



Image: The stand's versatility, accommodating various mini appliances like compact freezers, mini fridges, beverage refrigerators, and wine cabinets.

Large Capacity Storage



Image: The stand providing large capacity storage, effectively saving space with a removable basket that can be pulled out.

MAINTENANCE

Regular maintenance helps prolong the life of your product.

- **Cleaning:** Wipe the metal frame and top board with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Wheel Care:** Keep the wheels free of debris to ensure smooth movement.

TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions.

- **Stand is wobbly:**
 - Ensure all assembly screws are tightened securely.
 - If using foot pads, adjust them to level the stand on uneven floors.

- Verify that the appliance on top is centered and its weight is evenly distributed.
- **Wheels do not roll smoothly:**
 - Check if the wheel locks are engaged. Disengage them for movement.
 - Remove any debris (hair, dust) that may be caught in the wheels.
- **Drawer basket is difficult to slide:**
 - Ensure the basket is properly aligned within its runners.
 - Check for any obstructions preventing smooth movement.
 - Do not overload the basket beyond its 110 lbs (50 kg) capacity.

SPECIFICATIONS

Model Number	455-WL-W
Product Dimensions (L x W x H)	20.8"D x 20.8"W x 14.6"H (52.8 cm D x 52.8 cm W x 37.1 cm H)
Item Weight	11.88 Kilograms (26.2 lbs)
Material	Metal Frame, Eco-Boards
Color	White
Maximum Top Load Capacity	220 lbs (100 kg)
Maximum Drawer Basket Load Capacity	110 lbs (50 kg)
Features	Reinforced Steel Framing, Dual Load-Bearing Bars, Metal Triangular Bracing, Slide-out Metal Mesh Basket, 360° Swivel Wheels (2 lockable), Adjustable Foot Pads, Impact Resistance



WATERPROOF



EASY TO CLEAN



STRUCTURALLY SOLID



STRONG LOAD-BEARING



The 2 steel pipes provide greater structural stability under load





Image: Dimensional diagram and load capacities for the stand and its drawer basket.

WARRANTY INFORMATION

Urban Deco products are manufactured to high-quality standards. For specific warranty details regarding your Mini Fridge Stand, please refer to the warranty card included with your purchase or contact Urban Deco customer support. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For assistance with assembly, missing parts, or any other inquiries, please contact Urban Deco customer support through the retailer's platform or visit the official Urban Deco website for contact information.