

PURPLE LEAF ZYFR01HLRRC0911-GY

PURPLE LEAF 2.7 x 3.5 m Rectangular Cantilever Parasol Instruction Manual

Model: ZYFR01HLRRC0911-GY

1. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Ensure the parasol base is adequately weighted to prevent tipping, especially in windy conditions. The weighted base is not included and must be purchased separately.
- Do not use the parasol in strong winds or storms. Close and secure it to prevent damage or injury.
- Keep children and pets away from the parasol during assembly and operation.
- Avoid placing the parasol near open flames or heat sources.
- Regularly inspect all components for wear and tear. Replace damaged parts immediately.

For additional safety guidelines, refer to the official safety document: [Safety Information \(PDF\)](#).

2. PRODUCT OVERVIEW

The PURPLE LEAF Cantilever Parasol provides shade and UV protection for your outdoor living space. It features a robust aluminum frame and a durable polyester canopy.



Image: The PURPLE LEAF cantilever parasol providing shade over an outdoor seating area next to a pool.

Key Features:

- **Modern Design:** Champagne-colored ribs and a triangular structure for enhanced stability.
- **Easy Operation:** Crank mechanism for opening/closing and a pedal for 360° rotation.
- **UV Protection:** 240 g/m² solution-dyed polyester canopy with UPF 50+ rating.
- **Adjustable Tilt:** 5-level inclination for optimal shade positioning.
- **Durable Construction:** Robust aluminum frame and ribs, resistant to rust and fading.



Image: Close-up view of the parasol's internal structure, showing the robust aluminum ribs and frame, emphasizing wind resistance and durability.

3. SETUP AND ASSEMBLY

Assembly typically requires two people. Ensure all parts are present before beginning.

Package Contents:

Refer to your product packaging for a complete list of included components. The weighted base is not included and must be purchased separately.

Assembly Steps:

1. **Prepare the Base:** Place the parasol base (not included) in the desired location. Ensure it is stable and adequately weighted.
2. **Attach the Pole:** Securely attach the main pole of the parasol to the base according to the base's instructions.
3. **Unfold the Canopy:** Use the crank mechanism to slowly open the parasol canopy. Ensure all ribs extend fully without obstruction.
4. **Adjust Position:** Once open, you can adjust the parasol's position using the rotation pedal and tilt mechanism.

La base lestée n'est pas incluse



Image: Diagram illustrating the dimensions of the parasol and explicitly stating that the weighted base is not included.

4. OPERATING INSTRUCTIONS

Opening and Closing the Parasol:

- To open the parasol, turn the crank handle clockwise until the canopy is fully extended.
- To close the parasol, turn the crank handle counter-clockwise until the canopy is fully retracted.



Image: Detail of the crank handle, showing its design and function for easy adjustment of the parasol canopy.

360° Rotation:

- The parasol features a foot pedal at the base for 360° rotation.
- Press the pedal to unlock the rotation mechanism, then gently rotate the parasol to the desired position.
- Release the pedal to lock the parasol in place.

Rotation à 360

La fonction de rotation permet à votre parasol de changer librement de place.






Image: The foot pedal at the base of the parasol, which controls the 360-degree rotation feature.

Tilt Adjustment:

- The parasol offers 5 levels of inclination.
- Adjust the tilt by manipulating the handle on the main pole to achieve the desired angle of shade.

 Contrôle facile



Disponible en 5 hauteurs et angles

Parasol cantilever réglable pour différentes positions au soleil

Image: A visual representation of the parasol's ability to adjust its height and angle across five different positions.

5. MAINTENANCE

Proper maintenance will extend the life of your parasol.

- **Canopy Cleaning:** Clean the canopy by hand with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners.
- **Frame Cleaning:** Wipe the aluminum frame with a dry cloth to remove dust and debris.
- **Storage:** When not in use, especially during off-season or severe weather, close the parasol and cover it with a protective cover (not included). Store in a dry, sheltered area.
- **Inspection:** Periodically check all screws and connections to ensure they are tight.



Image: Detailed view of the parasol's polyester fabric, emphasizing its quality, UV protection, and resistance to fading.

6. TROUBLESHOOTING

- **Parasol does not open/close smoothly:** Check for any obstructions in the mechanism or canopy. Ensure the crank handle is not damaged.
- **Parasol is unstable:** Verify that the base is properly weighted and placed on a flat, stable surface. Ensure all connections are secure.
- **Canopy fading:** While the canopy is fade-resistant, prolonged exposure to intense sunlight can still cause some fading over time. Use a protective cover when not in use.

7. SPECIFICATIONS

Feature	Specification
Brand	PURPLE LEAF
Model Number	ZYFR01HLRRC0911-GY
Color	Gris acier (Steel Grey)
Size	2.7 X 3.5 m
Item Shape	Rectangular
Canopy Material	Polyester (240 g/m ² , UPF 50+)
Frame Material	Aluminum
Pole Material	Aluminum
Handle Material	Aluminum
Opening Mechanism	Crank Lift
Tilt Mechanism	Manual Tilt (5 levels)
Special Feature	Cantilever, 360° Rotation
Item Weight	30.77 Kilograms
Care Instructions	Hand wash canopy with damp cloth, wipe frame with dry cloth
Country of Origin	China

8. WARRANTY AND SUPPORT

For warranty information and customer support, please contact PURPLE LEAF directly or refer to your purchase documentation. Keep your proof of purchase for any warranty claims.

You can visit the PURPLE LEAF store for more products and support: [PURPLE LEAF Store](#).