Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- advwin /
- advwin 24-Inch 4 Burner 6000W Electric Ceramic Cooktop Instruction Manual

advwin Electric Cooktop

advwin 24-Inch 4 Burner 6000W Electric Ceramic Cooktop Instruction Manual

Model: Electric Cooktop (ASIN: B0DP2QY14D)

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your advwin 24-inch 4 burner 6000W electric ceramic cooktop. Please read all instructions carefully before installation and use, and retain this manual for future reference.

IMPORTANT SAFETY INFORMATION

- Electrical Requirements: This appliance is exclusively designed for 220-240V systems. It is not compatible with 110-120V regions. A dedicated air switch (sold separately) must be installed for safe operation. Consult a licensed electrician to ensure compliance with local electrical standards and proper installation.
- Hot Surface Warning: The ceramic plate remains hot after cooking. Avoid touching the hot surface with bare hands to prevent burns. Indicator lights will signal when a burner is hot.
- Child Safety Lock: Utilize the integrated child safety lock feature to prevent accidental or unsupervised usage, ensuring the safety of children in the household.
- **Installation:** Professional assistance is recommended for installation to ensure correct setup and adherence to all safety guidelines.
- Cookware: Ensure cookware is suitable for electric ceramic cooktops.

SETUP AND INSTALLATION

1. Electrical Connection

The cooktop requires a 220-240V electrical supply. A dedicated 40 Amp Miniature Circuit Breaker (MCB) and 6mm cable are typically required for a 6.5 Kw hob. It is crucial to consult a licensed electrician for proper wiring and connection to your home's electrical system. Ensure all local electrical codes are met.

Video: Power Cord Installation Guide. This video demonstrates the process of connecting the power cord to a cooktop, highlighting the types of wires and connections required for a safe and compliant electrical setup. Consult a qualified electrician for professional installation.

2. Countertop Preparation

This is a built-in drop-in electric cooktop. Ensure your countertop has a cut-out size of 22 inches by 20 inches (55.88 cm x 50.8 cm) to accommodate the unit. The product dimensions are 23.2 inches x 20.3 inches x 2.9 inches (58.9 cm x 51.5 cm x 7.3 cm).



Image: Illustration of the cooktop's dimensions and the required countertop cut-out size for built-in installation. This ensures proper fit and integration into your kitchen space.

OPERATING INSTRUCTIONS

1. Powering On and Zone Selection

The cooktop features four powerful cooking zones with a total output of 6000W. There are two high-power burners (1800W each) and two low-power burners (1200W each). To activate a cooking zone, use the touch controls located on the cooktop's surface. Select the desired burner and adjust the power level.



Image: The advwin 4-burner electric ceramic cooktop in operation, showing the different wattage outputs for each cooking zone (two 1800W and two 1200W burners). This illustrates the cooktop's capacity for simultaneous cooking.

2. Adjusting Power Levels

The cooktop offers 9 heating levels for precise temperature control. Use the touch controls to increase or decrease the heat intensity for each individual burner. This allows for versatile cooking, from gentle simmering to rapid boiling.



Image: A visual representation of the cooktop's 9 power level settings, indicating the range of heat control available for various cooking needs. This highlights the flexibility in adjusting heat for different dishes.

3. Timer Function

The cooktop includes a 4-hour timer and a pause function. This feature allows you to set a cooking duration, after which the burner will automatically shut off. This is useful for preventing overcooking and managing cooking times effectively.



Image: A graphic illustrating the timer function on the cooktop, showing a clock icon and a visual representation of time passing. This feature helps users manage cooking durations and prevent overcooking.

4. Child Safety Lock

Activate the child safety lock to disable the control panel, preventing accidental changes to settings or activation of burners by children. To engage or disengage the lock, refer to the specific instructions in the full user manual.



Image: A visual of the child safety lock feature, depicted with a lock icon on the control panel. This function is designed to prevent unintended operation of the cooktop, enhancing household safety.

5. Compatible Cookware

The ceramic cooktop is compatible with various types of cookware, including stainless steel, cast iron, aluminum, copper, and non-magnetic pans. This versatility allows you to use your existing pots and pans without needing specialized induction-compatible cookware.



Image: A collage showcasing different types of cookware, such as woks, aluminum, ceramic, stainless steel, glass, and cast iron pans, all compatible with the electric ceramic cooktop. This highlights the cooktop's versatility with various kitchen utensils.

Video: Empava 24 Inch Electric Cooktop 4 Burners 24REC11. This video demonstrates the cooktop in use, showing various cooking activities and the ease of operation with different pots and pans.

Video: 24 inch electric cooktop 4 burner. This short video demonstrates the touch controls and digital display of the 4-burner electric cooktop, showing how to adjust heat settings.

MAINTENANCE AND CLEANING

The smooth ceramic glass surface of the cooktop makes cleaning simple. Allow the cooktop to cool completely before cleaning. Use a soft rag and mild soap water to wipe down the surface. For stubborn stains, a provided scrape can be used carefully. Avoid abrasive cleaners or scouring pads that could scratch the surface.



Image: A hand in a yellow glove cleaning the ceramic cooktop surface with a sponge, illustrating the ease of maintenance. The smooth glass surface simplifies cleanup after cooking.

Troubleshooting

If you encounter any issues with your cooktop, please refer to the comprehensive troubleshooting section in the full user manual.

Common issues may include power supply problems, incorrect settings, or cookware incompatibility. Ensure the cooktop is properly connected to the power supply and that the correct power levels are selected. If problems persist, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	advwin
Model Name	electric cooktop
Product Dimensions	23.2"D x 20.3"W x 2.9"H (58.9 cm x 51.5 cm x 7.3 cm)
Cut-out Dimensions	22" x 20" (55.88 cm x 50.8 cm)
Item Weight	21.7 pounds (9.84 kg)
Installation Type	Drop-In
Heating Elements	4 Burners (2x 1800W, 2x 1200W)
Total Wattage	6000 watts
Voltage	220-240V
Control Type	Digital Touch / Knob Control
Heating Levels	9
Timer	4-hour timer with pause function
Safety Features	Kid Safety Lock, Over-Temperature Protection, Residual Heat Warning
Heater Surface Material	Glass Ceramic
Included Components	1*Electric Cooktop, Scrape for cleaning

WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please contact advwin customer service. Refer to your purchase documentation for specific warranty terms and contact details. Always provide your product model number (Electric Cooktop) and ASIN (B0DP2QY14D) when seeking support.

© 2025 advwin. All rights reserved.

Related Documents - Electric Cooktop



Upright Freezer User Manual - BD-88-E | Installation, Operation, Safety & Care

Comprehensive user manual for the ADVWIN BD-88-E upright freezer. Covers important safety instructions, installation, operation, features, defrosting, cleaning, food storage, and troubleshooting for optimal use and maintenance.



Musical Boxing Pro: Smart Music Wall Mounted Boxing Training Machine User Manual

Learn how to set up and operate the Musical Boxing Pro, a smart music wall-mounted boxing training machine for home workouts and stress relief. Includes technical data, operation guide, assembly instructions, and safety precautions.



Portable Washing Machine User Manual

This manual provides instructions and specifications for the Advwin portable washing machine, covering its electrical principle, parts, operation, maintenance, and troubleshooting.



Advwin BCD-90 Refrigerator User Manual

User manual for the Advwin BCD-90 refrigerator, detailing safety precautions, installation, features, operation, care, and troubleshooting. Includes model numbers 140900200 and 141100800.



ADVWIN Vibration Exercise Platform User Manual

Comprehensive user manual for the ADVWIN Vibration Exercise Platform, detailing safety information, package contents, unit components, specifications, operation, maintenance, troubleshooting, and exercise guides.



ADVWIN HZB-12E Portable Ice Maker User Manual

Comprehensive user manual for the ADVWIN HZB-12E portable ice maker, detailing setup, operation, maintenance, troubleshooting, and technical specifications. Learn how to make ice cubes and dispense water with this user-friendly appliance.