



[Manuals.plus](#) /

› [GameSir](#) /

› GameSir Cyclone 2 Multiplatform Wireless Controller User Manual

GameSir Cyclone 2

GameSir Cyclone 2 Multiplatform Wireless Controller User Manual

Model: Cyclone 2

1. INTRODUCTION

The GameSir Cyclone 2 is a versatile multiplatform wireless controller designed for an enhanced gaming experience across various systems. It features advanced TMR Electromagnetic Joysticks, Hall Effect Switch triggers, and a 6-axis Gyro for precise control. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting.



Figure 1: GameSir Cyclone 2 Multiplatform Wireless Controller (Phantom White)

The controller is compatible with PC, Steam, Nintendo Switch, iOS, and Android platforms, offering flexible connectivity options including Bluetooth, 2.4G wireless, and wired USB connection.

2. SETUP

2.1 Package Contents

- GameSir Cyclone 2 Wireless Controller
- USB-C Charging Cable
- 2.4G Wireless Dongle (if included in your edition)
- User Manual

2.2 Initial Charging

Before first use, fully charge the controller using the provided USB-C cable. Connect the USB-C end to the controller and the USB-A end to a power source (e.g., PC USB port, USB wall adapter). The 860mAh battery provides long-lasting play.

860mAh BATTERY FOR LONG-LASTING PLAY



Figure 2: 860mAh Battery for Extended Play

2.3 Connecting the Controller

The GameSir Cyclone 2 offers multiple connection methods:

- **Bluetooth:** For iOS, Android, and Nintendo Switch. Refer to your device's Bluetooth settings for pairing instructions.
- **2.4G Wireless:** For PC and Nintendo Switch. Insert the 2.4G wireless dongle into an available USB port on your device. The controller should automatically connect.
- **Wired USB:** For PC. Connect the controller directly to your PC using the USB-C cable.

2.4 GameSir Connect Software Installation

To unlock full customization options and update firmware, download and install the latest version of the GameSir Connect software from the official GameSir website or the Microsoft Store. This software allows for button remapping, macro creation, dead zone adjustments, and more.




Figure 3: GameSir Connect Software for Full Customization

Your browser does not support the video tag.

Video 1: How to connect your GameSir Cyclone 2 to GameSir Connect software and update firmware.

3. OPERATING INSTRUCTIONS

3.1 Key Features and Controls

- **TMR Electromagnetic Joysticks:** Experience linear output, high precision, and enhanced durability.
- **Hall Effect Switch Triggers:** Offers both analog precision for racing games and hair-trigger mode for rapid response in FPS/action games.
- **6-axis Gyro:** Provides precise motion control for immersive gameplay, especially on Nintendo Switch.
- **RGB Lighting:** Customizable RGB lighting strip for personalized aesthetics.
- **1000Hz Report Rate:** Ensures highly responsive input in both wired and wireless modes.
- **Professional Button Layout:** Xbox-style layout with two customizable back buttons (R4/L4).
- **3.5mm Headphone Jack:** For audio connectivity during wireless play.

ADVANCED FEATURES

Perfect for Esports




Figure 4: Advanced Features of the GameSir Cyclone 2

3.2 Motion Mapping

The GameSir Cyclone 2 supports motion mapping via the GameSir Connect software. This feature allows you to map controller movements to in-game actions, enhancing precision and immersion.

- **Aim Mode:** Suitable for mapping the right joystick to simulate viewpoint control.
- **Tilt Mode:** Ideal for mapping the left joystick to simulate steering wheel control in driving games.

Within the software, you can customize X-Axis output modes, activation methods, dead zones, anti-dead zones, and sensitivity curves for precise control.

Your browser does not support the video tag.

Video 2: Overview of GameSir Cyclone 2 features, including motion mapping, TMR sticks, and Hall Effect triggers.

4. MAINTENANCE

4.1 Cleaning

To clean your controller, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials, as these can damage the controller's finish and internal components.

4.2 Storage

Store the controller in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, ensure the battery is partially charged (around 50%) to maintain battery health.

4.3 Battery Care

The 860mAh battery is designed for durability. To prolong its lifespan, avoid completely draining the battery frequently and do not leave it uncharged for very long periods. Charge the controller using only approved USB power sources.

5. TROUBLESHOOTING

5.1 Connection Issues

- **Controller not connecting:** Ensure the controller is charged. For 2.4G wireless, check if the dongle is properly inserted and recognized by your device. For Bluetooth, ensure Bluetooth is enabled on your device and the controller is in pairing mode.
- **Intermittent disconnections:** Ensure there are no obstructions between the controller and the wireless receiver (dongle or Bluetooth device). Avoid strong electromagnetic interference.

5.2 Input Lag or Unresponsiveness

- **Check Report Rate:** Ensure the 1000Hz report rate is active in GameSir Connect software for optimal responsiveness.
- **Adjust Dead Zones:** If joysticks or triggers feel unresponsive, adjust dead zone settings in the GameSir Connect software.
- **Firmware Update:** Always ensure your controller's firmware is up to date using the GameSir Connect software. Firmware updates often include performance improvements and bug fixes.

5.3 Other Issues

- **Buttons not responding:** Verify button mappings in GameSir Connect. Clean around the buttons if they feel sticky.
- **Vibration issues:** Check vibration settings in GameSir Connect. Ensure rumble motors are enabled.

6. SPECIFICATIONS

Feature	Detail
Model Name	Cyclone 2
Brand Name	GameSir
Controller Type	Gamepad
Compatible Devices	Android, iOS, Nintendo Switch, PC
Connectivity Technology	Bluetooth, 2.4G Wireless, USB (Wired)
Joysticks	TMR Electromagnetic Joysticks
Triggers	Hall Effect Switch Triggers (Analog & Hair Trigger Modes)
Gyroscope	6-axis Gyro

Feature	Detail
Report Rate	1000Hz (Wired & Wireless)
Battery Capacity	860mAh
Additional Features	Customizable RGB Lighting, Asymmetrical Vibration Motors, Two Customizable Back Buttons, 3.5mm Headphone Jack
Item Weight	450 Grams

7. WARRANTY AND SUPPORT

7.1 Warranty Information

The GameSir Cyclone 2 Multiplatform Wireless Controller comes with a **1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and ensures product quality. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For any product inquiries, technical assistance, or warranty claims, please contact GameSir customer support. You can typically reach support through the following channels:

- **Amazon Messaging:** Send a message to the seller (JOBBALON) through your Amazon order history.
- **Official GameSir Website:** Visit the GameSir official website for support resources, FAQs, and contact information.

GameSir aims to respond to inquiries within 24 hours.