



[Manuals.plus](#) /

› [GameSir](#) /

› GameSir G8 Plus Thanos Edition Mobile Game Controller User Manual

GameSir G8 Plus

GameSir G8 Plus Thanos Edition Mobile Game Controller User Manual

Model: G8 Plus | Brand: GameSir

INTRODUCTION

The GameSir G8 Plus Thanos Edition is a versatile mobile game controller designed to provide a console-like gaming experience across multiple platforms. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your controller.



Figure 1: GameSir G8 Plus Thanos Edition Mobile Game Controller.

SETUP

Package Contents

Verify that all items are present in the package:

- GameSir G8 Plus Thanos Edition Mobile Game Controller
- Interchangeable Thumbstick Caps (3 pairs)
- USB-C Cable
- User Manual (this document)




Figure 2: Contents of the GameSir G8 Plus Thanos Edition package.

Device Compatibility

The GameSir G8 Plus is compatible with a wide range of devices:

- Android devices (Android 8.0 or later)
- iOS devices
- Nintendo Switch
- Tablets (4.7 to 8.4 inches)
- PC (via 2.4G receiver, sold separately, or wired)

UNIVERSAL COMPATIBILITY



Figure 3: Universal compatibility of the GameSir G8 Plus.

Initial Connection

To connect your GameSir G8 Plus controller to a device:

1. **For Mobile Devices (Bluetooth):** Extend the controller to fit your smartphone or tablet. Ensure Bluetooth is enabled on your device. Press and hold the pairing button on the controller until the indicator light flashes, then select "GameSir G8 Plus" from your device's Bluetooth settings.
2. **For Nintendo Switch:** Insert the Switch console into the controller. The controller should automatically connect.
3. **For PC (Wired):** Connect the controller to your PC using the provided USB-C cable.
4. **For PC (2.4G Wireless):** Insert the 2.4G receiver (sold separately) into your PC's USB port. The controller should connect automatically.

Video 1: Overview of the Gamesir G8 Plus Bluetooth Marvel Licensed controller, demonstrating its design and features.

OPERATING


Key Features and Controls

- **Hall Effect Joysticks:** Experience precise 360° control with anti-drift technology, ensuring longevity and accuracy.
- **Hall Effect Triggers:** Optimized triggers provide smooth and quick response, ideal for various game genres.
- **Mappable Back Buttons:** Two additional back buttons (L4/R4) allow for instant button mapping, enhancing gameplay customization.
- **Motion Sensing:** A built-in 6-axis gyroscope enhances motion control, particularly useful for compatible Switch games and motion-sensitive gameplay.
- **Haptic Feedback:** Console-level haptic feedback provides realistic and immersive sensations during gameplay.



Figure 4: Explanation of GameSir Hall Effect Sticks.

TOGGLE TRIGGER MODES



© 2024 MARVEL

Figure 5: Toggle Trigger Modes for different game types.

MOTION CONTROL



Immersive
gaming



Precise
control



Built-in
6-axis gyro



© 2024 MARVEL

Figure 6: Motion Control capabilities with built-in 6-axis gyro.



Figure 7: Realistic and immersive haptic sensation.

Customization

- **Magnetic Faceplates:** The controller features magnetic faceplates that can be easily removed and swapped for personalized aesthetics or maintenance.
- **Interchangeable Thumbstick Caps:** Three pairs of thumbstick caps with varying heights are included, allowing users to customize control feel.
- **GameSir App:** The GameSir app (Android exclusive) allows for real-time customization, including button mapping and sensitivity adjustments, for personalized gameplay.





Figure 8: Free customization options for the controller.


ADVANCED FEATURES




Magnetic Faceplate



Remapping on the Fly



Anti-slip Textured Surface



More Compatibility

*For devices with a big camera.

© 2024 MARVEL

Figure 9: Advanced features of the GameSir G8 Plus.

Video 2: Introduction to the GameHub App, showcasing its features for game management and controller customization.

Mode Switching

The controller supports various modes for different platforms. To switch between modes, press the corresponding key combination:

| Mode | Home Indicator | Connection Method | Compatible Platform |
|---------|----------------|-------------------|-------------------------------|
| Android | Green | Controller + A | Android 8.0 or later versions |
| DS4 | Blue | Controller + B | iOS |
| Switch | Red | Controller + X | Switch |
| G-Touch | Cyan | Controller + Y | GameSir App |

*In working status, press corresponding key combination to switch to the desired mode.

MAINTENANCE

To ensure the longevity and optimal performance of your GameSir G8 Plus controller, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the controller. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures. When not in use for extended periods, ensure it is fully charged before storage.
- **Handling:** Avoid dropping the controller or subjecting it to strong impacts. Do not attempt to disassemble the controller beyond removing the magnetic faceplates and thumbstick caps.

TROUBLESHOOTING

If you encounter issues with your GameSir G8 Plus controller, refer to the following common troubleshooting steps:

- **Controller Not Connecting:** Ensure Bluetooth is enabled on your device and the controller is in the correct mode (Android, DS4, Switch). Try restarting both the controller and your device. For wired connections, ensure the USB-C cable is securely connected.
- **Buttons or Joysticks Unresponsive:** Check if the controller's battery is charged. If using the GameSir App, verify that button mappings are correctly configured. For Hall Effect Joysticks, recalibration might be necessary if drift occurs (refer to GameSir App for calibration options).
- **Device Not Fitting:** Ensure your device's dimensions are within the supported range of 4.7 to 8.4 inches. The controller's design accommodates devices with larger cameras.
- **GameSir App Issues:** Ensure your GameSir App is updated to the latest version. The app is currently exclusive to Android devices.

For further assistance, please contact GameSir customer support.

SPECIFICATIONS

Detailed specifications for the GameSir G8 Plus Thanos Edition Mobile Game Controller:

| Feature | Detail |
|-------------------------|--|
| Compatible Devices | Android, iOS, Nintendo Switch, PC |
| Controller Type | Gamepad |
| Connectivity Technology | Bluetooth 5.3, USB, 2.4G (receiver sold separately) |
| Additional Features | Multiuse, Wireless, Hall Effect Joysticks & Triggers, 6-axis Gyroscope, Mappable Back Buttons, Magnetic Faceplates, Interchangeable Thumbstick Caps, Pass-through Charging |
| Button Quantity | 6 (standard face buttons) + D-pad, shoulder buttons, triggers, menu buttons, 2 back buttons |
| Hardware Platform | Smartphone, Tablet, Nintendo Switch, PC |

| Feature | Detail |
|--------------|--|
| Power Source | Battery Powered (500mAh per side) |
| Item Weight | 620 Grams |
| Model Name | G8 Plus |
| Manufacturer | GameSir |
| Color | Gamesir G8 Plus Thanos Edition (Gold/Purple) |

WARRANTY AND SUPPORT

Warranty Information

The GameSir G8 Plus Thanos Edition Mobile Game Controller comes with a **1-Year Warranty**. GameSir provides 12 months replacement service for product issues.

Customer Support

If you experience any problems with your product or require further assistance, please feel free to send a message through Amazon. GameSir aims to reply within 24 hours.