Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Jkarao /
- Ikarao Shell S1 Karaoke Machine User Manual

Ikarao Shell S1

Ikarao Shell S1 Karaoke Machine User Manual

Model: Shell S1

1. Introduction

This user manual provides comprehensive instructions for the safe and efficient operation of your Ikarao Shell S1 Karaoke Machine. Please read this manual thoroughly before using the product and retain it for future reference. The Ikarao Shell S1 is a portable karaoke system featuring a built-in display, powerful speaker, and wireless microphones, designed for various entertainment settings.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Ikarao Shell S1 Karaoke Machine
- 2 Wireless Microphones
- Shoulder Strap
- USB-C Charging Cable (Charger not included)
- User Manual



Image: The Ikarao Shell S1 Karaoke Machine with its included accessories: two wireless microphones, a shoulder strap, a USB-C charging

3. PRODUCT OVERVIEW

The Ikarao Shell S1 is designed for versatile audio entertainment. It integrates a powerful speaker system with a smart display and wireless microphones, suitable for various environments.

Key Features:

- 280W Speaker System: Features dual woofers for deep bass and dual dome tweeters for clear high frequencies, capable of filling spaces up to 800 sq. ft.
- 10.1" HD Display: An integrated screen compatible with Android V13, preloaded with Karafun software, and capable of streaming online content.
- **Dual Wireless Microphones:** Self-charging microphones with adjustable EQ effects and anti-spray covers for clear vocal reproduction.
- Multiple Connectivity: Supports Wi-Fi, Bluetooth, AUX, USB, and HDMI for diverse audio and video sources.
- Long Battery Life: The main unit provides extended playback, and microphones offer up to 20 hours of usage with quick charging.
- **Portable Design:** Equipped with a shoulder strap for easy transport and a built-in power bank function for emergency device charging.



Image: The Ikarao Shell S1 Karaoke Machine shown with its top screen open, revealing the storage and charging slots for the two wireless microphones.

4. SETUP

4.1 Initial Charging

Before first use, fully charge the Ikarao Shell S1. Connect the provided USB-C charging cable to the charging port on the device and to a compatible USB power adapter (not included). The device includes a 12V Lithium Ion battery. The microphones also feature self-charging capabilities; place them in their designated slots on the main unit for charging.

4.2 Power On/Off

To power on the device, press and hold the power button located on the front panel. Repeat the action to power off the device.

5. OPERATING INSTRUCTIONS

5.1 Using the 10.1" HD Display

The integrated 10.1-inch HD screen runs on Android V13 and comes with Karafun software preloaded. This allows for direct access to karaoke content and other online streaming services like YouTube. Ensure the device is connected to Wi-Fi for online content access.



Image: The Ikarao Shell S1's integrated screen showing the YouTube application interface, indicating its capability for online video streaming.

5.2 Wireless Microphones

The system includes two wireless microphones. These microphones automatically charge when placed in their dedicated slots on the main unit. A 3-minute charge provides approximately 30 minutes of singing time, with a total usage time of up to 20 hours when fully charged.

Microphones feature adjustable EQ effects with 8 modes, including "Super" for deep bass and "Karaoke" for crisp highs. They also incorporate a double-layer anti-spray cover to reduce sound bursts.

Enjoy Contents in Vivid Detail Crystal clear lyrics & video. HD resolution brings your content to life with vivid clarity.

Image: A close-up view of the two wireless microphones securely placed in their charging slots within the Ikarao Shell S1 Karaoke Machine.



Image: The Ikarao Shell S1's display showing various microphone modes and EQ settings for reverb, treble, and bass, allowing users to customize vocal output.

5.3 Audio Connectivity

The Ikarao Shell S1 offers multiple ways to connect audio sources:

- Wi-Fi: Connect to a wireless network to stream music directly from online services.
- Bluetooth: Pair with Bluetooth-enabled devices like smartphones or tablets for wireless audio playback.
- AUX Input: Use a 3.5mm audio cable to connect external devices.
- USB: Play media files from a USB drive.
- HDMI Output: Connect the device to a TV or projector to display lyrics and video on a larger screen.

• Additional Microphone/Instrument Inputs: Two 1/4-inch inputs are available for connecting wired microphones or instruments like a guitar.



Image: The Ikarao Shell S1 highlighting its diverse connectivity options, including USB, HDMI, AUX, MIC, OTG, and Bluetooth, for versatile media playback.




Image: The Ikarao Shell S1 connected to a large television screen via HDMI, demonstrating its capability to display lyrics and video content on an external display.

5.4 Sound Adjustment

The device features controls for adjusting the overall sound output. Utilize the bass boost function for enhanced low frequencies. Microphone EQ settings can be adjusted via the display to fine-tune vocal performance.

280W Peak Power

Music and vocals stay clear, high-quality sound encourages guests to join in, and the sound fills every corner of the venue.



Image: An internal diagram of the Ikarao Shell S1's speaker system, illustrating the dual woofers and tweeters responsible for its 280W sound output.

6. MAINTENANCE

6.1 Cleaning

Wipe the exterior of the device with a soft, dry cloth. Do not use abrasive cleaners or solvents. For the display screen, use a screen-specific cleaning solution and a microfiber cloth. Ensure the device is powered off and unplugged before cleaning.

6.2 Storage

When not in use for extended periods, store the karaoke machine in a cool, dry place away from direct sunlight and extreme temperatures. Ensure microphones are fully charged before storage to maintain battery health.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution	
Device does not power on.	Low battery or power cable not connected.	Charge the device fully. Ensure the power cable is securely connected.	
No sound from speakers.	Volume too low, incorrect input source, or device not paired.	Increase volume. Select the correct input source (Bluetooth, AUX, Wi-Fi). Ensure Bluetooth is paired correctly.	
Microphones not working.	Microphone battery low, not paired, or incorrect microphone mode.	Place microphones in charging slots. Ensure they are paired with the main unit. Check microphone mode settings on the display.	
Wi-Fi connection issues.	Incorrect password, out of range, or network interference.	Verify Wi-Fi password. Move closer to the Wi-Fi router. Restart the device and router.	
Display screen unresponsive.	Software glitch or temporary error.	Restart the device. If the issue persists, contact customer support.	

8. TECHNICAL SPECIFICATIONS

Feature	Detail
Model Number	Ikarao Shell S1
Item Weight	12.96 pounds
Product Dimensions	6.8 x 13.8 x 6.6 inches
Batteries	1 x 12V Lithium Ion battery (included)
Color	Black
Compatible Devices	Laptop, MP3 Player, Projector, Smartphone, Television
Connector Types	3.5 mm Jack, HDMI, USB
Speaker Amplification Type	Active
Speaker Count	2
Output Wattage	280 Watts
Charging Time	3 Hours (for main unit)
Media Format	Digital
Power Source	Battery Powered
Voltage	12 Volts (DC)
Special Features	Bass Boost, Built-In Microphone, Built-In Powerbank, Display, Portable

9. WARRANTY AND SUPPORT

9.1 Product Warranty

The Ikarao Shell S1 Karaoke Machine comes with a 360-day warranty from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact Ikarao customer support:

Email: Support@ikarao.com

Customer service is available 24 hours a day, 7 days a week, 365 days a year.

© 2024 Ikarao. All rights reserved.

