

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [eKids](#) /

› [eKids Pokemon Pokeball Bluetooth Speaker Instruction Manual \(Model Pi-B67PK\)](#)

eKids Pi-B67PK

eKids Pokemon Pokeball Bluetooth Speaker

Model: Pi-B67PK

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your eKids Pokemon Pokeball Bluetooth Speaker. Please read these instructions thoroughly before use and retain them for future reference.

WHAT'S IN THE Box

- eKids Pokemon Pokeball Bluetooth Speaker
- USB-C Charging Cable

PRODUCT OVERVIEW

The eKids Pokemon Pokeball Bluetooth Speaker features a compact, spherical design inspired by the iconic Pokeball. It offers wireless audio streaming and a built-in speakerphone function.



Image: The eKids Pokemon Pokeball Bluetooth Speaker, showcasing its Bluetooth connectivity, rechargeable lithium-ion battery, and USB-C charging cable.

Controls and Ports

- **Power Switch:** Located on the back, slide to ON/OFF.
- **USB-C Charging Port:** Located on the back for charging the internal battery.
- **Multi-function Button:** The central button on the front for playback control and call management.



Image: Rear view of the speaker, detailing the USB-C charging port and the ON/OFF switch.

SETUP

1. Charging the Speaker

1. Connect the supplied USB-C charging cable to the speaker's USB-C port.
2. Connect the other end of the cable to a powered USB port (e.g., computer, USB wall adapter).
3. The LED indicator on the speaker will illuminate to show charging status. A full charge provides up to 10 hours of playtime.

2. Powering On/Off

- To power on, slide the Power Switch to the 'ON' position. The LED indicator will light up.
- To power off, slide the Power Switch to the 'OFF' position. The LED indicator will turn off.

3. Bluetooth Pairing

1. Ensure the speaker is powered on. The LED indicator will flash, indicating it is in pairing mode.
2. On your Bluetooth-enabled device (smartphone, tablet, laptop), go to the Bluetooth settings.
3. Search for available devices and select "eKids Pokeball Speaker" from the list.
4. Once paired, the LED indicator on the speaker will glow solid blue, and you will hear an audible confirmation.



Image: The speaker demonstrating compatibility with mobile phones, tablets, PCs, smartwatches, game devices, and notebooks.

OPERATING INSTRUCTIONS

Playing Audio

- After successful pairing, open your preferred music or audio application on your connected device.
- Audio will stream wirelessly to the Pokeball speaker.
- Use the controls on your connected device to adjust volume, skip tracks, or pause/play.
- The multi-function button on the speaker can be pressed to Play/Pause audio.



Image: A user controlling music playback on the speaker via a smartphone.

Speakerphone Function

- When connected to a Bluetooth-enabled smartphone, you can answer incoming calls directly from the speaker.
- Press the multi-function button once to answer an incoming call.
- Press the multi-function button once again to end the call.

MAINTENANCE

Cleaning

- Wipe the speaker with a soft, dry cloth.
- Do not use liquid cleaners or abrasive materials.

Battery Care

- Charge the speaker fully before first use.
- Avoid exposing the battery to extreme temperatures.
- If storing for an extended period, charge the battery every few months to maintain its lifespan.

TROUBLESHOOTING

No Power

- Ensure the power switch is in the 'ON' position.
- Charge the speaker using the provided USB-C cable.

Cannot Pair via Bluetooth

- Make sure the speaker is in pairing mode (flashing LED).
- Ensure your device's Bluetooth is enabled and within 100 feet of the speaker.

- Try unpairing and re-pairing the speaker from your device's Bluetooth settings.

Poor Audio Quality

- Move the speaker closer to your Bluetooth device.
- Ensure there are no obstructions between the speaker and your device.
- Check the volume levels on both the speaker and your connected device.

SPECIFICATIONS

Model Name	Pi-B67PK
Brand	eKids
Material	Metal, Plastic
Speaker Type	Portable Speaker
Special Feature	Portable
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Range	100 Feet
Power Source	Battery Powered
Battery Capacity	10 Hours
Number of Batteries	1 P76 batteries required (included)
Control Method	Touch
Audio Output Mode	Stereo
Speaker Maximum Output Power	86 Watts
Product Dimensions	3.01"D x 2.96"W x 2.84"H
Item Weight	0.24 Kilograms (8.4 ounces)
Water Resistance Level	Not Water Resistant
Indoor/Outdoor Usage	Indoor

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video from eKids showcasing the features and design of the Pokemon Pokeball Bluetooth Speaker.

WARRANTY AND SUPPORT

Warranty Information

This product comes with a **Limited Warranty**. Please refer to the warranty card included with your

purchase or visit the eKids official website for detailed terms and conditions.

Customer Support

For further assistance, technical support, or warranty claims, please contact eKids customer service through their official website or the contact information provided in your product packaging.

© 2025 eKids. All rights reserved. Pokemon © 1995-2025 Nintendo / Creatures Inc. / GAME FREAK inc. TM, ®, and character names are trademarks of Nintendo.