

Sanford SF5195IC

Sanford SF5195IC Infrared Cooker with BBQ Grill User Manual

1. INTRODUCTION

Thank you for choosing the Sanford SF5195IC Infrared Cooker with BBQ Grill. This appliance combines the functionality of an infrared cooker and a BBQ grill, offering versatile cooking options. It features a powerful 2200W ceramic heating element, a durable stainless steel body, and a high-temperature resistant glass surface. Please read this manual thoroughly before operation to ensure safe and efficient use.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- This appliance is equipped with high and low voltage protection to ensure safety and longevity.
- Ensure proper ventilation around the appliance during use.

3. PRODUCT OVERVIEW

The Sanford SF5195IC is designed for efficient and versatile cooking. It features a sleek design with a durable stainless steel body and a high-temperature resistant glass cooking surface.

3.1 Components

- Infrared Cooker Unit
- BBQ Grill Rack
- Power Cord

3.2 Control Panel and Features

The appliance features a 4-digit LED display and touch controls for easy operation.



Image 1: Sanford SF5195IC Infrared Cooker with BBQ Grill in use, showing the grill rack with food.



Touch Control Panel

Image 2: Close-up view of the touch control panel, highlighting the digital display and function buttons.

- **Power On/Off:** Touch button to turn the appliance on or off.
- **Adjustable Watts with Control Knobs:** Use the rotary knob to customize power output (wattage) for different cooking needs. The 4-digit LED display shows the current wattage.
- **BBQ Function:** Activates the BBQ grilling mode, optimized for use with the included grill rack.
- **Fry Function:** Pre-set function for frying, providing suitable heat levels.
- **Child Lock Function:** Engages a safety lock to prevent accidental operation.
- **Timer Function:** Allows setting a specific cooking duration. The appliance will automatically turn off once the timer expires.
- **High-Temperature Resistant Glass:** Durable and easy-to-clean cooking surface.
- **Stainless Steel Body:** Provides a stylish and robust construction.

sanford

SF5195IC

Infrared Cooker
with BBQ Grill

2In1
Infrared Cooker &
Barbeque Maker



- Soft Finger Touch Control**
- Adjustable Watts With Control Knobs**
- BBQ, Fry and Child Lock Functions**
- Timer Function**
- Digital Display**
- High Temperature Resistant Glass**

Stainless Steel Body



SUITABLE FOR ALL
KINDS OF COOKWARE

2200w
CERAMIC



Image 3: Overview of the Sanford SF5195IC, illustrating its key features such as touch control, adjustable watts, BBQ/Fry/Child Lock functions, timer, digital display, high-temperature resistant glass, and stainless steel body.

4. SETUP

- Unpacking:** Carefully remove the appliance and all accessories from the packaging. Retain packaging for future storage or transport.
- Placement:** Place the infrared cooker on a stable, flat, heat-resistant surface. Ensure there is adequate ventilation around the appliance (at least 10-15 cm clearance from walls or other objects). Do not place it near flammable materials.
- Power Connection:** Ensure the voltage indicated on the appliance matches your local power supply. Plug the power cord into a grounded electrical outlet.
- Initial Cleaning:** Before first use, wipe the glass cooking surface and the BBQ grill rack with a damp cloth. Ensure all parts are dry before plugging in.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation

- Power On:** Press the 'On/Off' touch button. The LED display will illuminate.
- Adjusting Wattage:** Rotate the control knob to increase or decrease the heating power. The LED display will show the selected wattage (up to 2200W).
- Power Off:** Press the 'On/Off' touch button again to turn off the appliance. The surface will remain hot

for some time after use.

5.2 Infrared Cooking

The infrared cooker is suitable for all kinds of cookware, including ceramic, glass, stainless steel, and cast iron. Place your cookware centrally on the heating zone.

1. Place your desired cookware with food onto the ceramic glass surface.
2. Turn on the appliance and adjust the wattage using the control knob.
3. Monitor your cooking and adjust heat as needed.

5.3 BBQ Grilling

Use the included BBQ grill rack for grilling meats, vegetables, and more.

1. Place the BBQ grill rack securely onto the ceramic glass surface. Ensure it is stable.
2. Turn on the appliance and select the 'BBQ' function, or adjust the wattage manually to a high setting.
3. Allow the grill rack to preheat for a few minutes.
4. Place food directly onto the hot grill rack.
5. Use appropriate grilling tools to turn food.

5.4 Special Functions

- **Fry Function:** Press the 'Fry' button to activate a pre-set temperature/power level suitable for frying. You can still adjust the wattage manually if desired.
- **Timer Function:** Press the 'Timer' button, then use the control knob to set the desired cooking time. The appliance will count down and automatically switch off when the time expires.
- **Child Lock Function:** Press and hold the 'Lock' button for a few seconds to activate the child lock. This will disable all other controls. To deactivate, press and hold the 'Lock' button again.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and optimal performance of your appliance.

1. **Always unplug the appliance** from the power outlet and allow it to cool completely before cleaning.
2. **Glass Cooking Surface:** Wipe the ceramic glass surface with a damp cloth and mild detergent. For stubborn stains, use a non-abrasive ceramic hob cleaner. Do not use abrasive pads or harsh chemicals.
3. **BBQ Grill Rack:** The grill rack can be washed with warm soapy water. Ensure it is thoroughly dried before storage.
4. **Stainless Steel Body:** Wipe the stainless steel body with a soft, damp cloth. For best results, use a stainless steel cleaner.
5. **Do not immerse** the main unit, power cord, or plug in water or any other liquid.
6. Ensure all parts are completely dry before storing or reusing the appliance.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	No power supply. Child lock is active.	Check if the power cord is securely plugged into a working outlet. Deactivate the child lock by pressing and holding the 'Lock' button.
Heating is uneven or weak.	Incorrect wattage setting. Cookware not suitable or placed incorrectly.	Increase the wattage using the control knob. Ensure cookware is flat-bottomed and centered on the heating zone.
Appliance makes unusual noise.	Normal fan operation for cooling. Loose component.	A slight fan noise is normal during and after operation. If the noise is excessive or unusual, discontinue use and contact customer support.
Display shows an error code.	Internal malfunction.	Note the error code and refer to the specific troubleshooting section in a full manual (if available) or contact customer support.

8. SPECIFICATIONS

- **Model:** SF5195IC
- **Brand:** Sanford
- **Power:** 2200W
- **Heating Element:** Ceramic Infrared
- **Body Material:** Stainless Steel
- **Cooking Surface:** High-Temperature Resistant Glass
- **Display:** 4-Digit LED
- **Functions:** BBQ, Fry, Child Lock, Timer
- **Voltage Protection:** High and Low Voltage Protection
- **Item Weight:** Approximately 2.84 Kilograms
- **Package Dimensions:** Approximately 44.2 x 34.2 x 9.2 cm

9. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical support, service, or warranty claims, please contact Sanford customer service through their official website or the contact information provided in your product documentation.