

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Reebok](#) /
- › [Reebok Unisex-Adult Press Sneakers Instruction Manual](#)

Reebok Press

Reebok Unisex-Adult Press Sneakers Instruction Manual

Model: Press

1. INTRODUCTION

Welcome to the instruction manual for your new Reebok Unisex-Adult Press Sneakers. These athletic shoes are designed for comfort, durability, and performance, making them suitable for various activities, including basketball, or for everyday casual wear. This manual provides essential information on how to properly set up, use, maintain, and troubleshoot your sneakers to ensure their longevity and your satisfaction.

Please read this manual thoroughly before first use and retain it for future reference.



Image 1.1: Reebok Unisex-Adult Press Sneakers, showcasing the Core Black/Neon Cherry/Core Black colorway.

2. SETUP

Your Reebok Press Sneakers are ready to wear right out of the box. Follow these steps for optimal initial setup:

1. **Unboxing:** Carefully remove the sneakers from their packaging. Inspect them for any visible damage or manufacturing defects.
2. **Lacing:** The shoes come pre-laced. Adjust the laces to achieve a snug yet comfortable fit. Ensure the tongue is centered and smooth against your foot.
3. **Initial Fit Check:** Wear both shoes and walk around to assess the fit. Your toes should have a small amount of space at the front, and your heel should feel secure without slipping excessively. The mesh upper is designed to be breathable and conform to your foot over time.



Image 2.1: Close-up of the Reebok Press Sneakers, illustrating the lace-up closure system.

3. OPERATING (WEARING) YOUR SNEAKERS

The Reebok Press Sneakers are versatile and designed for both athletic performance and casual comfort.

- **For Athletic Activities:** When engaging in sports like basketball, ensure your laces are tied securely to provide maximum ankle and foot support. The rubber sole offers superior traction for quick movements and stability.
- **For Casual Wear:** For everyday use, you may adjust the laces for a slightly looser fit, prioritizing comfort. The lightweight and breathable mesh upper makes these shoes comfortable for extended periods.
- **Proper Footwear:** Always wear appropriate socks to enhance comfort, manage moisture, and prevent friction.

4. MAINTENANCE

Proper care will extend the life and appearance of your Reebok Press Sneakers.

- **Cleaning the Mesh Upper:**
 - Gently brush off loose dirt with a soft brush.
 - Mix a small amount of mild soap with cool water.

- Using a soft cloth or sponge, gently wipe the mesh material. Avoid saturating the shoe.
- Wipe off soap residue with a clean, damp cloth.
- **Cleaning the Rubber Sole:**
 - Use a brush (an old toothbrush works well) and soapy water to scrub away dirt and grime from the rubber sole.
 - Rinse with a damp cloth.
- **Drying:** Allow shoes to air dry at room temperature. Do not use direct heat sources like radiators or hair dryers, as this can damage the materials. Stuffing the shoes with paper towels can help absorb moisture and maintain shape.
- **Storage:** Store your sneakers in a cool, dry place away from direct sunlight.
- **Do Not Machine Wash:** Machine washing can damage the shoe's structure and materials.

5. TROUBLESHOOTING

If you encounter any issues with your Reebok Press Sneakers, consider the following common solutions:

- **Uncomfortable Fit:**
 - Ensure laces are adjusted correctly. Too tight or too loose lacing can cause discomfort.
 - Verify you are wearing the correct size. Refer to the size guide if available or consult a Reebok retailer.
 - Allow for a break-in period. New shoes may feel stiff initially.
- **Slipping on Surfaces:**
 - Clean the rubber soles thoroughly. Dirt and debris can reduce traction.
 - Inspect the sole for excessive wear. If the tread is worn smooth, the shoes may need replacement for safety.
- **Odor:**
 - Ensure shoes are fully air-dried after each use.
 - Use odor-absorbing inserts or sprays designed for footwear.
 - Regularly wash your socks.

6. SPECIFICATIONS

Feature	Detail
Brand	Reebok
Model Name	Press
Department	Unisex-Adult
Item Type Name	Sneaker
Outer Material	Mesh
Sole Material	Rubber

Insole Material	Rubber
Closure Type	Lace-Up
Sport Type	Basketball
Shoe Type	Athletic Shoe
Shoe Height Map	Low Top
Heel Type	No Heel
Toe Style	Closed Toe
Water Resistance Level	Not Water Resistant
Item Weight	1 Pound
UPC	198806256100
ASIN (Parent)	B0DP3P4QHR
Date First Available	November 26, 2024

7. WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the specific terms and conditions provided at the time of purchase or visit the official Reebok website. General return policies may apply through your retailer.

If you require further assistance or have questions not covered in this manual, please contact Reebok customer support through their official website or the retailer from whom you purchased the product.

You can visit the official Reebok store for more information:[Reebok Store on Amazon](#)