

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [LIJIANI](#) /

> [LIJIANI SH-01 Pocket AM/FM Radio User Manual](#)

LIJIANI SH-01

LIJIANI SH-01 Pocket AM/FM Radio User Manual

Model: SH-01

[Safety Information](#)

[Product Components](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

1. SAFETY INFORMATION

Please read all safety instructions carefully before using the LIJIANI SH-01 Pocket AM/FM Radio. Keep this manual for future reference.

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the radio to strong impacts.
- Do not attempt to disassemble or modify the radio. This will void the warranty and may cause damage.
- Keep batteries away from children. If swallowed, seek immediate medical attention.
- Dispose of used batteries according to local regulations.
- Use only AAA batteries as specified.

2. PRODUCT COMPONENTS

The LIJIANI SH-01 Pocket AM/FM Radio package includes the following items:

- LIJIANI SH-01 Pocket AM/FM Radio Unit
- Stereo Earphones (3.5mm jack)
- User Manual (this document)



Image 2.1: Front view of the LIJIANI SH-01 Pocket AM/FM Radio with connected earphones. The radio features a large LCD screen displaying time and frequency, along with control buttons for volume, band selection, scanning, and alarm functions.

3. SETUP

3.1. Battery Installation

1. Locate the battery compartment cover on the back of the radio.
2. Slide the cover open in the direction indicated by the arrow.
3. Insert two (2) AAA batteries, ensuring correct polarity (+/-) as marked inside the compartment.
4. Close the battery compartment cover securely.

2XAAA battery powered



Image 3.1: Rear view of the LIJIANI SH-01 radio showing the open battery compartment. Two AAA batteries are inserted, demonstrating the correct orientation for power.

Note: Batteries are not included and must be purchased separately. For optimal performance, use high-quality alkaline AAA batteries.

3.2. Connecting Earphones

The included earphones serve as both the audio output and the FM antenna. For best FM reception, ensure the earphone cable is fully extended.

1. Insert the 3.5mm jack of the earphones into the earphone port located on the top of the radio.

More practical functions to meet daily needs




Image 3.2: The LIJIANI SH-01 radio with earphones plugged into the top jack. This image highlights the compact size of the radio and its portability.

4. OPERATION

4.1. Power On/Off

- To power on, press and hold the **POWER** button (usually located on the side or top).
- To power off, press and hold the **POWER** button again.

4.2. Adjusting Volume

- Press the **VOL+** button to increase the volume.
- Press the **VOL-** button to decrease the volume.

4.3. Selecting Radio Band (AM/FM)

- Press the **BAND/PRE** button to switch between AM and FM bands. The current band will be displayed on the LCD screen.

4.4. Tuning Stations

4.4.1. Automatic Scan

- Press and hold the **SCAN/SLEEP** button to automatically scan for available stations and

save them as presets.

4.4.2. Manual Tuning

- Press the **UP** or **DOWN** buttons to manually tune the frequency step by step.
- Press and hold **UP** or **DOWN** to quickly scan to the next strong station.

4.5. Managing Presets

4.5.1. Saving a Preset

1. Tune to the desired station.
2. Press and hold the **M+** or **M-** button until the preset number flashes, then release.
3. Use the **UP** or **DOWN** buttons to select the desired preset number.
4. Press **M+** or **M-** again to confirm and save the station.

4.5.2. Recalling a Preset

- Press the **M+** or **M-** button to cycle through saved preset stations.

4.5.3. Deleting a Preset

1. Recall the preset you wish to delete.
2. Press the **DEL/TIME** button. The preset will be removed.

4.6. Setting Time and Alarm

4.6.1. Setting Time

1. With the radio off, press and hold the **DEL/TIME** button until the hour digits flash.
2. Use the **UP** or **DOWN** buttons to adjust the hour.
3. Press **DEL/TIME** again to switch to minute adjustment.
4. Use the **UP** or **DOWN** buttons to adjust the minutes.
5. Press **DEL/TIME** to confirm and exit time setting.

4.6.2. Setting Alarm

1. With the radio off, press and hold the **ALARM** button until the alarm hour digits flash.
2. Use the **UP** or **DOWN** buttons to adjust the alarm hour.
3. Press **ALARM** again to switch to alarm minute adjustment.
4. Use the **UP** or **DOWN** buttons to adjust the alarm minutes.
5. Press **ALARM** to confirm and activate the alarm. An alarm icon will appear on the display.
6. To deactivate the alarm, press the **ALARM** button once when the radio is off. The alarm icon will disappear.

Alarm clock function

At the set alarm time, the buzzer will emit a "ticking" sound.



Image 4.1: The LIJIANI SH-01 radio on a bedside table, with the display showing the time and an alarm icon. This illustrates the alarm clock functionality.

4.7. Sleep Timer Function

The sleep timer allows the radio to automatically turn off after a set period.

1. While the radio is on, repeatedly press the **SCAN/SLEEP** button to cycle through available sleep timer options (e.g., 10, 15, 30, 45, 60, 90 minutes).
2. The selected time will be displayed, and the radio will turn off automatically after the countdown.
3. To cancel the sleep timer, press **SCAN/SLEEP** until "OFF" or no timer icon is displayed.



Image 4.2: The LIJIANI SH-01 radio on a bedside table, illustrating the sleep countdown shutdown feature with options for 10, 15, 30, 45, 60, and 90 minutes.

4.8. Lock Screen Function

The lock screen function prevents accidental button presses.

- To activate the lock, slide the **LOCK** switch (usually on the side of the radio) to the locked position. A key icon will appear on the display.
- To deactivate, slide the **LOCK** switch back to the unlocked position. The key icon will disappear.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the radio's exterior. Do not use abrasive cleaners, solvents, or harsh chemicals.
- **Battery Care:** If the radio will not be used for an extended period, remove the batteries to prevent leakage and damage.
- **Storage:** Store the radio in a cool, dry place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Radio does not power on.	<ul style="list-style-type: none"> ◦ Batteries are dead or incorrectly inserted. ◦ Power button not pressed correctly. 	<ul style="list-style-type: none"> ◦ Replace batteries with new AAA batteries, ensuring correct polarity. ◦ Press and hold the POWER button firmly.
Poor reception or static.	<ul style="list-style-type: none"> ◦ Earphones not fully extended (FM). ◦ Weak signal in current location. ◦ Interference from other electronic devices. 	<ul style="list-style-type: none"> ◦ Ensure earphone cable is fully extended and positioned for best reception. ◦ Move to a different location, preferably outdoors or near a window. ◦ Move the radio away from other electronics.

Problem	Possible Cause	Solution
No sound from earphones.	<ul style="list-style-type: none"> Volume is too low or muted. Earphones not properly connected. Faulty earphones. 	<ul style="list-style-type: none"> Increase volume using VOL+ button. Ensure earphones are fully plugged into the jack. Try a different pair of 3.5mm earphones to check if the issue is with the radio or the earphones.
Buttons are unresponsive.	<ul style="list-style-type: none"> Lock function is activated. Low battery power. 	<ul style="list-style-type: none"> Deactivate the lock function by sliding the LOCK switch. Replace batteries.

7. SPECIFICATIONS

Feature	Detail
Model Number	SH-01
Brand	LIJIANI
Tuner Technology	FM, AM
Power Source	2 x AAA Batteries (not included)
Battery Life (Approx.)	10-12 hours (continuous use)
Display	1.8-inch LCD with backlight
Connectivity	3.5mm Earphone Jack (Auxiliary)
Product Dimensions	2.3"L x 3.2"W x 1"H (approx. 58.4 x 81.3 x 25.4 mm)
Item Weight	3.87 ounces (approx. 110 grams)
Special Features	Digital Tuning, Stereo Earphone Output, Alarm Clock, Sleep Timer, Lock Screen Function

Compact and portable



Image 7.1: A visual comparison of the LIJIANI SH-01 radio's dimensions against a standard credit card, highlighting its compact and mini portable design.

8. WARRANTY AND SUPPORT

LIJIANI products are designed for reliability and performance. For warranty information and customer support, please refer to the contact details provided with your purchase or visit the official LIJIANI website.

Please retain your proof of purchase for any warranty claims.

© 2025 LIJIANI. All rights reserved.

 <p>MAPTUNER X YAMAHA Quick Start Guide</p> <p>READ ALL PAGES BEFORE STARTING TO TUNE!</p> <p>WARNING: This device will control the engine's throttle. Improper use may result in injury or death. Read the manual carefully before using this device. For more information, please refer to the manual.</p> <p>YAMAHA 44-999A-0000-0000-0000-0000</p>	<p>RIVA Maptuner X Quick Start Guide</p> <p>Comprehensive guide to installing and using the RIVA Maptuner X for performance tuning of Yamaha watercraft, ATVs, and UTVs, covering hardware setup, software installation, programming tunes, and service functions.</p>
 <p>AQUOS</p>	<p>AQUOS</p> <p>AQUOS</p>
<p>Magnetic Stirrer</p> <p>Operation instruction</p>	<p>VEVOR Magnetic Stirrer Operation Instructions</p> <p>Official operation instructions for VEVOR Magnetic Stirrers. This guide details product specifications, operating procedures for models with and without displays, safety precautions, and packing lists for laboratory and scientific applications.</p>
 <p>Ultrasound Cleaners</p> <p>User Manual</p> <p>SH Series</p>	<p>SharperTek SH-Series Ultrasonic Cleaners User Manual - NDT Supply</p> <p>Comprehensive user manual for SharperTek SH-Series ultrasonic cleaners, covering operation, specifications, safety precautions, troubleshooting, and maintenance. Provided by NDT Supply.com.</p>
 <p>SH-TENT-GRAY-HS03</p> <p>ROOFTOP TENT</p> <p>USER MANUAL</p> <p>SH-TENT-GRAY-HS03 / SH-TENT-QD-004 / SH-TENT-QD-008</p>	<p>SH-TENT-GRAY-HS03 User Manual: Setup, Care, and Specifications</p> <p>Comprehensive user manual for the SH-TENT-GRAY-HS03 tent, covering setup instructions, care and maintenance tips, safety guidelines, and product specifications. Includes models SH-TENT-QD-004 and SH-TENT-QD-008.</p>
 <p>Lock Instructions</p> <p>Setting the Passcode for Combination Padlock</p> <p>Rear Lock Access</p>	<p>Shintaro Lock Instructions: Setting Passcode & Rear-Lock Access for SH-MDUC-C16S/C32S</p> <p>Step-by-step instructions for setting the combination passcode and using the rear-lock access for Shintaro SH-MDUC-C16S and SH-MDUC-C32S charging stations.</p>