

[Manuals.plus](#) /

› [RALGEND](#) /

› RALGEND Farmhouse End Table with Charging Station and LED Light, Model 9901BZUDWH Instruction Manual

RALGEND 9901BZUDWH

RALGEND Farmhouse End Table with Charging Station and LED Light

MODEL: 9901BZUDWH

Important Safety Information

For your safety and to prevent damage to the product, please read and adhere to the following guidelines:

- Always assemble and secure the table to a wall using the provided anti-tip device. This prevents accidental tipping, especially in households with children or pets.
- Do not place heavy items on the table that could cause it to tip over or exceed its weight capacity. The tabletop supports up to 110 lb, and each drawer supports up to 22 lb.
- Always follow the instructions provided in the assembly manual for safe and correct use.
- Ensure all electrical connections for the charging station and LED light are properly secured and not overloaded.

Product Overview

The RALGEND Farmhouse End Table is designed to provide functional storage and convenient charging capabilities with integrated LED lighting. Its robust construction and thoughtful design make it suitable for various living spaces.



Image: The RALGEND Farmhouse End Table in a living room setting, showcasing its design and illuminated LED compartment.

Key Features:

- **Large-Capacity Storage:** Features two spacious drawers and three open compartments for organizing various items.
- **Convenient Charging Station:** Includes a built-in power strip with 2 standard AC outlets and 2 USB ports.
- **Smart RGB LED Strip:** Adjustable LED lighting with multiple modes, colors, music sync, and timer functions, controllable via remote or mobile app.
- **Elegant Farmhouse Style:** Designed with a square structure, beveled base, metal corners, wire mesh drawers, and diamond handles.
- **Sturdy Construction:** Crafted from premium particleboard and MDF for durability, with non-slip foot pads for stability.

PRODUCT SIZE



Image: Diagram illustrating the dimensions of the end table (23.6" W x 23.6" D x 24" H) and weight capacities for the tabletop (110 lb) and drawers (22 lb).

Built-in Power Strip

2 AC standard outlets and 2 USB ports make it easy to charge various electronic devices at once.




Image: An overhead view of the end table with various items like books, headphones, and a phone placed in its storage compartments, highlighting its space-saving design.

Specifications

Feature	Detail
Brand	RALGEND
Model Number	9901BZUDWH
Product Dimensions	23.6"D x 23.6"W x 24"H
Item Weight	52.4 Pounds
Material Type	Engineered Wood
Number of Drawers	2
Tabletop Load Capacity	110 lb
Drawer Load Capacity	22 lb (each)
Charging Station	2 AC Outlets (120V 12A), 2 USB Ports (5V 2A)
Power Cord Length	4.9-Foot
LED Light	RGB, Multiple Modes, Music Sync, Timer Function
Control Method	Remote Control, Mobile App
Style	Farmhouse
Included Components	1 x Charging Station, 1 x End Table, Assembly Guide, Installation Tool
Tools Recommended For Assembly	Screw Driver

Setup and Assembly

The RALGEND Farmhouse End Table requires assembly. Please follow the detailed instructions provided in the included Assembly Guide. A screwdriver is the primary tool recommended for assembly.

- Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list in the Assembly Guide.
- Assemble Structure:** Follow the step-by-step diagrams in the Assembly Guide to construct the table frame, drawers, and shelves.
- Install Charging Station:** Integrate the charging station into the designated slot on the tabletop as per instructions.
- Attach LED Strip:** Secure the LED strip in the specified location within the open compartment.
- Install Anti-Tip Device:** For safety, it is crucial to install the anti-tip device and secure the table to a wall. Refer to the Assembly Guide for proper installation.
- Final Checks:** Ensure all screws are tightened and the table is stable before use.

Versatile Spacious Side Table

Store items, keep your space in order and showcase the aesthetics of life.



Bedside Table



Sofa Table



Coffee Table



Image: A detailed view of the built-in power strip, showing two AC outlets and two USB ports, with a device charging.

Operating Instructions

Charging Station:

- Plug the table's power cord into a standard wall outlet.
- Use the 2 AC outlets (120V 12A) to power devices such as lamps or laptops.
- Use the 2 USB ports (5V 2A) to charge smartphones, tablets, and other USB-powered devices.
- The 4.9-foot power cord provides flexibility for placement.

LED Light Strip:

The integrated RGB LED light strip offers customizable illumination for your space.

- **Power On/Off:** Use the provided remote control or the mobile app to turn the LED light on or off.
- **Color Selection:** Choose from a wide range of colors to match your mood or decor.
- **Lighting Modes:** Select from various dynamic lighting modes.
- **Brightness Adjustment:** Adjust the intensity of the light to your preference.
- **Music Sync:** Activate music sync mode for the lights to react to audio.
- **Timer Function:** Set a timer for the lights to automatically turn off.



Image: The RALGEND End Table with its LED light illuminated, accompanied by icons representing app control, remote control, over 6000 colors, adjustable brightness, timer function, and music mode.

Maintenance

Proper care will ensure the longevity and appearance of your RALGEND Farmhouse End Table.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Clean spills immediately to prevent staining, especially on the engineered wood surfaces.
- **Dusting:** Regularly dust the table with a dry, soft cloth.
- **Electrical Components:** Ensure the charging station and LED light strip remain dry. Do not immerse in water or expose to excessive moisture.
- **Hardware:** Periodically check and tighten any loose screws or hardware to maintain stability.

Troubleshooting

If you encounter any issues with your RALGEND Farmhouse End Table, consider the following common solutions:

- **Charging Station Not Working:**

- Ensure the table's main power cord is securely plugged into a functional wall outlet.
- Check if the devices you are trying to charge are properly connected to the AC outlets or USB ports.
- Verify that the wall outlet itself is receiving power.

- **LED Light Not Illuminating:**

- Confirm the table's power cord is connected.
- Check the remote control battery and ensure it is pointed directly at the receiver.
- If using the app, ensure your device is properly paired and within range.
- Inspect the LED strip connection to the power source.

- **Table Instability:**

- Ensure all assembly screws are fully tightened.
- Verify that the table is placed on a flat, level surface.
- Confirm the anti-tip device is correctly installed and secured to the wall.

For issues not resolved by these steps, please contact customer support.

Warranty Information

This RALGEND Farmhouse End Table comes with a **Limited Warranty**. For specific details regarding coverage, duration, and terms, please refer to the warranty documentation included with your purchase or contact RALGEND customer support.

Customer Support

If you require further assistance, have questions about assembly, operation, or warranty, please contact RALGEND customer support. Our team is available to help you.

Please have your model number (9901BZUDWH) and purchase information ready when contacting support.

For the most up-to-date contact information, please visit the official RALGEND brand store or refer to your purchase documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question