

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [OHAYO](#) /

› [OHAYO S6 40W Wireless Portable Bluetooth Speaker User Manual](#)

## OHAYO S6

# OHAYO S6 40W Wireless Portable Bluetooth Speaker User Manual

Model: S6

## INTRODUCTION

Thank you for choosing the OHAYO S6 40W Wireless Portable Bluetooth Speaker. This speaker is designed to deliver powerful, clear stereo sound with dynamic RGB lighting, making it ideal for various environments including home, parties, travel, and outdoor activities. Its IPX7 waterproof rating ensures durability against water exposure, and the long-lasting battery provides extended playtime. Please read this manual carefully to ensure proper use and optimal performance of your device.

## WHAT'S IN THE BOX

- OHAYO S6 Portable Bluetooth Speaker
- USB-C Charging Cable
- AUX Audio Cable
- Quick Start Guide (Instruction Manual)

# 40W Hi-Res Sound

Clear Highs and Deep Lows for a Powerful Audio Experience



Image: The OHAYO S6 speaker shown alongside its included USB-C charging cable and AUX audio cable.

## PRODUCT OVERVIEW

The OHAYO S6 speaker features a durable, black mesh exterior with a convenient carrying strap. The top panel houses intuitive controls, while the rear panel provides access to various input ports.

### Controls

- **Power Button ( )**: Press and hold to power on/off.
- **Mode Button (M)**: Short press to switch between Bluetooth, AUX, and TF Card modes.
- **Volume Down (-) / Previous Track**: Short press for volume down; long press for previous track.
- **Play/Pause Button (▶)**: Short press to play/pause; answer/end calls.
- **Volume Up (+) / Next Track**: Short press for volume up; long press for next track.
- **TWS Pairing Button (∞)**: Press to initiate True Wireless Stereo pairing.
- **Bass Boost Button (BASS)**: Press to activate/deactivate enhanced bass.

**6600 mAh,  
UP TO 15H,  
Enjoy non-stop music**

At 50% volume, enjoy up to 15 hours of continuous playtime.

**15H**



Image: A close-up of the OHAYO S6 speaker's top panel, highlighting the power, mode, volume, play/pause, TWS, and bass boost buttons.

## Ports

- **USB-C Charging Port:** For charging the speaker.
- **AUX-in Port:** For wired audio connection using the AUX cable.
- **TF Card Slot:** For playing music directly from a TF (MicroSD) card.



Image: The side of the OHAYO S6 speaker with the protective flap open, revealing the USB-C charging port, AUX-in port, and TF card slot.

## SETUP

---

### Charging the Speaker

1. Connect the provided USB-C charging cable to the speaker's USB-C port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status and turn off when fully charged.

### Bluetooth Pairing

1. Press and hold the Power button () to turn on the speaker. The LED indicator will flash, indicating it's in pairing mode.
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "OHAYO S6" from the list of devices. Once connected, the LED indicator will remain solid.

### True Wireless Stereo (TWS) Pairing

TWS allows you to connect two OHAYO S6 speakers for a more immersive stereo sound experience.

1. Ensure both OHAYO S6 speakers are powered off.
2. Power on the first speaker. This will be your primary speaker.
3. Press the TWS button (∞) on the primary speaker. It will enter TWS pairing mode.
4. Power on the second speaker. It will automatically search for and connect to the primary speaker.
5. Once successfully paired, the primary speaker's LED will indicate TWS connection.
6. Connect your mobile device to the primary speaker via Bluetooth as described in the "Bluetooth Pairing" section.




Image: Two OHAYO S6 speakers are shown wirelessly connected on an outdoor table, demonstrating the TWS pairing feature.

## OPERATING INSTRUCTIONS

### Basic Audio Playback

- **Play/Pause:** Press the Play/Pause button (▶).
- **Volume Adjustment:** Short press the Volume Up (+) or Volume Down (-) buttons.
- **Next/Previous Track:** Long press the Volume Up (+) for next track or Volume Down (-) for previous

track.

## Mode Selection

Press the Mode button (M) to cycle through available input sources: Bluetooth, AUX, and TF Card.

## Bass Boost

Press the Bass Boost button (BASS) to enhance the low-frequency audio output for a deeper bass experience. Press again to deactivate.

## Hands-Free Calling

When connected via Bluetooth, the built-in microphone allows for hands-free calls. Press the Play/Pause button (▶) to answer or end a call.

## Dynamic LED Lighting

The speaker features dynamic RGB LED lights that add a visual element to your music. The lighting patterns are pre-programmed and activate automatically.

## MAINTENANCE

---

### Waterproof Care (IPX7)

The OHAYO S6 speaker has an IPX7 waterproof rating, meaning it can be submerged in water up to 1 meter for 30 minutes. To maintain its waterproof integrity:

- Ensure the rubber flap covering the charging and AUX ports is securely closed before exposing the speaker to water.
- After exposure to saltwater or chlorinated water, rinse the speaker with fresh water and allow it to air dry completely before charging or using the ports.

### Cleaning

Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.

### Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

---

| Problem                    | Possible Cause   | Solution  |
|----------------------------|--|---|
| Speaker does not power on. | Low battery.   | Charge the speaker using the provided USB-C cable.  |
| No sound or low volume.    | Volume too low on speaker or connected device; incorrect input mode; device not connected. | Increase volume on both speaker and device. Press 'M' to select correct input mode. Re-pair Bluetooth device. |

| Problem                    | Possible Cause  | Solution   |
|----------------------------|---|--|
| Cannot pair via Bluetooth. | Speaker not in pairing mode; Bluetooth disabled on device; too many devices connected.        | Ensure speaker is on and LED is flashing. Enable Bluetooth on your device. Disconnect other Bluetooth devices.                 |
| Poor sound quality.        | Distance from device too far; obstacles between speaker and device; low quality audio source. | Move device closer to speaker. Remove obstacles. Try a different audio source.   |
| TWS pairing fails.         | Incorrect pairing procedure; speakers too far apart.  | Ensure both speakers are OHAYO S6 and follow TWS pairing steps carefully. Keep speakers within close proximity during pairing. |

## SPECIFICATIONS

- **Model Name:** S6-Black
- **Speaker Maximum Output Power:** 40 Watts
- **Battery Capacity:** 6600 mAh
- **Playtime:** Up to 15 hours (at 50% volume)
- **Waterproof Rating:** IPX7
- **Connectivity Technology:** Bluetooth, AUX, TF Card, USB
- **Wireless Communication Technology:** Bluetooth
- **Audio Output Mode:** Stereo
- **Product Dimensions:** 8.67"D x 3.7"W x 2.83"H
- **Item Weight:** 1.63 pounds (0.74 Kilograms)
- **Frequency Response:** 2000 KHz (Note: This value is as provided in product specifications. Typical frequency response ranges are broader.)
- **Control Method:** Touch
- **Compatible Devices:** Gaming Console, Laptop, MP3 Player, Smartphone, Tablet, Television

# Fully Waterproof Design

resistant to rain, spills, and extreme outdoor conditions, allowing your music to flow uninterrupted!



Image: An exploded view of the OHAYO S6 speaker, illustrating its internal 40W Hi-Res Sound drivers for clear highs and deep lows.

## LED-Illuminated Button Indicator

The translucent button design features built-in LED indicators, providing clear visibility and intuitive control, even in low-light environments.



Image: A graphic depicting the OHAYO S6 speaker with a clock icon, indicating its long battery life of up to 15 hours.

## WARRANTY & SUPPORT

### Warranty Information

This product comes with a Limited Warranty. Please refer to the warranty card included in your packaging for

specific terms and conditions.

## Customer Support

For any inquiries, technical assistance, or support regarding your OHAYO S6 speaker, please contact our customer support team. We offer 24-hour customer support and facilitate easy, hassle-free returns and replacements. Support for an extended term of service is also available.

## Related Documents - S6

|   |  |
|---|--|
|    | <p><a href="#"><b>OHAYO X3 Bluetooth Speaker Quick Start Guide</b></a></p> <p>Comprehensive quick start guide for the OHAYO X3 Bluetooth speaker, covering setup, TWS pairing, controls, charging, and technical specifications.</p>   |
|   | <p><a href="#"><b>OHAYO A7 Quick Start Guide</b></a></p> <p>A concise quick start guide for the OHAYO A7 wireless earbuds, covering powering on/off, pairing, music mode, call mode, factory reset, charging, specifications, and troubleshooting.</p>   |
|  | <p><a href="#"><b>S6 Dash Cam User Manual</b></a></p> <p>User manual for the S6 Dash Cam, detailing product accessories, appearance, usage instructions, video viewing, wired remote controller operation, GPS module installation, troubleshooting, and important notes.</p>  |
|  | <p><a href="#"><b>Wellermoz WMOS-S6 Portable Waterproof Wireless Speaker User Manual</b></a></p> <p>Detailed instructions and specifications for the Wellermoz WMOS-S6 portable waterproof wireless speaker, covering setup, features, TWS pairing, AUX input, TF card playback, charging, and warranty information.</p> |