

## ProCase PC-08366028

# ProCase Keyboard Case for iPad Pro 11-inch (M5/M4) 2025/2024 Instruction Manual

Model: PC-08366028

## INTRODUCTION

Thank you for choosing the ProCase Keyboard Case for your iPad Pro 11-inch (M5/M4) 2025/2024. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device. Please read this manual thoroughly before use.

## PACKAGE CONTENTS

- 1 x ProCase Keyboard
- 1 x ProCase Keyboard Cover (integrated with case)
- 1 x USB-C Charging Cable (not explicitly mentioned but standard for keyboards)
- 1 x User Manual (this document)

## COMPATIBILITY

This keyboard case is specifically designed for the following iPad models:

- iPad Pro 11-inch (M5) 2025
- iPad Pro 11-inch (M4) 2024 (Models: A2836 / A2837 / A3006)

To verify your iPad model number, please check the back of your iPad. The model number typically starts with 'A' followed by four digits.

# Does this fit your iPad Model?

## Only Fits:

iPad Pro 11-inch (M5) 2025

iPad Pro 11-inch (M4) 2024 (Model: A2836 /A2837 /A3006)



**Please check your model number on the back**

Figure 1: Locating your iPad model number on the device's back.

## SETUP

### 1. Attaching the iPad to the Case

1. Gently align your iPad Pro 11-inch with the protective back shell of the case.
2. The magnetic design will securely attach the iPad to the case. Ensure all edges are properly seated.

# Innovative Protection Design

2 - in - 1 lightweight back shell and protective keyboard cover




Figure 2: Innovative 2-in-1 protection design with detachable back shell.

## 2. Charging the Keyboard

Before initial use, fully charge the keyboard. Connect the provided USB-C charging cable to the keyboard's charging port and a power source.

- A red indicator light will illuminate when the battery is low.
- The light will change or turn off when fully charged (specific behavior may vary by model).



Figure 3: Type C charging port location on the keyboard.



Figure 4: Low battery indicator light.

### 3. Bluetooth Pairing

1. Turn on the keyboard using the power switch (usually located on the side).
2. On your iPad, go to **Settings > Bluetooth**.
3. Ensure Bluetooth is turned **On**.
4. The keyboard should appear in the "Other Devices" list (e.g., "ProCase Keyboard"). Tap on it to connect.
5. If prompted, enter the pairing code displayed on your iPad using the keyboard and press **Enter**.
6. Once paired, the keyboard will show as "Connected" in your iPad's Bluetooth settings.

## OPERATING INSTRUCTIONS

### Viewing Angles and Modes

The case supports multiple viewing angles for various activities:

- **Typing Mode:** Position the iPad upright with the keyboard for comfortable typing.
- **Viewing Mode:** Adjust the iPad to a reclined angle for watching videos or presentations.
- **Browsing Mode:** Detach the iPad from the keyboard for tablet-only use, or fold the keyboard behind for a compact browsing experience.

# Flexi Ways



Figure 5: Flexible viewing and typing positions.



Figure 6: Demonstrating various typing and viewing angles.

## Keyboard Functions

The keyboard features a standard QWERTY layout with additional function keys for iPad control. Refer to the keyboard layout for specific key functions.

## Touchpad Gestures

The integrated touchpad supports multiple gesture controls for enhanced navigation and productivity. Common gestures include:

- **Single Finger Tap:** Left-click.
- **Two-Finger Tap:** Right-click (context menu).
- **Two-Finger Scroll:** Scroll up/down or left/right.
- **Pinch to Zoom:** Use two fingers to zoom in or out.
- **Swipe with Three Fingers:** Navigate between open applications or access the App Switcher (specific gestures may vary based on iPadOS version).

## Multiple Gesture Control Touchpad



Figure 7: Touchpad with multiple gesture control capabilities.

## Auto Wake/Sleep Function

The case supports an auto wake/sleep feature. Opening the cover will wake your iPad, and closing it will put your iPad to sleep, conserving battery life.




Figure 8: Features including auto wake/sleep and pencil holder.

## Pencil Holder

The integrated pencil holder provides a secure location for your Apple Pencil, allowing for convenient storage and charging (if your iPad model supports magnetic charging through the case).

## MAINTENANCE

---

### Cleaning

- Wipe the exterior of the case with a soft, damp cloth.
- For the keyboard, use a dry, lint-free cloth. Avoid excessive moisture.
- Do not use harsh chemicals or abrasive cleaners.

### Storage

When not in use for extended periods, store the keyboard case in a cool, dry place. Ensure the keyboard is turned off to preserve battery life.

## TROUBLESHOOTING

---

- **Keyboard not connecting via Bluetooth:**

Ensure the keyboard is charged and turned on. Turn off and on your iPad's Bluetooth. Forget the device in iPad's Bluetooth settings and re-pair.

- **Keys not responding:**

Check if the keyboard is charged. Restart the keyboard and your iPad. Ensure the keyboard is properly paired.

- **Touchpad not working:**

Ensure the keyboard is charged and connected. Check iPadOS settings for touchpad functionality. Restart the keyboard and iPad.

- **iPad not waking/sleeping automatically:**

Ensure the iPad is correctly seated in the case and the cover is fully closing.

- **Case feels loose:**

Verify that your iPad model is compatible with this specific case. Ensure the iPad is properly aligned and magnetically attached to the back shell.

## SPECIFICATIONS

<b>Brand</b>	ProCase
<b>Model Number</b>	PC-08366028
<b>Compatible Devices</b>	iPad Pro 11 Inch (M4) 2024, iPad Pro 11 Inch (M5) 2025
<b>Connectivity Technology</b>	Bluetooth
<b>Special Features</b>	Trackpad, Magnetic Detachable Back Case, Multiple Viewing Angles, Pencil Holder, Auto Wake/Sleep
<b>Material</b>	Polycarbonate, Polyurethane (PU)
<b>Product Dimensions</b>	10.04 x 7.68 x 0.67 inches (25.5 x 19.5 x 1.7 cm)
<b>Item Weight</b>	1.83 pounds (0.83 kg)
<b>Included Components</b>	1 x Keyboard, 1 x Keyboard Cover

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official ProCase website or contact their customer service directly. Details are typically available on the product packaging or the manufacturer's official online resources.

Please retain your proof of purchase for any warranty claims.