

[Manuals.plus](#) /

> [URintells Cuising](#) /

> URintells Cuising CM6110-US Coffee Maker with Grinder Instruction Manual

URintells Cuising CM6110-US

URintells Cuising CM6110-US Coffee Maker with Grinder Instruction Manual

1. SETUP

Before first use, ensure all parts are clean and dry. This section guides you through the initial preparation of your URintells Cuising CM6110-US coffee maker.

1.1 Unpacking and Initial Cleaning

Carefully remove all packaging materials. Wash the glass carafe, filter, and water tank with warm, soapy water. Rinse thoroughly and dry all components before assembly.




Image: Initial cleaning of coffee maker components.

1.2 Water Tank Installation and Filling

The water tank is detachable for easy filling. Remove the water tank from the side of the unit. Fill it with fresh, cold water up to the desired level indicated by the cup markings. Ensure the water level does not exceed the 'MAX' line. Reinsert the water tank firmly into its position.



DETACHABLE WATER TANK WITH SCALE

Image: Detachable water tank with clear scale markings for water levels.

1.3 Grinder Assembly

Ensure the conical burr grinder is correctly installed in the bean hopper. The grinder knob allows adjustment of grind size from coarse to fine. For initial use, it is recommended to perform a rinse cycle without coffee to flush out any manufacturing residues.

Video: Instructions for initial setup and first use of the CM6110-US coffee maker.

2. OPERATING INSTRUCTIONS

Your URintells Cuisining coffee maker offers versatile brewing options. Follow these steps to brew your perfect cup.

2.1 Control Panel Overview

The large, intuitive control panel allows you to select brewing modes, coffee strength, temperature, and cup quantity. The digital display shows the current time and selected settings.



Image: Detailed view of the coffee maker's control panel.

2.2 Brewing Modes

Select your desired brewing mode using the 'MODE' button:

- **Bean Mode:** For brewing with whole coffee beans. The machine will grind the beans fresh before brewing.
- **Powder Mode:** For brewing with pre-ground coffee.
- **Grind Mode:** To only grind coffee beans without brewing.

2.3 Adjusting Strength, Temperature, and Quantity

Customize your coffee to your preference:

- **Aroma (Strength):** Choose from Mild, Medium, or Strong.
- **Temp (Temperature):** Select Ice, Normal, or High. The 'Ice' setting is designed for brewing directly over ice.
- **Cups (Quantity):** Select the number of cups from X1 (4.4 fl oz) to X5 (21.98 fl oz), or M1 (6.59 fl oz) and M2 (8.79 fl oz) for specific mug sizes.

22 FL OZ GLASS CARAFE

Less Waste, More Fresh Taste

= 5 
4.4 fl oz




Ideal for personal use, small to medium households

Image: The 5-cup glass carafe with clear measurement markings.

2.4 Programmable Brewing Timer

Set the timer to wake up to freshly brewed coffee. Press the 'TIME' button to enter the scheduling mode, adjust the hour and minute values, and then press 'DRIP' to start the countdown.



Programmable Brewing Timer

Set your desired time in advance, and wake up to freshly brewed coffee. Perfect for busy mornings or a hassle-free routine.

Image: The coffee maker displaying the programmable brewing timer.

2.5 Automatic Keep Warm Function

The built-in warming plate keeps your coffee at the perfect temperature for up to 30 minutes after brewing.



Image: The coffee maker with its automatic keep warm function activated.

2.6 No-Drip Pause & Serve

The machine features a pause and serve function, allowing you to pour a cup of coffee mid-brew without any drips or mess.




Image: Demonstrating the no-drip pause and serve feature.

3. MAINTENANCE

Regular cleaning and maintenance ensure optimal performance and longevity of your coffee maker.

3.1 Daily Cleaning

After each use, clean out the coffee grounds promptly. The removable filter and funnel can be rinsed under running water or placed in the dishwasher for easy cleaning.

Video: Instructions for daily cleaning of the CM6110-US coffee maker.

3.2 Grinder Cleaning

To clean the coffee grinder and ground coffee chute, ensure the bean hopper is empty. Use the provided brush to clean the bean hopper and grinder burr. The upper grinder burr can be removed for thorough cleaning. The machine also has a C3 cleaning mode for the grinder.




Image: Step-by-step guide for cleaning the coffee grinder and chute.

3.3 Descaling

Descaling is recommended every 2 months to prevent mineral buildup. Add descaling agent and water to the tank. Select the C2 descaling mode by pressing 'CLEAN' twice, then press 'DRIP' to start. Repeat the process with water only to remove any leftover descaling solution.



Image: Visual guide for the descaling process.

4. TROUBLESHOOTING

If you encounter issues with your coffee maker, refer to the following common problems and solutions.

4.1 Grinder Burr Reinstallation Issues

If the upper grinder burr is removed before coffee beans are completely ground, it may be difficult to reinstall. Ensure the grinder is empty, clean the burr, and then reinstall the grinder hopper knob, locking it tightly. The coffee machine is ready to work.

Video: Guide on how to reinstall the grinder burr if it becomes dislodged.

4.2 Water Pumping Issues

If the machine is not pumping water, check if the water tank is properly seated and filled. Ensure there are no obstructions in the water inlet or outlet. If the issue persists, contact customer support.

Video: Troubleshooting steps for when the coffee maker is not pumping water.

4.3 Coffee Spills During Brewing

To prevent occasional coffee spills, ensure the carafe is correctly positioned on the warming plate and the filter basket is properly inserted. Do not overfill the water tank beyond the maximum level.

Video: Tips to prevent coffee spills during the brewing process.

5. SPECIFICATIONS

| Feature | Detail |
|--------------------|---------------------------|
| Brand | URintells Cuising |
| Model Name | CM6110-US |
| Color | Black |
| Product Dimensions | 12.8"D x 6.69"W x 16.93"H |
| Item Weight | 12.72 pounds |
| Capacity | 1.4 Pounds (Coffee Beans) |
| Coffee Maker Type | Drip Coffee Machine |
| Operation Mode | Fully Automatic |

| | |
|-----------------------|---|
| Coffee Input Type | Ground, Instant, Whole Bean |
| Special Features | Adjustable Brew Strength, Auto Clean Function, Auto Shut-Off, Cup Warmer, Integrated Coffee Grinder |
| Included Components | Brush, Carafe, Filter, Grinder Conical Burr, Powder Funnel |
| Human Interface Input | Touchscreen |
| Power Source | AC adapter |
| Is Dishwasher Safe | No (for main unit) |

6. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the contact details provided in your product packaging or visit the official URintells Cuising website. Keep your purchase receipt for warranty claims.