Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Conyat H63

Conyat H63 Wireless Earbuds User Manual

Model: H63

1. Introduction

Thank you for choosing the Conyat H63 Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance and longevity. Please read this manual carefully before use and retain it for future reference.

2. Package Contents

Ensure all items are present in your package:

- Conyat H63 Wireless Earbuds (Left & Right)
- Charging Case
- USB Type-C Charging Cable
- Multiple Silicone Ear Tips (S/M/L)
- User Manual



Image: Contents of the Conyat H63 Wireless Earbuds package.

3. Product Overview

The Conyat H63 earbuds feature an ergonomic design for comfortable wear and advanced components for high-quality audio.



Image: Exploded view of an earbud, highlighting internal audio components.

Charging Case with LED Display

The charging case is equipped with an LED digital display to show the remaining battery percentage of the case and the charging status of each earbud.



Image: Charging case with LED power display.

4. Setup

4.1 Charging the Earbuds and Case

1. **Initial Charge:** Before first use, fully charge the earbuds and charging case. Connect the provided USB Type-C cable to the charging port on the case and a compatible USB power source.
2. **Charging Case:** The LED display on the case will show the battery percentage while charging. It will indicate 100% when fully charged.
3. **Charging Earbuds:** Place the earbuds into the charging case. The LED indicators on the earbuds (if present) or the case display will show their charging status. The case provides approximately 4 full charges for the earbuds.

4.2 Pairing with Your Device

The Conyat H63 earbuds utilize Bluetooth 5.4 for a stable and efficient connection.

1. **First-Time Pairing:**
    - Open the charging case. The earbuds will automatically power on and enter pairing mode.
    - On your device (smartphone, tablet, laptop), go to Bluetooth settings and ensure Bluetooth is enabled.
    - Search for available devices and select "**H63**" from the list.
    - Once connected, you will hear a confirmation prompt, and the earbuds will be ready for use.
2. **Automatic Re-connection:** After the initial pairing, the earbuds will automatically connect to the last paired device when you open the charging case, provided Bluetooth is enabled on your device.



Image: One-step pairing process for Conyat H63 earbuds.

5. Operating Instructions

5.1 Wearing the Earbuds

For optimal sound quality and comfort, choose the ear tips that best fit your ears. The earbuds are designed to fit securely

during various activities.



Image: Ergonomic design and ear tip selection for comfortable wear.

5.2 Touch Controls

The Conyat H63 earbuds feature smart touch controls on each earbud for easy management of music, calls, and voice assistant functions.

Action	Function
Double Tap (L/R)	Play/Pause Music
Tap and Hold 2S (Left Earbud)	Previous Track
Tap and Hold 2S (Right Earbud)	Next Track
Single Tap (Left Earbud)	Volume Down

Action	Function
Single Tap (Right Earbud)	Volume Up
Single Tap (L/R) during incoming call	Answer Call
Tap and Hold 2S (L/R) during incoming call	Reject Call
Tap and Hold 2S (L/R) during call	End Call
Triple Tap (L/R)	Activate Voice Assistant (Siri, Google Assistant, etc.)



Image: Detailed touch control functions.

5.3 Environmental Noise Cancellation (ENC)

The earbuds are equipped with ENC noise reduction microphones to minimize background noise during calls, ensuring clear communication.



Image: Illustration of ENC noise cancellation for calls.

6. Maintenance

6.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Ensure charging contacts on both earbuds and case are clean and free of debris to maintain proper charging.

6.2 Water Resistance (IPX7)

The earbuds have an IPX7 waterproof rating, meaning they can withstand immersion in water up to 1 meter for 30 minutes. This protects against sweat, light rain, and accidental splashes.

- Do not intentionally submerge the charging case. Only the earbuds are IPX7 rated.

- After exposure to water, ensure the earbuds are completely dry before placing them back into the charging case to prevent damage.



Image: IPX7 water resistance rating for the earbuds.

6.3 Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

7. Troubleshooting

If you encounter any issues, please refer to the following common solutions:

Problem	Possible Solution

Problem	Possible Solution
Earbuds not pairing	◦ Ensure earbuds are charged. ◦ Turn off and on Bluetooth on your device. ◦ Forget "H63" in your device's Bluetooth settings and re-pair. ◦ Place earbuds back in the case, close, then open again to reset pairing mode.
No sound from one earbud	◦ Ensure both earbuds are charged. ◦ Place both earbuds back in the case, close, then open again. ◦ Clean the charging contacts on both earbuds and in the case.
Earbuds not charging	◦ Ensure the charging cable is securely connected to both the case and power source. ◦ Check if the power source is working. ◦ Clean the charging contacts on the earbuds and inside the case.
Poor sound quality	◦ Ensure earbuds are clean and free of earwax. ◦ Try different sized ear tips for a better seal. ◦ Move closer to your paired device to avoid interference.

8. Specifications

Feature	Detail
Model Name	H63
Connectivity Technology	Wireless (Bluetooth 5.4)
Earbud Battery Life	Up to 8 hours (single charge)
Total Playtime (with Case)	Up to 40 hours
Water Resistance Rating	IPX7 (Earbuds only)
Control Type	Touch Control
Noise Control	Passive Noise Cancellation (ENC for calls)
Earbud Weight	Approximately 3.8g per earbud
Material	Plastic
Included Components	Earbuds, Charging Case, USB-C Cable, S/M/L Ear Tips, User Manual

9. Warranty and Support

Conyat products come with a standard manufacturer's warranty. For detailed warranty information, technical support, or

customer service inquiries, please refer to the contact information provided on the product packaging or visit the official Conyat website.
Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DP4GHKMR

More documents and user manuals: **https://manuals.plus/**