

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Grundig](#) /

› [Grundig Light Alarm Clock with FM Radio - User Manual](#)

Grundig Light Alarm Clock

Grundig Light Alarm Clock with FM Radio - User Manual

Model: Light Alarm Clock

INTRODUCTION

Thank you for choosing the Grundig Light Alarm Clock with FM Radio. This device is designed to provide a gentle and natural wake-up experience through simulated sunrise, soothing natural sounds, and an integrated FM radio. Please read this manual carefully to ensure proper use and to fully benefit from all its features.

SAFETY INFORMATION

- Do not expose the device to water or excessive moisture.
- Use only the specified power adapter (5V USB) to avoid damage.
- Keep the device away from direct sunlight and heat sources.
- Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel.
- Ensure the device is placed on a stable, flat surface.

PRODUCT OVERVIEW

The Grundig Light Alarm Clock features an intuitive design with a central digital display and easily accessible control buttons. The outer ring illuminates to simulate sunrise and provide ambient lighting.



This image displays the Grundig Light Alarm Clock. It features a circular design with a white casing and a glowing light ring around the central display. The digital display shows '07:25 AM' in red. Below the display are several control buttons with icons for time setting, alarm 1, snooze, light intensity, and alarm 2. The brand 'GRUNDIG' is printed at the bottom.

Control Buttons:

- **Clock Icon:** Time setting.
- **Bell 1 Icon:** Alarm 1 setting.
- **ZZz Icon:** Snooze function.
- **Light Bulb Icon (+/-):** Adjust light intensity and color.
- **Bell 2 Icon:** Alarm 2 setting.
- **Radio Icon:** FM Radio control.

SETUP

1. Power Connection

1. Connect the provided 5V USB power cable to the alarm clock.
2. Plug the other end of the USB cable into a compatible USB power adapter (not always included) and then into a wall outlet.
3. The digital display will light up, indicating the device is powered on.

2. Initial Time Setting

1. Press the **Clock Icon** button to enter time setting mode.
2. Use the +/- buttons (often associated with light intensity) to adjust the hour. Press the **Clock Icon** again to confirm the hour and move to minute setting.
3. Use the +/- buttons to adjust the minutes. Press the **Clock Icon** one more time to confirm and exit time setting.
4. The display may show AM/PM indicators for 12-hour format.

OPERATING INSTRUCTIONS

Setting Alarms (Alarm 1 and Alarm 2)

1. Press the **Bell 1 Icon** button to set Alarm 1. The alarm time will flash on the display.
2. Use the +/- buttons to adjust the desired alarm hour and then minutes. Press the **Bell 1 Icon** again to confirm each step.
3. After setting the time, you can select the alarm sound:
 - **Natural Sounds:** The clock offers 10 natural sounds (e.g., bird chirping, running water). Use the +/- buttons to cycle through these options.
 - **FM Radio:** Select the FM radio option to wake up to your favorite station. Ensure the radio is tuned to a station beforehand.
4. Press the **Bell 1 Icon** one last time to activate the alarm. A small bell icon will appear on the display.
5. Repeat the process using the **Bell 2 Icon** for Alarm 2, if desired.

Sunrise Simulation

- The sunrise simulation feature gradually increases the light intensity before your set alarm time, mimicking a natural dawn.
- This process typically starts 30 minutes before the alarm, with the light slowly brightening from a dim red to a bright white.
- The duration and intensity of the simulation may be adjustable via the settings menu (refer to specific button combinations in your detailed manual if available).

FM Radio Operation

1. Press the **Radio Icon** button to turn the FM radio on or off.
2. When the radio is on, use the +/- buttons to scan for and select radio stations. A long press may initiate an automatic scan.
3. Adjust the volume using dedicated volume buttons or the +/- buttons when in radio mode (if not used for tuning).

Color Changing LED and Light Intensity

- Press the **Light Bulb Icon** to turn the light on or off.
- When the light is on, use the **+/−** buttons to adjust its brightness.
- Repeatedly pressing the **Light Bulb Icon** may cycle through different light colors or modes (e.g., solid color, color-changing sequence).
- This feature can be used as a bedside lamp or for creating ambient mood lighting.

Snooze Function

- When an alarm sounds, press the **Zzz Icon** button to activate the snooze function.
- The alarm will pause for a set period (typically 5-9 minutes) and then sound again.
- You can usually repeat the snooze function multiple times.

Timer Function

- The timer function allows you to set the light or sound to turn off after a specified duration.
- Consult your specific product's detailed instructions for how to activate and set the timer, as this often involves a combination of button presses.

MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the alarm clock in a cool, dry place when not in use for extended periods.
- Ensure all vents (if any) are clear of dust and debris.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Power cable not connected properly or power source issue.	Check USB cable connection and try a different USB power adapter or outlet.
Alarm does not sound.	Alarm not activated or volume too low.	Ensure the alarm icon is displayed. Check alarm volume settings.
FM Radio static or poor reception.	Weak signal or interference.	Reposition the device. Extend any integrated antenna if available. Try scanning for stations again.
Light not working or changing colors.	Light function not activated or settings incorrect.	Press the Light Bulb Icon to activate. Cycle through light modes using the Light Bulb Icon.

SPECIFICATIONS

Feature	Detail
Brand	Grundig
Model	Light Alarm Clock
Display Type	Digital
Power Supply	5V USB
Alarm Tones	10 Natural Sounds + FM Radio
Light Options	Adjustable colors and brightness, Sunrise Simulation
Special Features	Snooze Function, Timer Function
Product Dimensions	17W x 10H Centimetres
Item Weight	445 Grams
Color	White

WARRANTY AND SUPPORT

This Grundig product is covered by a manufacturer's warranty. For detailed warranty information, please refer to the documentation included with your purchase or visit the official Grundig website. For technical support, troubleshooting assistance, or service inquiries, please contact Grundig customer service through their official channels.

For more information, you may visit the [Grundig Brand Page](#).

© 2025 Grundig. All rights reserved.

Related Documents - Light Alarm Clock

 <p>AUS GUTEN GRUND GRUNDIG CLOCK RADIO Sonoclock 590 Sonoclock 590 Q</p>	<p><u>Grundig Sonoclock 590 & 590 Q Clock Radio User Manual</u> Comprehensive user manual for the Grundig Sonoclock 590 and Sonoclock 590 Q clock radios, covering safety, setup, operation, alarm functions, sleep timer, and technical specifications.</p>
	<p><u>Grundig Sonoclock 3500 BT DAB+ Clock Radio User Manual</u> User manual for the Grundig Sonoclock 3500 BT DAB+ clock radio. Learn how to set up, operate DAB and FM radio, connect via Bluetooth, use alarm and timer functions, and understand safety and technical specifications.</p>
	<p><u>Grundig Sonoclock 3500 User Manual: DAB Radio, Bluetooth, and Alarm Clock Features</u> This user manual provides comprehensive instructions for the Grundig Sonoclock 3500 clock radio, covering setup, safety, DAB/FM radio tuning, Bluetooth connectivity, alarm functions, timer settings, and technical specifications. Learn how to operate your Grundig Sonoclock 3500 effectively.</p>
	<p><u>Grundig SCC 240 Clock Radio User Manual</u> User manual for the Grundig SCC 240 Clock Radio, detailing setup, safety, radio mode, Bluetooth mode, timer functions, and technical specifications.</p>
	<p><u>Grundig Sonoclock 3000 Clock Radio User Manual</u> User manual and safety instructions for the Grundig Sonoclock 3000 clock radio, covering setup, radio operation, timer functions, and charging capabilities. Includes technical specifications and compliance information.</p>
	<p><u>Grundig SCC 240 SCN 230 Sonoclock 2000 Sonoclock 2500 BT Clock Radio User Manual</u> Comprehensive user manual for Grundig SCC 240, SCN 230, Sonoclock 2000, and Sonoclock 2500 BT clock radios. Covers setup, safety precautions, power supply, operation, settings, alarm functions, sleep timer, and Bluetooth connectivity.</p>