

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Conyat](#) /

› [Conyat H63 Wireless Earbuds User Manual](#)

## Conyat H63

# Conyat H63 Wireless Earbuds User Manual

Model: H63

Brand: Conyat

## 1. INTRODUCTION

---

Thank you for choosing the Conyat H63 Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with advanced features such as Bluetooth 5.4 connectivity, immersive stereo bass, Environmental Noise Cancellation (ENC) for clear calls, and IPX7 waterproofing. This manual will guide you through the setup, operation, and maintenance of your new earbuds.



Image: Conyat H63 Wireless Earbuds in their navy blue charging case, displaying a 100% charge on the LED screen.

## 2. PACKAGE CONTENTS

Please check the package for the following items:

- Conyat H63 Wireless Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- Silicone Ear Tips (S, M, L sizes)
- User Manual



Image: Contents of the Conyat H63 package, showing the earbuds, charging case, USB-C cable, and user manual.

### 3. PRODUCT OVERVIEW

---

The Conyat H63 earbuds are designed for comfort and high-fidelity audio. Each earbud is lightweight and features touch controls. The charging case provides extended battery life and a digital display for power management.

# Hi-Fi Stereo & Deep Bass

Enjoy a surround sound experience that lets you feel every note like you're there



Image: Exploded view diagram of an earbud, illustrating its internal structure for Hi-Fi stereo and deep bass sound.




Image: Technical diagram showcasing the integrated Bluetooth 5.4 chipset for stable and efficient wireless communication.

## 4. SETUP

### 4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Use the provided Type-C charging cable to connect the case to a USB power source. The digital LED display on the case will show the current battery percentage. The earbuds will charge automatically when placed inside the case.

- A single full charge provides approximately 7 hours of listening time for the earbuds.
- The charging case provides up to 4 full charges for the earbuds, extending total playtime to over 40 hours.



Image: The charging case with its digital LED display indicating a full charge, representing the extended 40-hour battery life.

### 4.2 Pairing with Your Device

The earbuds feature automatic pairing for convenience.

#### 1. First-time Pairing:

- Open the charging case. The earbuds will automatically power on and enter pairing mode.
- On your device (smartphone, tablet, laptop), go to Bluetooth settings and enable Bluetooth.
- Search for available devices and select "H63" from the list.
- Once connected, you will hear a confirmation prompt, and the earbuds will be ready for use.

## 2. Subsequent Pairing:

- After the initial connection, the earbuds will automatically connect to the last paired device when you open the charging case.
- To disconnect, simply place the earbuds back into the charging case and close the lid.



Image: Visual guide for one-step pairing, demonstrating how opening the case initiates connection and closing it powers off, with a phone's Bluetooth menu displaying the "H63" device.

## 5. OPERATING INSTRUCTIONS

### 5.1 Wearing the Earbuds

The earbuds are designed with an ergonomic structure for a comfortable and stable fit. Choose the silicone ear tips that best fit your ear canals for optimal sound quality and comfort.

- Insert the earbud gently into your ear canal.
- Rotate it slightly to find a secure and comfortable position.
- Ensure a snug fit to maximize noise isolation and bass performance.

## Comfortable and Stable to Wear

Lightweight, only **3.8g**  
comfortable fit for any ear



Ergonomic design



Easy to carry



3 Different sizes ear tips



Image: A person demonstrating the comfortable and stable fit of the lightweight (3.8g) earbuds, along with a visual guide for selecting the correct ear tip size.

### 5.2 Touch Controls

The Conyat H63 earbuds feature smart touch controls on each earbud. The functions are as follows:

Action	Function
Tap 2 times (L/R)	Play/Pause Music
Press and hold for 2 seconds (L)	Previous Track

Action	Function
Press and hold for 2 seconds (R)	Next Track
Tap 1 time (L)	Volume Down
Tap 1 time (R)	Volume Up
Tap 1 time (L/R) during incoming call	Answer Call
Press and hold for 2 seconds (L/R) during incoming call	Reject Call
Tap 2 times (L/R) during a call	End Call
Tap 3 times (L/R)	Activate Voice Assistant (Siri, Google Assistant, etc.)



Image: A visual guide detailing the various touch control gestures and their corresponding functions on the earbuds.

### 5.3 Making and Receiving Calls

The earbuds are equipped with ENC noise-cancelling microphones to ensure clear communication.

- **Answering a Call:** Tap either earbud once.
- **Rejecting a Call:** Press and hold either earbud for 2 seconds.
- **Ending a Call:** Tap either earbud twice during an active call.




Image: Depiction of the Environmental Noise Cancellation (ENC) feature, showing how it reduces background noise for clearer audio during calls.

## 6. MAINTENANCE

### 6.1 Cleaning Your Earbuds

To maintain optimal performance and hygiene, regularly clean your earbuds and charging case.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- For ear tips, remove them from the earbuds and clean with a mild soap solution, then rinse thoroughly and dry completely before reattaching.
- Avoid using abrasive materials or harsh chemicals.

### 6.2 Water Resistance (IPX7)

The Conyat H63 earbuds are rated IPX7 waterproof, meaning they can withstand immersion in water up to 1 meter for 30 minutes. This makes them suitable for use during workouts, in light rain, or with accidental splashes.

- Do not intentionally submerge the charging case, as it is not waterproof.
- Ensure earbuds are dry before placing them back into the charging case to prevent damage.
- IPX7 rating does not mean they are suitable for swimming or showering.

# Water Resistant with IPX7 Rating



Light Rain



Accident Splashes



Sweat



Image: Visual representation of the IPX7 waterproof rating, showing the earbuds resisting water from light rain, splashes, and sweat.

## 7. TROUBLESHOOTING

If you encounter any issues with your Conyat H63 Wireless Earbuds, please refer to the following common solutions:

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Earbuds not pairing	<ul style="list-style-type: none"> <li>◦ Ensure earbuds are charged.</li> <li>◦ Place earbuds back in the case, close the lid, then open again to re-enter pairing mode.</li> <li>◦ Turn off and on Bluetooth on your device.</li> <li>◦ Forget "H63" from your device's Bluetooth list and re-pair.</li> </ul>
Only one earbud working	<ul style="list-style-type: none"> <li>◦ Ensure both earbuds are charged.</li> <li>◦ Place both earbuds back in the charging case, close the lid, and then open it again.</li> <li>◦ Try resetting the earbuds (refer to manufacturer's website for specific reset instructions if needed).</li> </ul>
Low volume or poor sound quality	<ul style="list-style-type: none"> <li>◦ Adjust the volume on both your device and the earbuds.</li> <li>◦ Ensure ear tips are properly sealed in your ear canal. Try different sizes.</li> <li>◦ Clean any debris from the earbud nozzles.</li> <li>◦ Ensure there are no obstructions between the earbuds and your device.</li> </ul>
Charging case not charging	<ul style="list-style-type: none"> <li>◦ Check the Type-C cable and power adapter.</li> <li>◦ Ensure the charging port is clean and free of debris.</li> <li>◦ Try a different charging cable or power source.</li> </ul>
Touch controls unresponsive	<ul style="list-style-type: none"> <li>◦ Ensure your fingers are clean and dry.</li> <li>◦ Restart the earbuds by placing them in the case and taking them out.</li> </ul>

## 8. SPECIFICATIONS

Detailed technical specifications for the Conyat H63 Wireless Earbuds:

Feature	Detail
Model Name	H63
Brand	Conyat
Connectivity Technology	Wireless (Bluetooth 5.4)
Wireless Communication Technology	Bluetooth
Compatible Devices	Cellphones, Desktops, Laptops, Tablets
Ear Placement	In Ear
Form Factor	In Ear
Noise Control	Environmental Noise Cancellation (ENC)
Water Resistance Level	IPX7 Waterproof

Feature	Detail
Control Method	Touch
Battery Average Life (Earbuds)	7 Hours (single charge)
Total Playtime (with Charging Case)	Over 40 Hours
Charging Interface	Type-C
Battery Cell Composition	Lithium Polymer
Item Weight	Approximately 3.8g per earbud

## 9. SAFETY INFORMATION

---

Please read and follow these safety guidelines to ensure safe and proper use of your earbuds:

- Do not disassemble or modify the product.
- Keep the earbuds and charging case away from extreme temperatures, direct sunlight, and open flames.
- Avoid exposing the charging case to water or moisture.
- Do not use the earbuds at excessively high volumes for prolonged periods to prevent hearing damage.
- Keep out of reach of children and pets.
- Dispose of the product and batteries responsibly according to local regulations.

## 10. WARRANTY AND SUPPORT

---

Conyat products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Conyat website.

For further assistance, you may contact customer support via the retailer where the product was purchased.