Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Treocho ST2403-RT4

Treocho 47-inch Fluted Console Table with 3 Drawers (Model ST2403-RT4) - User Manual

1. Introduction

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Treocho 47-inch Fluted Console Table. Designed for versatility and durability, this table features three fluted drawers and a two-tier shelving system, making it suitable for various spaces such as entryways, living rooms, or hallways. Please read these instructions carefully before assembly and use to ensure proper setup and longevity of your product.



Image 1: The Treocho 47-inch Fluted Console Table, showcasing its natural oak finish and elegant design in a home setting.

2. Safety Information

For your safety and to prevent damage to the product, please adhere to the following guidelines:

- Always follow the assembly instructions carefully.
- Use appropriate tools as specified in the assembly guide.
- Exercise caution when handling heavy components to avoid injury.
- Ensure the table is properly assembled and stable before placing any items on it or using it.
- Do not overload the drawers or shelves beyond their weight capacity.
- Keep small parts and packaging materials away from children to prevent choking hazards.

3. Package Contents

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged,

please contact customer support.

- Tabletop (1)
- Side Panels (2)
- Bottom Shelf (1)
- Drawer Units (3)
- Hardware Pack (screws, cam locks, dowels, etc.)
- Assembly Instructions Manual (1)

4. Assembly Instructions

Assembly of the Treocho Console Table is designed to be straightforward. Please follow the step-by-step instructions provided in the included manual. A screwdriver is recommended for assembly.
For a visual guide on the assembly process, please refer to the official product video below:

Your browser does not support the video tag.

Video 1: Official assembly guide for the Treocho Console Table, demonstrating the step-by-step process for setting up the unit. Note: The table shown in the video is a black variant, but the assembly steps are applicable to the natural oak model.

Key Assembly Steps:

1. Unpack all components and verify against the package contents list.
2. Attach the side panels to the tabletop using the provided hardware.
3. Secure the bottom shelf to the side panels.
4. Assemble the three fluted drawers and install them into the designated slots.
5. Ensure all connections are tight and the table is stable before use.



Image 2: Dimensional diagram of the console table, illustrating its overall measurements for planning placement.

5. Operating Instructions (Usage)

The Treocho Fluted Console Table is designed for versatile use and storage. Its elegant design complements various home styles.

- **Spacious Storage:** Utilize the three fluted drawers for organizing smaller items such as keys, mail, remote controls, or personal accessories.
- **Two-Tier Shelving:** The lower shelf provides additional space for books, decorative baskets, plants, or other display items.
- **Versatile Placement:** This console table is ideal for entryways, hallways, behind sofas, or as an accent piece in living rooms and foyers.
- **Display Surface:** The tabletop offers ample space for lamps, vases, picture frames, and other decorative elements to personalize your space.



Image 3: The console table with drawers open, demonstrating the internal storage capacity.



Image 4: A detailed view of the fluted drawer design, highlighting the texture and craftsmanship.

6. Maintenance

Proper care will help maintain the appearance and extend the life of your console table.

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Clean spills immediately with a dry cloth to prevent staining.
- **Protection:** Use coasters under drinks and placemats under hot items to protect the tabletop from heat and moisture damage.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood finish.

7. Troubleshooting

If you encounter any issues with your Treocho Console Table, refer to the following common solutions:

Problem	Possible Cause	Solution
Table is wobbly	Loose connections or uneven floor.	Check and tighten all screws. Ensure the table is on a level surface; use furniture pads if needed.
Drawers do not slide smoothly	Misaligned drawer slides or obstruction.	Verify that drawer slides are correctly installed and aligned. Check for any debris or objects obstructing the slides.
Surface scratches or marks	Impact from objects or abrasive cleaning.	For minor scratches, a wood repair kit or furniture marker matching the finish may be used. Avoid abrasive cleaning.

8. Specifications

Feature	Detail
Brand	Treocho
Model Number	ST2403-RT4
Product Dimensions (D x W x H)	11.81"D x 47.24"W x 31.49"H
Color	Natural Oak
Material Type	Engineered Wood (MDF)
Number of Drawers	3
Number of Shelves	1 (bottom shelf)
Item Weight	41.3 Pounds
Tools Recommended For Assembly	Screwdriver

9. Warranty and Support

For information regarding product warranty, returns, or technical support, please contact Treocho customer service directly. Keep your purchase receipt and model number (ST2403-RT4) handy for faster service.
Additional protection plans may be available for purchase through your retailer. Please refer to the specific terms and conditions of any extended warranty or protection plan you may have acquired.

© 2025 Treocho. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DP4SBW2Q

More documents and user manuals: **https://manuals.plus/**