

LIK CUT S501

LIK CUT Glee S501 Vinyl Cutter Machine User Manual

Model: S501

INTRODUCTION

This manual provides essential instructions for the safe and effective operation of your LIK CUT Glee S501 Vinyl Cutter Machine. Please read this manual thoroughly before using the device and retain it for future reference.

Important Safety Notice:

This machine and its accessories are intended for adult use ONLY. Use by children or individuals under supervision is strictly prohibited due to potential hazards.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 LIK CUT Glee S501 Cutting Machine
- 1 Power Adapter
- 1 USB-C Cable
- Vinyl Bundle (includes various materials for initial projects)
- 1 Cutting Mat
- 1 Hook Weeder Tool
- 1 Watercolor Pen (0.4mm)
- Transfer Tape



Image: Contents of the LIKCUT Glee S501 box, including the machine, power adapter, USB-C cable, vinyl, cutting mat, weeder tool, watercolor pen, and transfer tape.

PRODUCT OVERVIEW

The LIKCUT Glee S501 is a compact and portable smart cutting machine designed for various crafting projects. It features a precise cutting mechanism and a convenient storage compartment for tools.



Image: The LIKCUT Glee S501 Vinyl Cutter Machine in pink and white, shown with its accessories and a smartphone

displaying the design app.

Key Features:

- **Compact and Portable Design:** Easy to transport and store, ideal for small workspaces.
- **Versatile Material Compatibility:** Cuts over 46 materials, including vinyl, cardstock, and iron-on transfers.
- **Precision Cutting:** Ensures clean and accurate cuts for intricate designs.
- **Integrated Tool Storage:** A convenient compartment keeps weeding tools organized.
- **Drawing Functionality:** Can create designs, handwritten text, or illustrations using the included pen.



Image: Close-up view of the LIKUT Glee S501's integrated storage compartment, holding small crafting tools.

SETUP

1. **Unpack the Machine:** Carefully remove the LIKUT Glee S501 and all accessories from the packaging.
2. **Power Connection:** Connect the power adapter to the machine and plug it into a suitable power outlet.

3. **Software Installation:** Download and install the LIKCUT Design Store application on your mobile device, tablet, or PC. The application is required for operating the machine.
4. **Connectivity:** Establish a connection between your device and the LIKCUT Glee S501. The machine supports seamless connections via Bluetooth for mobile/tablet and USB for PC.

Two connection methods

Compatible with  Desktop  Mobile/Tablet



Image: Demonstrates the two connection methods for the LIKCUT Glee S501: via USB to a laptop and wirelessly to a smartphone/tablet.

OPERATING INSTRUCTIONS

1. Preparing Your Design:

- Open the LIKCUT Design Store application on your connected device.
- Select or create your desired design. The application offers a wide range of designs and tools for customization.
- Adjust the design size and settings according to your material and project requirements. The machine supports precision cutting for materials up to 4.5 inches in width.

Plenty of materials

NOTE: This cutting machine cannot print pictures.



Image: A visual representation of the LIKCUT Design Store application interface, showcasing numerous design options available for cutting.

2. Loading Material:

- Place your chosen material onto the cutting mat. Ensure it is securely adhered and aligned with the grid.
- Insert the cutting mat with the material into the machine's feed slot, following the directional arrows.

Bring Your Projects to Life




Image: Illustrates the process of loading material onto the cutting mat and into the LIKUT Glee S501, highlighting the maximum cutting dimensions of 4.5 inches by 6.5 inches.

3. Cutting or Drawing:

- If drawing, ensure the watercolor pen is correctly inserted into the tool carriage.
- From the LIKUT Design Store application, initiate the cutting or drawing process.
- The machine will automatically feed the material and execute the design.

Bring Your Art to Life

Creativity meets reality



Image: The LIKUT Glee S51 actively cutting a design on a green mat, surrounded by various finished paper crafts, demonstrating its use in creating art.

4. Finishing Your Project:

- Once the process is complete, carefully remove the cutting mat from the machine.
- Use the hook weeder tool to remove excess material and transfer your design to your desired surface.



Portable
Design



Stable
Connection



Easy
Crafting



Quick & Accurate
Cutting



Material
Versatility

This machine and its accessories are for adult use ONLY.

Image: A collage showing the LIKUCUT Glee S501 in use, with examples of finished projects like a decorated tote bag and a personalized mug, highlighting its versatility.

MAINTENANCE

Cleaning:

- Regularly clean the machine's exterior with a soft, dry cloth.
- Periodically inspect the cutting area for any debris or material scraps and remove them carefully.

Blade Care:

- Ensure the cutting blade is clean and free from adhesive residue.
- Replace the blade when you notice a decrease in cutting precision or quality. Refer to the LIKUCUT Design Store or official website for compatible replacement blades.

Storage:

- Store the machine in a clean, dry place away from direct sunlight and extreme temperatures.
- Utilize the integrated tool storage compartment to keep accessories organized and prevent loss.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---|--|---|
| Machine not powering on | Power cable not connected; power outlet issue. | Ensure power cable is securely connected. Try a different power outlet. |
| Difficulty connecting to device | Bluetooth/USB connection issue; app not running. | Restart the machine and your device. Ensure Bluetooth is enabled or USB cable is properly connected. Restart the LIKCUT Design Store app. |
| Poor cutting quality | Dull blade; incorrect material settings; material not properly adhered to mat. | Replace the blade. Verify material settings in the app. Ensure material is firmly pressed onto the cutting mat. |
| Machine not responding during operation | Software glitch; temporary communication error. | Close and reopen the LIKCUT Design Store app. Disconnect and reconnect the machine. |

SPECIFICATIONS

| Feature | Detail |
|---------------------------|---|
| Brand | LIKCUT |
| Model Number | S501-WPK-A1-EU (S501) |
| Color | Pink |
| Product Dimensions | 6.3 x 8.58 x 4.53 inches |
| Item Weight | 5.79 pounds (2.63 Kilograms) |
| Active Surface Area | 310.4 square centimeters (approx. 4.5 inches width for cutting) |
| Operation Mode | Automatic |
| Print Media Compatibility | Card stock, Vinyl, Iron-on transfers, Smart materials, and more (over 46 types) |
| Connectivity | Mobile, Tablet, PC (via Bluetooth or USB) |

WARRANTY AND SUPPORT

For warranty information, technical support, or to purchase replacement parts and accessories, please visit the official LIKCUT website or contact LIKCUT customer service. Details can typically be found on the product packaging or within the LIKCUT Design Store application.

Online Resources:

- [Visit the LIKCUT Store on Amazon](#)

- Check the LIKCUT Design Store application for tutorials and FAQs.