

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Monster](#) /

› [Monster Open Free AC100 Open Ear Bluetooth 5.3 Headphones User Manual](#)

Monster E18

Monster Open Free AC100 Open Ear Bluetooth 5.3 Headphones

USER MANUAL

Model: E18

Introduction

Thank you for choosing the Monster Open Free AC100 Open Ear Bluetooth 5.3 Headphones. These headphones are designed to provide an immersive stereo sound experience with the comfort of an open-ear design, allowing you to stay aware of your surroundings while enjoying high-quality audio. Featuring 16mm large drivers, AI noise-canceling for clear calls, and up to 30 hours of total playtime, the AC100 offers a seamless and comfortable listening experience.

MONSTER®
OPEN FREE **AC100**

Open-Ear Headphones

Secure Fit and All-day Comfort, Reduce Hearing Loss

- Powerful Bass Experience
- Secure Fit
- Situational Awareness
- Bluetooth 5.3

The Monster Open Free AC100 headphones offer secure fit, all-day comfort, and situational awareness.

What's in the Box

Please check the package contents to ensure all items are present:

- Open Ear Headphones x 2 (Left & Right)

- Charging Case x 1
- Type-C Charging Cable x 1
- Quick Guide x 1



All components included in the Monster Open Free AC100 package.

Product Overview

The Monster Open Free AC100 headphones are engineered for comfort, sound quality, and connectivity.

Comfort Open-Ear Design

Experience true pain-free listening. The open-ear design eliminates the need to insert earbuds into the ear canal, preventing soreness and discomfort even during extended use. This design also ensures a secure fit with ergonomic ear hooks and ultra-light construction.

Open-Ear Design for Ultimate Comfort



Ergonomic
ear hook

Secure Fit

Ultra light

The open-ear design provides ultimate comfort and a secure fit.


Immersive Stereo Sound

Dive into rich sonic detail with 16mm large drivers that deliver deep bass and crisp highs, bringing every nuance of your music to life with breathtaking clarity. Directional sound technology minimizes sound leakage.

Superb Sound Quality



16mm super large drivers




Powerful chip



Strong bass



Stereo sound



Detailed view of the 16mm large drivers for immersive stereo sound.

Crystal Clear Calls with AI Noise-Canceling

Equipped with built-in AI noise-canceling technology and dual microphones, these headphones monitor and reduce background noise, ensuring crystal-clear conversations even in noisy environments.

Crystal Clear Calls

Dual mics with AI call noise cancellation technology



Enjoy clear calls with AI noise-canceling technology.

Extended Playtime

Enjoy up to 6 hours of listening on a single charge, with a total of 30 hours of playtime using the charging case. This extended battery life ensures uninterrupted audio throughout your day.

Up to 30H Long Playtime



The headphones offer up to 30 hours of total playtime with the charging case.

Enhanced Awareness

The open-ear design allows you to stay connected to your surroundings. Whether commuting or exercising outdoors, ambient sounds blend seamlessly with your music, enhancing safety and awareness.

Safety and Awareness

Enjoy music and keep aware of your surrounding



Maintain awareness of your environment while enjoying audio.

Setup: Pairing Your Headphones

The Monster Open Free AC100 headphones feature advanced Bluetooth 5.3 technology for fast and stable connections. Follow these steps to pair your headphones:

1. Ensure the headphones are charged.
2. Open the charging case. The headphones will automatically power on and enter pairing mode.
3. On your device (smartphone, tablet, laptop), go to the Bluetooth settings.
4. Search for available devices and select "Monster Open Free AC100" from the list.
5. Once selected, the headphones will connect automatically. A voice prompt will confirm the connection.

The headphones will automatically pair with the last connected device when removed from the case, provided Bluetooth is enabled on the device.

One-Step Auto Pairing

Stable and faster connection



Simple one-step auto pairing for quick connection.

Operating Instructions

Wearing the Headphones

For optimal comfort and sound, ensure the headphones are worn correctly:

1. Confirm to take the earbuds as shown in the figure (ear hook facing up and forward).
2. From top to bottom, place the ear hook behind your ear.
3. Adjust the earbud for comfort and security, ensuring the speaker is positioned near your ear canal.
4. The fit should be snug but comfortable, allowing for situational awareness.




Follow these steps for easy and secure wearing.

Touch Controls

The Monster Open Free AC100 headphones feature intuitive touch controls on each earbud:

- **Play/Pause:** Tap 1x (R/L)
- **Answer/Hang up Call:** Tap 1x (R/L)
- **Reject Call:** Hold 2s (R/L)
- **Voice Assistant:** Hold 2s (R/L)
- **Previous Song:** Tap 3x (L)
- **Next Song:** Tap 3x (R)
- **Volume Down:** Tap 2x (L)
- **Volume Up:** Tap 2x (R)



Detailed guide to the easy tap controls on each earbud.

Maintenance

To ensure the longevity and optimal performance of your Monster Open Free AC100 headphones, please follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the headphones and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners, alcohol, or chemical solvents.
- **Water Resistance:** These headphones are *Not Water Resistant*. Avoid exposure to water, rain, sweat, or excessive moisture. Do not submerge them in any liquid.
- **Storage:** When not in use, store the headphones in their charging case to protect them from dust and damage. Store in a cool, dry place away from extreme temperatures.
- **Charging:** Use only the provided Type-C charging cable and a compatible power adapter. Avoid overcharging.

Troubleshooting

If you encounter issues with your Monster Open Free AC100 headphones, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Place headphones in the charging case and charge fully.
Cannot pair with device.	Bluetooth is off on device; headphones not in pairing mode; interference.	Ensure Bluetooth is enabled. Open case to enter pairing mode. Move closer to device, away from other wireless signals. Forget device and re-pair.
No sound or low volume.	Volume too low; headphones not connected; dirty speaker mesh.	Increase volume on both headphones and device. Reconnect headphones. Gently clean speaker mesh with a dry cotton swab.
Intermittent connection.	Too far from device; interference; low battery.	Stay within Bluetooth range (approx. 10 meters). Avoid strong Wi-Fi signals. Charge headphones.
Microphone not working.	Microphone blocked; app permissions.	Ensure microphone is not covered. Check app permissions for microphone access on your device.

Specifications

Model Name	E18
Connectivity Technology	Wireless (Bluetooth 5.3)
Audio Driver Type	Dynamic Driver
Audio Driver Size	16 Millimeters
Battery Life (Single Charge)	Up to 6 hours
Total Playtime (with Case)	Up to 30 hours
Noise Control	Active Noise Cancellation (for calls)
Water Resistance Level	Not Water Resistant

Item Weight	6.7 ounces (0.19 Kilograms)
Compatible Devices	Smartphones, Tablets, Laptops, Gaming Consoles, Smart Speakers
UPC	810079703463
Manufacturer	Monster

Warranty and Support

Monster products are designed and manufactured to the highest quality standards. For warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official Monster website. Keep your proof of purchase for any warranty claims.

For further assistance, please contact Monster customer service through their official channels.