

[Manuals.plus](#) /

› [Aquasonic](#) /

› AquaSonic Electric Toothbrush Charger Instruction Manual

Aquasonic B0DP56XC9K

AquaSonic Electric Toothbrush Charger Instruction Manual

Model: B0DP56XC9K

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your AquaSonic Electric Toothbrush Charger. Please read this manual thoroughly before use and retain it for future reference.

2. PRODUCT OVERVIEW

The AquaSonic Electric Toothbrush Charger is a conductive charging dock designed to power your AquaSonic electric toothbrush. It features advanced conductive charging technology for reliable power transfer and a compact, portable design for convenience.

Key Features:

- **Effortless Conductive Charging:** Utilizes advanced conductive charging technology for efficient power transfer.
- **Compact & Portable:** Designed for both home use and travel, minimizing space requirements.
- **Long Cord:** Features a cable length of over 48 inches for flexible placement.



Image 2.1: AquaSonic Electric Toothbrush Charger with its packaging.

3. COMPATIBILITY

This charger is compatible with most AquaSonic electric toothbrushes. Refer to the list below to confirm compatibility with your specific model:

- Black Series
- Black Series PRO
- Clinical AQ
- Duo Series PRO
- Elite
- HDC Pro

- Vibe Series
- Vibe Series PRO

Compatible

with the following
AquaSonic
toothbrushes

Black Series
Black Series Pro
Clinical AQ
Duo Series Pro
Elite
HDC Pro
Vibe Series
Vibe Series Pro



Image 3.1: Visual representation of compatible AquaSonic toothbrush models.

4. WHAT'S INCLUDED

Upon opening the package, you should find the following item:

- 1 AquaSonic Electric Toothbrush Charger

5. SETUP

Follow these steps to set up your AquaSonic Electric Toothbrush Charger:

1. **Unpack the Charger:** Carefully remove the charger from its packaging.
2. **Choose a Location:** Select a dry, stable surface near a standard electrical outlet. Ensure the surface is not prone to water splashes.
3. **Plug In:** Insert the charger's power plug into a 120-volt electrical outlet.

6. OPERATING INSTRUCTIONS

To charge your AquaSonic electric toothbrush:

1. **Place Toothbrush:** Gently place your AquaSonic electric toothbrush onto the charging dock. Ensure it is seated correctly and securely on the conductive base.
2. **Verify Charging:** The toothbrush should indicate that it is charging (e.g., a light indicator on the toothbrush may illuminate or flash). Refer to your toothbrush's manual for specific charging indicators.
3. **Charging Duration:** Allow the toothbrush to charge for the recommended duration as specified in your toothbrush's instruction manual.

Inductive Charger Base

Modern,
Wireless Charging



Image 6.1: Depiction of the inductive charging process with an AquaSonic toothbrush on the base.

Charging Made Easy

Portable
Compact
Lightweight
Easy to Use

AquaSonic

Image 6.2: An AquaSonic toothbrush positioned on its charger, illustrating ease of use.

7. MAINTENANCE

To ensure the longevity and proper function of your charger:

- **Cleaning:** Unplug the charger from the electrical outlet before cleaning. Wipe the surface of the charger with a soft, damp cloth. Do not use abrasive cleaners or immerse the charger in water.
- **Storage:** When not in use for extended periods, store the charger in a dry, cool place away from direct sunlight.
- **Inspection:** Periodically inspect the power cord and charger for any signs of damage. If damage is observed, discontinue use and replace the charger.

8. TROUBLESHOOTING

If you encounter issues with your AquaSonic Electric Toothbrush Charger, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Toothbrush not charging	Charger not plugged in correctly	Ensure the charger is securely plugged into a working electrical outlet.
Toothbrush not charging	Toothbrush not seated properly on the dock	Adjust the toothbrush on the charging dock to ensure full contact with the conductive base.
Charger feels warm during use	Normal operation	A slight warmth during charging is normal. If it becomes excessively hot, unplug immediately and contact support.

9. SPECIFICATIONS

Brand	Aquasonic
Model	B0DP56XC9K
Package Dimensions	4.53 x 2.64 x 1.54 inches
Item Weight	2.4 ounces
Input Voltage	120 Volts
Output Current	12 Amps
Connector Type	2-Pin
Special Feature	Wireless Charging
Color	Black

10. SUPPORT

For further assistance or inquiries, please refer to the AquaSonic official website or contact their customer support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question