

KlrSwp 1822

KlrSwp 1822 Handheld Cordless Pool Vacuum Instruction Manual

Model: 1822
Brand: KlrSwp

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation and maintenance of your KlrSwp 1822 Handheld Cordless Pool Vacuum. Please read this manual thoroughly before use and retain it for future reference.

PRODUCT OVERVIEW AND COMPONENTS

The KlrSwp 1822 is a cordless, water-activated pool and spa vacuum designed for cleaning small debris from various water bodies.

Key Features:

- **Water-Activated Automatic Activation:** Automatically turns on when submerged, preventing dry-running. The integrated LED light enhances underwater visibility.
- **Powerful Suction:** Efficiently removes small insects, silt, pollen, and leaves.
- **Fast Charging:** 2-hour charge provides up to 90 minutes of runtime.
- **Telescopic Pole:** Adjustable length up to 65 inches for extended reach.
- **Multiple Brush Heads:** Includes triangular, flat, and slim brushes for versatile cleaning of various surfaces and hard-to-reach areas.
- **Easy-to-Clean Filter:** Features a 0.32L large capacity stainless steel filter for simple debris disposal.

Package Contents:

- KlrSwp 1822 Vacuum Unit
- Telescopic Pole (multi-section)
- Triangular Brush Head
- Flat Vacuum Head
- Slim Brush Head
- USB Charging Cable
- Stainless Steel Filter (0.32L capacity)
- Rubber Block (for charging port waterproofing)
- Instruction Manual



Figure 1: KlrSwp 1822 Handheld Cordless Pool Vacuum and included accessories.

SETUP AND ASSEMBLY

1. **Charge the Battery:** Connect the USB charging cable to the vacuum unit and a suitable power source. Ensure the rubber block is securely in place to waterproof the charging port during use. A full charge takes approximately 2 hours.
2. **Assemble the Telescopic Pole:** Connect the pole sections by aligning the pins and holes until they click into place. Adjust the length as needed for your pool or spa depth. The maximum reach is 65 inches.
3. **Attach the Desired Brush Head:** Select the appropriate brush head (triangular for general floor cleaning, flat for corners, slim for stairs) and securely attach it to the vacuum unit.
4. **Insert Filter:** Ensure the 0.32L stainless steel filter is correctly inserted into the transparent debris collection chamber.

AUTO SENSOR SWITCH

Efficient and easy to operate



Cordless



Low Noise



Quick Cleaning



Powerful Suction



Intertek



The pool vacuum will start automatically when the water covers the sensor.



Figure 2: Assembly of the KlrSwp 1822 telescopic pole and vacuum head.

ADJUSTABLE TELESCOPIC POLE

Adjust the length to providing flexibility for your pool cleaning




Figure 3: Demonstrating the adjustable length of the telescopic pole for flexible cleaning.

REPLACEABLE CLEANING HEADS

Sweep all hard-to-reach area in your pool!

**TRIANGULAR BRUSH
FOR POOL FLOOR**



**FLAT VACUUM HEAD
FOR CORNERS**

**SLIM BRUSH
FOR POOL STAIRS**

Figure 4: The three interchangeable cleaning heads for various cleaning tasks.

OPERATING INSTRUCTIONS

1. **Activation:** The vacuum is equipped with a water sensor and will automatically activate and illuminate its LED light once submerged in water. No manual power button is required for activation.
2. **Submersion Depth:** For proper operation, immerse the motor in water deeper than 1.65 feet.
3. **Cleaning Technique:** Gently guide the vacuum along the bottom and sides of your pool or spa. The powerful suction will dislodge and collect debris. The integrated LED light enhances visibility in darker areas.
4. **Runtime:** The vacuum provides up to 90 minutes of continuous cleaning on a single full charge.
5. **Deactivation:** The vacuum will automatically deactivate when removed from water.

POWERFUL SUCTION AND PERFORMANCE

Easily dislodge and suction up debris accumulating in your pool



Figure 5: The KlrSwp 1822 vacuum in a pool, demonstrating its water-activated automatic start.



Figure 6: Underwater view of the vacuum effectively collecting debris from the pool floor.

Official Product Video:

Your browser does not support the video tag.

Video 1: Demonstration of the KlirSwp 1822 Handheld Cordless Pool Vacuum in use, showcasing its powerful suction and ease of operation for cleaning pool debris.

MAINTENANCE

1. **Emptying the Filter:** After each use, remove the debris collection chamber and the stainless steel filter. Discard collected debris.
2. **Cleaning the Filter:** Rinse the filter thoroughly with clean water until all debris is removed. The filter is reusable.
3. **Cleaning the Unit:** Wipe down the exterior of the vacuum unit with a soft, damp cloth.
4. **Storage:** Store the disassembled or assembled vacuum in a cool, dry place away from direct sunlight.

KEEP WATER CLEAN & CLEAR



Figure 7: Steps for easy removal and cleaning of the stainless steel filter.

TROUBLESHOOTING

Common Issues and Solutions:

- **Vacuum not activating:** Ensure the motor is submerged in water deeper than 1.65 feet. Check battery charge level.
- **Reduced suction:** Check if the filter is clogged with debris and clean it. Ensure the brush head is securely attached.
- **Short runtime:** Fully charge the battery for 2 hours. Battery life may decrease over time with repeated use.
- **LED light not working:** Check battery charge. If the issue persists, contact customer support.

For further assistance, please refer to the warranty and support information.

SPECIFICATIONS

- **Model Number:** 1822
- **Product Dimensions:** 3.15 x 3.15 x 65 inches (fully extended)
- **Item Weight:** 3.89 pounds

- **Battery:** 1 Lithium Polymer battery (included)
- **Charging Time:** Approximately 2 hours
- **Running Time:** Up to 90 minutes
- **Filter Capacity:** 0.32L
- **Minimum Water Depth for Operation:** 1.65 feet

Note: Specifications are subject to change without prior notice.

WARRANTY AND SUPPORT

KlrSwp offers customer support for any issues or questions you may have regarding your Handheld Cordless Pool Vacuum. Please refer to the product packaging or the official KlrSwp website for detailed warranty information and contact methods. For service inquiries, please retain your proof of purchase.