

[manuals.plus](#) /

› [BoxWave](#) /

› [BoxWave AccuPoint Active Stylus User Manual](#)

## BoxWave AccuPoint Active Stylus

# BoxWave AccuPoint Active Stylus User Manual

Model: AccuPoint Active Stylus

Brand: BoxWave

## INTRODUCTION

---

The BoxWave AccuPoint Active Stylus is an electronic stylus designed for precise interaction with your device's screen. It offers a natural writing and drawing experience without the need for Bluetooth pairing. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your stylus.



Image: The BoxWave AccuPoint Active Stylus shown alongside the ACODO Z5 Instant Translator, demonstrating its compatibility and sleek design.

## SETUP

---

### 1. Initial Charge

Before first use, ensure your AccuPoint Active Stylus is fully charged. Use the included MicroUSB cable to connect the stylus to any standard USB power source (e.g., computer USB port, wall adapter).



Image: The stylus connected to a laptop via its MicroUSB charging cable, illustrating the charging process.

The indicator light will show the charging status:

- **Red:** Charging
- **Green:** Fully Charged



Image: A detailed view of the stylus's charging port and indicator light, showing different light colors for power, charging, and full charge status.

## 2. Powering On

Simply press the button on the stylus to turn it on. No pairing with your device is required. The stylus emits quick electronic pulses to interact with your screen.





Image: An exploded view highlighting key features of the stylus: the built-in charging port, indicator light, 1.9mm extra fine tip, and FiberMesh tip. It also explicitly states that no Bluetooth connection is required.

## OPERATING INSTRUCTIONS

---

### Using the Stylus

The AccuPoint Active Stylus allows for natural interaction with your touchscreen device. Its ultra-accurate 2mm tip enables precise tapping, swiping, and drawing, similar to using a traditional pen.




Image: A hand demonstrating the use of the stylus on a tablet screen, highlighting its natural feel for navigation and input.

- **Precision Tip:** The fine tip is ideal for detailed work, writing, and accurate selection on your screen.
- **FiberMesh Tip:** The stylus also features a FiberMesh tip on the opposite end for broader strokes or general navigation, offering superior screen response.
- **Natural Writing Position:** The stylus is designed to allow for comfortable and natural writing positions.





Image: The stylus interacting with a tablet screen, emphasizing its high accuracy and sensitivity for precise input.

**Note:** The AccuPoint Active Stylus does not support Palm Rejection or Pressure Sensitivity.

## MAINTENANCE

---

### Cleaning

To maintain optimal performance and appearance, gently wipe the stylus with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials.

### Battery Care

The built-in battery provides approximately 12 hours of continuous use on a full charge. To prolong battery life:

- Charge the stylus regularly, avoiding complete discharge.
- Store the stylus in a cool, dry place when not in use.
- If storing for an extended period, charge it to about 50% before storage.

Stylus Not Responding

- **Check Battery:** Ensure the stylus is charged. Connect it to a power source and observe the indicator light.
- **Power On:** Confirm the stylus is turned on by pressing its button. The indicator light should illuminate.
- **Screen Compatibility:** While designed for broad compatibility, ensure your device's screen is clean and free of debris that might interfere with touch input.
- **Restart Device:** Sometimes, restarting your tablet or phone can resolve minor connectivity issues.

Charging Issues

- **Cable Check:** Ensure the MicroUSB cable is securely connected to both the stylus and the power source. Try a different MicroUSB cable if available.
- **Power Source:** Try a different USB power source (e.g., a different USB port on your computer, a different wall adapter).

SPECIFICATIONS

Feature	Detail
Model Name	AccuPoint Active Stylus
Brand	BoxWave
Color	Metallic Silver
Item Weight	1.3 ounces
Battery Type	Product Specific (included)
Battery Life	Up to 12 hours of use
Tip Size	2mm (Ultra Fine Tip)
Material	Solid brushed aluminum barrel
Charging Port	MicroUSB

WARRANTY AND SUPPORT






BoxWave products are designed for quality and reliability. For any questions, technical assistance, or warranty inquiries regarding your AccuPoint Active Stylus, please contact BoxWave Corporation directly.


You can typically find support contact information on the official BoxWave website or through your purchase platform.

**Note:** Protection plans may be available for purchase separately. Please refer to your purchase details for information on any extended protection plans.



## Related Documents - AccuPoint Active Stylus

 <p>DOUXE S3 Active Stylus Pen Instruction Manual</p>	<p><a href="#">DOUXE S3 Active Stylus Pen Instruction Manual</a></p> <p>Comprehensive instruction manual for the DOUXE S3 Active Stylus Pen, detailing features, technical specifications, operating instructions, safety warnings, and warranty information for touchscreen device users.</p>
	<p><a href="#">Penyeah Stylus Pen User Manual - DIY Combinations and Usage Guide</a></p> <p>Comprehensive user manual for the Penyeah P1 stylus pen, detailing DIY combinations of tips, usage instructions, and replacement procedures. Learn how to maximize your stylus experience for various devices and applications.</p>
 <p>sbs Ultra Fine Stylus Pen Designed for iPad 2018, 2019, 2020, 2021</p>	<p><a href="#">SBS Ultra Fine Stylus Pen for iPad: Precision, Tilt Function, and Style</a></p> <p>Discover the SBS Ultra Fine Stylus Pen (Tilt Pencil) for iPad 2018-2021. Featuring tilt function, palm rejection, durable aluminum design, and a replaceable POM nib for precise, lag-free drawing and writing.</p>
 <p>POWEROLOGY NÉOTEC Active Stylus Pen SKU: PGBSTPN</p>	<p><a href="#">Powerology NÉOTEC Active Stylus Pen - User Manual and Specifications</a></p> <p>Comprehensive guide to the Powerology NÉOTEC Active Stylus Pen (SKU: PGBSTPN), covering operation, features, specifications, compatible iPad models, and warranty information.</p>
 <p>ASUS ASUS PEN SA300</p>	<p><a href="#">ASUS Pen SA300 Quick Start Guide</a></p> <p>This guide provides instructions on how to use and maintain the ASUS Pen SA300 Active Stylus, including package contents, inserting and replacing the battery, and replacing the pen tip and holder.</p>



### [ASUS Pen 2.0 \(SA203H\) Active Stylus: Quick Start Guide](#)

Get started with your ASUS Pen 2.0 (SA203H) Active Stylus. This guide covers package contents, LED indicators, hardware interface, charging, and Bluetooth pairing instructions.