Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YESWELDER JP14-110R

YESWELDER Outer Protection Lens Instruction Manual

Model: JP14-110R (for LYG-32-110R Welding Goggles)

1. Introduction

This manual provides essential instructions for the proper installation, use, and maintenance of your YESWELDER 10-piece outer protection lenses. These lenses are specifically designed for use with YESWELDER LYG-32-110R welding goggles to protect the primary auto-darkening filter from spatter and scratches.

2. Safety Information

Always prioritize safety when working with welding equipment. These outer protection lenses are a consumable part designed to maintain the clarity and integrity of your welding goggles' main filter. They do not provide primary eye protection. Always wear appropriate personal protective equipment (PPE) for welding operations.
Important: Before installation, ensure you remove the protective plastic film from both sides of each new lens. Failure to do so will impair visibility.

3. Package Contents

- 10 x YESWELDER Outer Protection Lenses (Model JP14-110R)



Image: A pack of ten YESWELDER outer protection lenses, showing the protective film warning labels.

4. Setup and Installation

Follow these steps to replace the outer protection lens on your YESWELDER LYG-32-110R welding goggles:

1. **Prepare the Goggles:** Ensure your welding goggles are turned off and clean the exterior surface around the lens area.
2. **Remove Old Lens:** Carefully locate the clips or frame holding the existing outer protection lens in place. Gently unclip or open the frame to remove the old, damaged, or dirty lens. Dispose of the old lens responsibly.
3. **Prepare New Lens:** Take one new outer protection lens from the pack.**Crucially, peel off the protective plastic film from BOTH sides of the new lens.** These films are often clear or lightly tinted and must be removed for clear vision.
4. **Install New Lens:** Position the new lens into the designated slot on your welding goggles. Ensure it sits flush and correctly aligned.
5. **Secure Lens:** Re-engage the clips or close the frame to securely hold the new outer protection lens in place. Verify that the lens is firmly seated and does not wobble.
6. **Inspect:** Before use, visually inspect the installed lens for clarity and proper fit.

5. Operating Function

Once installed, the outer protection lens serves as a sacrificial barrier, shielding the sensitive auto-darkening filter of your LYG-32-110R welding goggles from welding spatter, grinding debris, and other physical damage. It ensures the longevity and optimal performance of your primary welding goggle lens by absorbing impacts and preventing scratches that could obscure your vision.

6. Maintenance

- **Cleaning:** Clean the outer protection lens regularly with a soft, lint-free cloth and a mild lens cleaning solution. Avoid abrasive materials or harsh chemicals that could scratch or damage the lens surface.
- **Replacement:** Replace the outer protection lens immediately if it becomes scratched, pitted, cracked, or otherwise damaged to the point where it impairs visibility or compromises the protection of the main filter. Regular replacement ensures clear vision and extends the life of your welding goggles.
- **Storage:** Store unused lenses in a clean, dry place, away from direct sunlight and extreme temperatures, to prevent degradation.

7. Troubleshooting

- **Blurry Vision After Installation:**
  Solution: Ensure the protective plastic film has been completely removed from both sides of the new lens. If the film is removed and vision is still blurry, the lens may be dirty or damaged and should be cleaned or replaced.
- **Lens Does Not Fit Properly:**
  Solution: Verify that you have the correct model of outer protection lens (JP14-110R) for your YESWELDER LYG-32-110R welding goggles. Check for any obstructions in the goggle frame that might prevent proper seating.

8. Specifications

Feature	Detail
Product Name	Outer Protection Lens
Model Number	JP14-110R
Compatibility	YESWELDER LYG-32-110R Welding Goggles
Quantity	10 Pieces
Material	Durable plastic
Package Dimensions	7.87 x 2.95 x 0.47 inches
Item Weight	0.35 ounces (total)

9. Warranty and Support

YESWELDER products are designed for quality and durability. This product comes with a **1-Year Warranty** from the date of purchase, covering manufacturing defects. For technical assistance, warranty claims, or any questions regarding your YESWELDER products, please contact YESWELDER customer support through the official website or your purchase platform.

© 2024 YESWELDER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DP5YK2KR

More documents and user manuals: **https://manuals.plus/**