

[Manuals.plus](#) /

› [AGIMA](#) /

› AGIMA X5 Mini Projector User Manual

AGIMA X5

AGIMA X5 Mini Projector User Manual

Model: X5
Brand: AGIMA

1. INTRODUCTION

Welcome to the AGIMA X5 Mini Projector user manual. This guide provides detailed instructions for setting up, operating, maintaining, and troubleshooting your new projector. Please read this manual thoroughly before using the device to ensure optimal performance and longevity.



Image: The AGIMA X5 Mini Projector, showcasing its compact design and key features such as 1080P Full HD, Auto Focus, Auto Keystone, 4K Support, and WiFi 6, alongside logos for Netflix, YouTube, and Prime Video.

2. WHAT'S IN THE BOX

Carefully unpack your AGIMA X5 Mini Projector and ensure all items are present:

- 1 x AGIMA X5 Projector
- 1 x HDMI Cable
- 1 x Power Adapter with Cable
- 1 x Remote Control (AAA batteries not included)
- 1 x User Manual (this document)

3. PRODUCT OVERVIEW

Key Features

- **Built-in Smart Streaming OS & App Store:** Access popular streaming services like Netflix, Prime Video, and YouTube directly.
- **Native 1080P Resolution & 4K Support:** Delivers crisp Full HD visuals with support for 4K video playback.
- **HDR10:** Enhances contrast and color accuracy for detailed images in both bright and dark scenes.
- **15W Dual Speakers & 3D Stereo Sound:** Integrated high-quality speakers provide immersive audio.
- **Auto Focus & Auto Keystone Correction:** Automatic image adjustment for optimal clarity and geometry.
- **Auto Screen Alignment & 50%-100% Zoom:** Effortless screen positioning and size adjustment.
- **WiFi 6 & Two-way Bluetooth 5.2:** High-speed wireless connectivity and versatile audio transmission.
- **Authentic 350 ANSI Lumens Brightness:** Provides clear and vibrant images in various lighting conditions.

Ports and Controls

Familiarize yourself with the projector's input/output ports and control buttons for seamless operation.



Image: The rear panel of the AGIMA X5 Mini Projector, highlighting its connectivity options including USB, HDMI, and power input, suitable for various devices and meeting environments.

- **HDMI Port:** Connect to laptops, gaming consoles (Switch/PS5), TV sticks, etc.
- **USB Port:** Connect USB drives for media playback or other compatible devices.
- **3.5mm Headphone Jack:** Connect external audio devices like headphones or speakers.
- **Power Port:** Connect the included power adapter.

4. SETUP

4.1 Powering On

1. Connect the power adapter to the projector's power port and then to an electrical outlet.
2. Press the power button on the projector or the remote control to turn on the device.

4.2 Initial Configuration

Upon first use, the projector will guide you through an initial setup process:

- **Language Selection:** Choose your preferred language.
- **Network Connection:** Connect to your Wi-Fi network (see section 5.2 for details).
- **Time Zone:** Set the correct time zone.

4.3 Placement and Projection

Place the projector on a stable, flat surface. The AGIMA X5 features automatic image adjustments:



Image: The AGIMA X5 Mini Projector demonstrating its auto-focus and auto-keystone correction capabilities, ensuring a clear and perfectly rectangular image on the projection surface.

- **Auto Focus:** The projector will automatically adjust the image clarity within seconds of being moved or powered on.
- **Auto Keystone Correction:** The image will automatically adjust to a rectangular shape, even if the projector is placed at an angle (up to $\pm 45^\circ$).
- **Projection Distance:** For optimal image size and clarity, ensure adequate distance from the projection surface. The projector supports screen sizes from 50% to 100% zoom.

5. OPERATING INSTRUCTIONS

5.1 Navigating the Smart OS

The AGIMA X5 runs on a smart operating system, providing a user-friendly interface:

Android TV Projector

Built-in Netflix

NETFLIX

 **YouTube**

prime video



Image: The AGIMA X5 Mini Projector projecting the Netflix interface onto a large screen, demonstrating its built-in smart streaming capabilities and Android TV OS.

- Use the remote control's directional buttons to navigate through menus and select options.
- Access pre-installed apps like Netflix, Prime Video, and YouTube directly from the home screen.
- Visit the App Store to download additional applications.
- The system supports online updates to ensure you have the latest features and improvements.

5.2 Connecting to Wi-Fi

To access online content and smart features, connect your projector to a Wi-Fi network:

Latest WiFi6 and Bluetooth 5.2 technology

Reduced latency for a seamless experience



Image: A visual comparison illustrating the enhanced performance of WiFi 6 over WiFi 5, highlighting the AGIMA X5 Mini Projector's advanced wireless connectivity for seamless streaming.

1. Go to **Settings > Network > Wi-Fi**.
2. Select your desired Wi-Fi network from the list.
3. Enter the password using the on-screen keyboard and confirm.

5.3 Bluetooth Connectivity

The projector supports two-way Bluetooth 5.2 for audio transmission:

- **Connecting to External Speakers/Headphones:** Go to **Settings > Bluetooth**, turn on Bluetooth, and select your device to pair.
- **Using as a Standalone Bluetooth Speaker:** The projector can receive audio from mobile devices. Refer to your mobile device's Bluetooth settings to connect to the projector.

5.4 Using External Devices (HDMI, USB)

- **HDMI:** Connect an HDMI cable from your external device (e.g., laptop, game console) to the projector's HDMI port. Select the HDMI input source from the projector's menu.
- **USB:** Insert a USB drive into the USB port. The projector's media player will typically prompt you to browse the contents of the drive.

5.5 Adjusting Image (Zoom, Keystone)

While auto-correction is standard, manual adjustments are available:

- **Zoom Function:** Use the remote control or on-screen menu to adjust the screen size from 50% to 100% without moving the projector.
- **Manual Keystone Correction:** If needed, fine-tune the keystone correction through the display settings menu.

6. MAINTENANCE

6.1 Cleaning the Lens

To maintain optimal image quality, regularly clean the projector lens:

- Use a soft, lint-free cloth specifically designed for optical lenses.
- Gently wipe the lens in a circular motion.
- Avoid using abrasive cleaners or excessive force.

6.2 Storage

When not in use, store the projector in a cool, dry place, away from direct sunlight and excessive dust. Consider using a protective cover to prevent dust accumulation.

7. TROUBLESHOOTING

If you encounter issues with your projector, refer to the table below for common problems and solutions.

Problem	Possible Solution
No image or blurry image	Ensure the projector is powered on. Check focus (allow auto-focus to complete or adjust manually). Verify projection distance.
No sound	Check volume settings on the projector and connected devices. Ensure external speakers/headphones are properly connected or paired via Bluetooth.
Remote control not working	Replace batteries. Ensure there are no obstructions between the remote and the projector's IR receiver.
Cannot connect to Wi-Fi	Ensure Wi-Fi is enabled on the projector. Verify Wi-Fi password. Restart your router and the projector.
Image is distorted (not rectangular)	Allow auto-keystone correction to complete. If needed, perform manual keystone correction in settings.

8. SPECIFICATIONS

Detailed technical specifications for the AGIMA X5 Mini Projector:

Feature	Specification
Model Number	X5
Display Resolution	Native 1920 x 1080 (1080P Full HD)
4K Support	Yes
Brightness	350 ANSI Lumens
Connectivity Technology	3.5mm Jack, HDMI, USB, WiFi 6 (Dual-band 5G/2.4G), Bluetooth 5.2
Special Features	AI Auto Focus, Auto Keystone Correction, Built-in Speaker, Portable, Lightweight, Android TV OS
Product Dimensions	4.88 x 5.66 x 6.45 inches (12.4 x 14.4 x 16.4 cm)
Item Weight	2 lb (0.9 kg)
Voltage Range	100-240V

9. WARRANTY AND SUPPORT

9.1 Warranty Information

The AGIMA X5 Mini Projector comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty duration and coverage details.

9.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact AGIMA customer support. Contact details can typically be found on the official AGIMA website or on the product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DP5ZNX4F>

More documents and user manuals: <https://manuals.plus/>