



[Manuals.plus](#) /

› [SPORTNOW](#) /

› SPORTNOW Wall-Mounted Basketball Hoop Instruction Manual

SPORTNOW A61-066V00BK

SPORTNOW Wall-Mounted Basketball Hoop Instruction Manual

Model: A61-066V00BK

Brand: SPORTNOW

1. INTRODUCTION

Thank you for choosing the SPORTNOW Wall-Mounted Basketball Hoop. This product is designed for both indoor and outdoor use, providing a durable and adjustable basketball experience for players of all ages and skill levels. This manual provides essential information for safe installation, operation, and maintenance of your new basketball hoop.




Figure 1: The SPORTNOW Wall-Mounted Basketball Hoop, featuring a clear backboard, steel hoop, and red, white, and blue net.

Key Features:

- **Practical Wall Mounting:** Easily attaches to concrete, brick walls, or wood, suitable for indoor and outdoor areas like gyms, garages, or house walls.
- **Height Adjustable:** The backboard height can be adjusted by up to 50 cm to accommodate players of various ages and skill levels.
- **Secure Flexibility:** The spring-loaded basketball hoop provides flexible response under stress, minimizing damage risk and enhancing player safety.
- **Shatterproof Construction:** Features a 110 cm wide shatterproof backboard, a sturdy steel hoop, and a tear-resistant net, designed for intensive play.

2. SAFETY INFORMATION

Please read and understand all safety warnings and instructions before assembly and use. Failure to follow

these instructions may result in serious injury or property damage.

- **Adult Supervision:** Children should always be supervised by an adult when using the basketball hoop.
- **Proper Installation:** Ensure the hoop is securely mounted to a sturdy wall capable of supporting its weight and the forces exerted during play. Refer to the "Setup / Installation" section for detailed instructions.
- **Inspect Before Use:** Before each use, check all bolts, nuts, and connections for tightness. Ensure the backboard, hoop, and net are in good condition. Do not use if any part is damaged or loose.
- **No Hanging:** Do not hang on the rim or any part of the backboard structure. This can cause serious injury and damage the product.
- **Clear Area:** Ensure the playing area around the hoop is clear of obstacles and hazards.
- **Weather Conditions:** If used outdoors, be aware of weather conditions. Strong winds or storms can damage the hoop or cause it to detach from the wall.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- 1 x Basketball Hoop (Rim)
- 1 x Backboard
- 1 x Net
- Mounting Hardware (screws, bolts, etc.)



Figure 2: The SPORTNOW Basketball Hoop mounted outdoors, showing the complete setup. This image also implies the components included in the package.

4. SETUP / INSTALLATION



This basketball hoop is designed for wall mounting. Proper installation is crucial for safety and product longevity. It is recommended that two adults perform the installation.

Required Tools (Not Included):

- Drill with appropriate drill bits for your wall type (concrete, brick, wood)
- Level
- Measuring tape
- Wrench or socket set
- Pencil for marking

Installation Steps:

1. **Choose Location:** Select a sturdy wall (concrete, brick, or solid wood) that can safely support the weight of the basketball hoop and withstand the forces of play. Ensure there is ample clear space around the installation area.
2. **Mark Drilling Points:** Hold the backboard assembly against the wall at the desired height. Use a level to ensure it is straight. Mark the positions for the mounting holes with a pencil.
3. **Drill Holes:** Using the appropriate drill bit for your wall material, drill holes at the marked points. Ensure the depth and diameter of the holes match the provided mounting hardware.
4. **Attach Mounting Brackets:** Secure any separate mounting brackets to the wall using the provided screws and anchors (if applicable).
5. **Mount Backboard Assembly:** Carefully lift the backboard assembly and align its mounting points with the drilled holes or attached brackets. Insert the provided bolts and tighten them securely with a wrench. Do not overtighten, but ensure there is no wobble.
6. **Attach Hoop and Net:** If the hoop and net are not pre-attached, follow the specific instructions to secure the steel hoop to the backboard and then attach the net to the hoop.
7. **Final Check:** Double-check all connections for tightness and stability. Gently pull on the hoop to ensure it is firmly secured to the wall.




 Installieren Sie das Gerät an einer Wand, in die Sie bohren können und die das Gewicht des Geräts tragen kann.

Figure 3: Illustration of the wall mounting process, showing the included fastening screws and how the hoop attaches to the wall.



Figure 4: The basketball hoop installed on an outdoor wall, demonstrating its use by two players.

5. OPERATING INSTRUCTIONS

Height Adjustment:

The backboard height can be adjusted by up to 50 cm to suit different players. To adjust the height, locate the two pins on the support structure behind the backboard. Remove these pins, slide the backboard up or down to the desired height, and reinsert the pins securely to lock it in place. Ensure both pins are fully engaged before use.

HÖHENVERSTELLBAR

Einfache Höhenverstellung durch
Herausnehmen von zwei Stiften



Figure 5: Diagram illustrating the height adjustment mechanism, showing how the backboard can be moved up or down by 50 cm.

Spring-Loaded Hoop:

The basketball hoop features a spring-loaded mechanism. This design allows the rim to flex downwards under pressure, reducing stress on the backboard and mounting structure, and minimizing the risk of damage during dunks or aggressive play. The rim will return to its original position once the pressure is released.

ABKLAPPBARER KORBBRAND

Verringerung des Schadensrisikos



Figure 6: Visual representation of the spring-loaded hoop, demonstrating its ability to bend under pressure to reduce damage risk.

6. MAINTENANCE

Regular maintenance will ensure the longevity and safe operation of your basketball hoop.

- **Cleaning:** Clean the backboard and frame with a soft cloth and mild soap and water. Avoid abrasive cleaners or solvents that could damage the materials. Rinse thoroughly and dry.
- **Hardware Check:** Periodically check all bolts, nuts, and screws for tightness. Retighten any loose fasteners to prevent wobbling or detachment.
- **Net Inspection:** Inspect the net for any tears or fraying. Replace the net if it shows signs of significant wear to ensure continued playability.
- **Rust Prevention:** For outdoor use, regularly inspect metal parts for signs of rust. If rust appears, clean the affected area and apply a rust-inhibiting paint or coating.
- **Storage (if applicable):** If storing the hoop for extended periods, especially in harsh weather, consider

covering it or disassembling it if feasible to protect it from elements.

7. TROUBLESHOOTING

If you encounter any issues with your basketball hoop, refer to the common problems and solutions below. If the problem persists, please contact customer support.

Problem	Possible Cause	Solution
Hoop feels wobbly after installation.	Mounting bolts are not sufficiently tightened or wall material is not strong enough.	Ensure all mounting bolts are securely tightened. If the wall material is weak, consider reinforcing it or choosing a different mounting location.
Height adjustment mechanism is stuck.	Pins are jammed or mechanism is dirty.	Clean the adjustment mechanism and pins. Apply a silicone-based lubricant if necessary. Ensure pins are fully retracted before attempting to slide.
Net is torn or damaged.	Normal wear and tear or excessive force.	Replace the net with a compatible replacement.
Backboard appears scratched or cloudy.	Improper cleaning or exposure to harsh elements.	Clean with a soft cloth and mild soap. Avoid abrasive materials. Minor scratches may be polished with plastic-specific polish.

8. SPECIFICATIONS

Detailed specifications for the SPORTNOW Wall-Mounted Basketball Hoop (Model A61-066V00BK).

Feature	Specification
Model Number	A61-066V00BK
Backboard Dimensions (L x W)	110 cm x 70 cm (43.3" x 27.6")
Hoop Diameter	Ø45 cm (Ø17.7")
Overall Product Dimensions (D x W x H)	28 cm x 110 cm x 70 cm (11" x 43.3" x 27.6")
Weight	11.5 kg (25.3 lbs)
Material	Alloy Steel (Frame), High-strength Plastic (Backboard)
Color	Black

Feature	Specification
Height Adjustment Range	Up to 50 cm (19.7")
Mounting Type	Wall Mount
Intended Use	Indoor and Outdoor




Figure 7: Detailed dimensions of the basketball hoop and backboard.

9. WARRANTY AND SUPPORT

SPORTNOW products are manufactured to high-quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please refer to the product packaging or the retailer's website for specific warranty terms and conditions.

For technical support, missing parts, or warranty claims, please contact the retailer or SPORTNOW customer

service directly. Have your model number (A61-066V00BK) and purchase information ready when contacting support.

Online Support: Visit the official SPORTNOW website for FAQs, product registration, and contact information.

Email Support: [Insert general support email if available, otherwise omit or state "Refer to website"]

Phone Support: [Insert general support phone if available, otherwise omit or state "Refer to website"]