

KICKPI KP1 Android TV

KICKPI KP1 Android TV Box User Manual

Model: KP1 Android TV | Brand: KICKPI

INTRODUCTION

The KICKPI KP1 Android TV Box is a Google Certified 4K streaming device designed to enhance your home entertainment experience. Featuring 2GB RAM, 32GB ROM, Dolby Audio, and Bluetooth 5.0, it offers seamless access to a vast library of movies, shows, and apps. With Chromecast built-in and Google Assistant voice control, managing your entertainment and smart home devices is effortless.

WHAT'S IN THE BOX

- Remote Control
- HDMI Cable 1.2 Meter
- 12.0V/1.5A Adapter
- User Manual
- KICKPI KP1 Google Certificated Player



Figure 1: KICKPI KP1 Android TV Box and its remote control, as included in the package.

Video 1: An unboxing and overview of the KICKPI KP1 Android TV Box and its components.

SETUP

1. Connecting the Device

1. Connect the KICKPI KP1 to your TV using the provided HDMI cable. Insert one end into the HDMI port on the TV Box and the other into an available HDMI input on your television.
2. Connect the power adapter to the DC 12V/1.5A port on the TV Box and plug it into a power outlet.
3. For wired internet, connect an Ethernet cable to the LAN port on the TV Box. For wireless, ensure your Wi-Fi network is available.

Convenient connectivity and Demension

Various interfaces such as HDMI, LAN, USB, Micro SD to meet your different needs.




Figure 2: Rear view of the KICKPI KP1 Android TV Box showing its various connectivity ports including HDMI, LAN, USB, and power input.

2. Initial Setup and Network Configuration

Upon first power-on, the device will guide you through the initial setup process. Follow the on-screen instructions to select your language, connect to your Wi-Fi network (if not using Ethernet), and sign in with your Google account. This step is crucial for accessing the Google Play Store and other Google services.

3. Remote Control Pairing and Google Assistant

The included remote control uses Bluetooth for enhanced functionality, including voice control. During setup, you may be prompted to pair the remote. Press and hold the specified buttons on the remote until the pairing indicator appears on screen. Once paired, you can use the Google Assistant button to issue voice commands for searching content, controlling smart home devices, and more.



Figure 3: Illustration of using Google Assistant voice commands with the KICKPI KP1 Android TV Box.

OPERATING THE KICKPI KP1

1. Navigation and Home Screen

Navigate the Android TV interface using the directional pad and select button on your remote. The home screen provides quick access to your favorite apps, recommended content, and various categories like movies, shows, and music. You can customize the home screen by adding or removing sections and rearranging your favorite apps.

2. Streaming Content

The KICKPI KP1 supports 4K HDR streaming across various platforms. Pre-installed apps like Netflix, Amazon Prime Video, YouTube, and Disney+ allow you to enjoy a wide range of content. Ensure you have active subscriptions for paid services.

4K Ultra HD Resolution



Figure 4: Viewing Netflix content in 4K resolution on the KICKPI KP1.

4K Ultra HD Resolution

Immerse yourself in ultra-high-definition video
with stunning clarity and detail




Figure 5: Visual representation of 4K Ultra HD resolution provided by the KICKPI KP1.

3. Chromecast Built-in

With Chromecast built-in, you can effortlessly cast your favorite entertainment, photos, and apps from your phone, tablet, or laptop directly onto your television screen for a more immersive viewing experience. Simply tap the Cast icon in compatible apps on your mobile device.

Video 2: Demonstration of Chromecast functionality with the KICKPI KP1 Android TV Box.

4. Playing Games

The KICKPI KP1's high-spec configuration delivers a seamless gaming experience. A plethora of games are available for download from the Google Play Store, which can be played directly on your TV. For an even more enjoyable gaming session, you can connect a wireless gamepad via Bluetooth.



Figure 6: A user playing a game on the TV using the KICKPI KP1 device and a connected gamepad.

SPECIFICATIONS

Feature	Detail
Brand	KICKPI
Model Name	KICKPI KP1 Smart Android 12 Streaming Media Player
Operating System	Android 12.0
RAM	2GB LPDDR4
ROM	32GB eMMC
Resolution	4K

Special Feature	Chromecast
Connectivity Technology	Wireless, Wi-Fi, USB, Ethernet, HDMI
Wi-Fi	Dual-band 2.4G/5G WiFi5
Bluetooth	Bluetooth 5.0
Item Weight	4.3 ounces
Product Dimensions	3.78 x 3.78 x 0.91 inches




Figure 7: Detailed view of the High Performance SOC (System on Chip) within the KICKPI KP1, highlighting its CPU, GPU, RAM, ROM, and 4K video decoding capabilities.

MAINTENANCE

1. Cleaning

To maintain optimal performance, regularly clean the exterior of the device with a soft, dry cloth. Avoid

using liquid cleaners or abrasive materials. Ensure ventilation openings are free from dust and obstructions.

2. Software Updates

The KICKPI KP1 may receive periodic software updates to improve performance, add new features, or enhance security. It is recommended to install these updates when prompted to ensure your device is running the latest software version. Updates can typically be found in the device's settings menu under 'About' or 'System Update'.

TROUBLESHOOTING

No Power

- Ensure the power adapter is securely connected to both the device and a working power outlet.
- Try a different power outlet to rule out power supply issues.

No Signal on TV

- Verify the HDMI cable is firmly connected to both the TV Box and the TV.
- Ensure your TV is set to the correct HDMI input source.
- Try a different HDMI port on your TV or a different HDMI cable.

App Freezing or Crashing

- Close and restart the problematic app.
- Clear the app's cache and data from the device settings (Apps > [App Name] > Storage > Clear Cache/Clear Data).
- Ensure the device's software is up to date.
- If issues persist, consider uninstalling and reinstalling the app.

Remote Control Not Responding

- Check and replace the batteries in the remote control.
- Ensure there are no obstructions between the remote and the TV Box.
- Re-pair the Bluetooth remote control in the device's settings (Remotes & Accessories).

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official KICKPI website or the contact information provided in the original product packaging. Keep your purchase receipt as proof of purchase for warranty claims.