

[Manuals.plus](#) /

> [Smuxee](#) /

> Smuxee Shoe Cabinet with 2 Flip Drawers (23.6 inch) Instruction Manual

Smuxee 23.6 in (60 cm) With Flip Drawer

Smuxee Shoe Cabinet with 2 Flip Drawers (23.6 inch) Instruction Manual

Model: 23.6 in (60 cm) With Flip Drawer

Brand: Smuxee

1. INTRODUCTION AND OVERVIEW

This manual provides essential information for the assembly, operation, and maintenance of your Smuxee Shoe Cabinet. This freestanding shoe cabinet features two flip drawers, offering a space-saving solution for organizing footwear. Its fluted design and grey finish provide a modern aesthetic suitable for various home environments such as entryways, hallways, living rooms, or closets.



Image 1.1: Smuxee Shoe Cabinet in an entryway setting.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use to prevent injury or damage to the product.

- Always follow the assembly instructions carefully.
- Use appropriate safety gear when handling tools during assembly.
- Secure the cabinet to the wall using the provided anti-tipping device to prevent tipping and potential injuries, especially in households with children.
- Do not overload the cabinet beyond its specified load-bearing capacity.
- Keep the area around the cabinet clear of obstacles to prevent trips and falls.



Anti-Tipping Device

Protect your family's safety

Image 2.1: Illustration of the anti-tipping device installation.

3. PACKAGE CONTENTS

Before beginning assembly, ensure all parts listed in the assembly guide are present and undamaged. The package includes all necessary panels, hardware, and the anti-tipping device required for construction.

4. SETUP AND ASSEMBLY

The Smuxee Shoe Cabinet is designed for straightforward assembly. Detailed installation instructions are included in the box to guide you through the process. It is recommended to have a second person assist during certain steps, particularly when installing the internal bracket shelves, as this can make the process easier.



Image 4.1: Product dimensions for planning placement.

Assembly Tips:

- Lay out all components on a clean, soft surface to prevent scratches.
- Follow the numbered steps in the provided instruction manual precisely.
- Ensure all screws and fasteners are tightened securely, but do not overtighten.
- Install the anti-tipping device as instructed in Section 2.

Assembly Demonstration:

Your browser does not support the video tag.

Video 4.2: A demonstration of the shoe cabinet's features and assembly process, including how the flip drawers operate and the overall appearance of the assembled unit.

5. OPERATING INSTRUCTIONS

The Smuxee Shoe Cabinet is designed for convenient and organized shoe storage.

Using the Flip Drawers:

- Each cabinet features two flip drawers that open downwards. Gently pull the handle to open a drawer.
- Each drawer contains two levels of storage.
- To close, push the drawer upwards until it securely latches. The smooth gliding mechanism ensures easy opening and closing.



Image 5.1: Smuxee Shoe Cabinet with flip drawers open, showing internal storage.

Adjustable and Removable Panels:

The internal panels within each flip drawer can be adjusted or removed to accommodate various shoe types and sizes.

- **Adjusting Panels:** The panels can be moved up or down in two grooves to fit different shoe styles, such as flats or mid-calf boots.

- **Removing Panels:** For taller footwear like heels or larger boots, the panels can be completely removed to create a single, larger storage space within the drawer.



Image 5.2: Details on adjusting and removing internal panels.

6. MAINTENANCE

To ensure the longevity and appearance of your Smuxee Shoe Cabinet, follow these maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish.
- **Dusting:** Regularly dust the cabinet with a dry, soft cloth.
- **Spills:** Clean up spills immediately to prevent staining or water damage.
- **Placement:** Avoid placing the cabinet in direct sunlight or near heat sources to prevent warping or fading.
- **Hardware:** Periodically check and tighten any loose hardware to maintain stability.

7. TROUBLESHOOTING

If you encounter any issues with your shoe cabinet, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Drawers do not close properly or open on their own.	Overloaded with shoes; shoes are too large or bulky; internal panels are incorrectly positioned.	Reduce the number of shoes. Adjust or remove internal panels to accommodate larger shoes. Ensure shoes are placed flat and do not obstruct the closing mechanism.
Cabinet feels unstable or wobbly.	Loose assembly hardware; uneven floor; anti-tipping device not installed or improperly secured.	Check and tighten all assembly screws. Place the cabinet on a level surface. Ensure the anti-tipping device is correctly installed and securely anchored to the wall.
Bottom drawer scrapes when opening/closing.	Misalignment during assembly.	Review assembly steps for the drawer mechanism. Ensure all parts are correctly aligned and tightened. If necessary, partially disassemble and reassemble the drawer section.

If issues persist, please contact Smuxee customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	Smuxee
Color	Grey With Flip Drawer
Recommended Uses	Shoes
Product Dimensions	9.5"D x 23.6"W x 37"H
Special Feature	Shoe Cabinet
Mounting Type	Floor Mount
Room Type	Entryway, Living Room
Door Style	Flip Drawers
Included Components	1 x Door (refer to assembly guide for full list)
Finish Type	Grey
Size	23.6 in (60 cm)
Shape	Rectangular
Number of Shelves	4 (internal adjustable panels)
Number of Pieces	1 (cabinet unit)
Item Weight	18.05 Kilograms (39.7 pounds)
Base Type	Legs

Feature	Detail
Installation Type	Freestanding
Top Material Type	Wood
Assembly Required	Yes
Frame Material	Engineered Wood
Number of Compartments	8 (adjustable)
Country/Region Of Origin	China

9. WARRANTY AND SUPPORT

For any questions regarding your Smuxee Shoe Cabinet, including assembly, parts, or operational concerns, please contact Smuxee customer support. Specific warranty details may be provided with your purchase documentation. Please retain your proof of purchase for any warranty claims.

Manufacturer: Smuxee