

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [MZYMI](#) /

› MZYMI S07 Wireless Earbuds User Manual

MZYMI S07

MZYMI S07 Wireless Earbuds User Manual

This manual provides detailed instructions for the setup, operation, and maintenance of your MZYMI S07 Wireless Earbuds.

1. INTRODUCTION

Thank you for choosing MZYMI S07 Wireless Earbuds. To ensure optimal performance and longevity of your device, please read this manual carefully before use. Keep this manual for future reference.

2. WHAT'S IN THE BOX

- MZYMI S07 Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual

3. PRODUCT OVERVIEW

The MZYMI S07 Wireless Earbuds are designed for a comfortable listening experience with advanced features.



Image 3.1: MZYMI S07 Wireless Earbuds in their open charging case, showcasing the earbuds and charging contacts.

MZYMI

-42dB noise reduction

New noise reduction experience

The ultra wide noise reduction of 4kHz means a wider range of applications, not only effectively suppressing low-frequency noise during aircraft and subway roars, but also better weakening mid to high frequency noise such as human voices



Image 3.2: A person demonstrating the smart touch control feature on an earbud, highlighting ease of access to functions.

MZYMI

Wireless Flash Connection 5.4 Strong performance leap

Equipped with high-performance wireless 5.4 chip, it enhances connection stability and speed



Image 3.3: A detailed diagram illustrating the high-performance Bluetooth 5.4 chip, emphasizing stable and fast connection.

4. SETUP

4.1 Charging the Earbuds and Case

1. Place the earbuds into the charging case. Ensure the charging contacts align.
2. Connect the USB charging cable to the charging port on the case and to a power source.
3. The LED indicator on the charging case will illuminate to show charging status. A full charge for the case takes approximately 2 hours.
4. The earbuds will charge automatically when placed in the case.

Note: The charging case provides approximately 60 hours of total playtime, with individual earbuds offering 5-10 hours per charge depending on usage.



Image 4.1: Visual representation of the MZYMI S07's battery life, indicating 180 days standby, 60 hours with the charging case, and 7-10 hours for a single earbud.

4.2 Bluetooth Pairing

1. Ensure the earbuds are charged.
2. Open the lid of the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for available Bluetooth devices and select "MZYMI S07" from the list.
5. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.
6. The earbuds will automatically reconnect to the last paired device when removed from the case.

4.3 App Installation

The MZYMI S07 earbuds support a companion application for enhanced control and customization. Please refer to the QR code or instructions provided in your physical user manual to download and install the official MZYMI application on your smartphone.

MZYMI multiple option functions

All in the **With APP**

The APP enables headphone positioning, customizable buttons, convenient functions, and many wonderful uses



Image 4.2: Screenshots of the MZYMI companion app, showing features like EQ regulation, noise reduction settings, and key settings for customizable controls.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging.

5.2 Touch Controls

The MZYMI S07 earbuds feature smart touch controls on each earbud. The specific functions can often be customized via the companion app.

- **Single Tap:** Play/Pause music. Answer/End call.
- **Double Tap:** Next track (Right earbud), Previous track (Left earbud).
- **Triple Tap:** Volume Up (Right earbud), Volume Down (Left earbud).
- **Press and Hold:** Cycle through ANC (Active Noise Cancellation) modes (ANC On, Transparency Mode, ANC Off). Reject incoming call.

5.3 Active Noise Cancellation (ANC) and Transparency Mode

The earbuds are equipped with ANC technology to reduce environmental noise and ENC for clear calls.

- **ANC On:** Reduces ambient noise, ideal for noisy environments.
- **Transparency Mode:** Allows you to hear your surroundings while listening to audio.
- **ANC Off:** Standard audio mode without noise cancellation or transparency.

Cycle through these modes by pressing and holding the touch area on either earbud.



MZYMI
Smart Touch Control
Access different functions by tapping on the earbuds

-  Beyond imagination
noise reduction
-  As if on site
Immersive enjoyment
-  Extremely clear
Call quality
-  Smaller and lighter
More comfortable
-  flexible
Stable connection
-  Wow Intelligence
New Experience

Image 5.1: A visual representation of the earbud's -42dB noise reduction capability, showing how it suppresses low-frequency and weakens mid-to-high frequency noise.

MZYMI

ANC+ENC

New noise cancelling headphones

-42dB noise reduction

ENC call noise reduction

HiFi sound quality

Total battery life of 60H

Wireless version V5.4

APP adjusts EQ sound effects

APP to check battery level

APP positioning headphones

Change the name of the app

APP mode switching

APP noise reduction switch



Image 5.2: An overview of the ANC+ENC features, detailing -42dB noise reduction, ENC call noise reduction, HiFi sound quality, and Bluetooth V5.4.

6. MAINTENANCE

6.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Ensure charging contacts on both earbuds and case are clean and free of debris to maintain proper charging.

6.2 Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Avoid storing in extreme temperatures, direct sunlight, or high humidity.

7. TROUBLESHOOTING

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Earbuds not pairing	<ul style="list-style-type: none"> • Ensure earbuds are charged. • Turn off and on Bluetooth on your device. • Forget the device in your Bluetooth settings and re-pair. • Place earbuds back in case, close lid, then open to re-enter pairing mode.
No sound or low volume	<ul style="list-style-type: none"> • Check device volume and earbud volume. • Ensure earbuds are properly connected. • Clean any debris from earbud speakers.
Charging issues	<ul style="list-style-type: none"> • Ensure charging cable is securely connected. • Clean charging contacts on earbuds and case. • Try a different charging cable or power adapter.
ANC not effective	<ul style="list-style-type: none"> • Ensure earbuds are properly seated in your ears for a good seal. • Cycle through ANC modes to ensure it is activated. • ANC is most effective against low-frequency noise.

8. SPECIFICATIONS

Feature	Detail
Model Name	S07 MZYMI
Connectivity Technology	Wireless (Bluetooth 5.4)
Noise Control	Sound Isolation, ANC (Active Noise Cancellation)
Water Resistance Level	Waterproof (IPX8)
Battery Life (Earbuds)	Up to 5 Hours
Battery Life (with Charging Case)	Up to 60 Hours
Charging Time	Approximately 2 Hours
Bluetooth Range	Up to 10 Meters
Material	Silicone
Item Weight	50 Grams (1.76 ounces)
Frequency Response	20000 Hz
Audio Driver Type	Dynamic Driver

9. WARRANTY AND SUPPORT

9.1 Warranty Information

Warranty details for your MZYMI S07 Wireless Earbuds are typically provided with your purchase documentation or can be obtained from the retailer or manufacturer. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For further assistance, technical support, or inquiries regarding your MZYMI S07 Wireless Earbuds, please contact the seller or manufacturer through their official support channels. Refer to the packaging or product listing for contact information.