

[Manuals.plus](#) /

> [Feelfunn](#) /

> Feelfunn 2.65 Cu.Ft Portable Clothes Dryer - 1400W Clothes Dryer with Stainless Steel Tub, Front Load Tumble, LCD Touch Panel - Compact Drying Unit for Laundry, Apartments, Dorms

Feelfunn 2.65 Cu.Ft (Touchpad Digital Control)

Feelfunn 2.65 Cu.Ft Portable Clothes Dryer Instruction Manual

Model: 2.65 Cu.Ft (Touchpad Digital Control)

Brand: Feelfunn

PRODUCT OVERVIEW

This Feelfunn 2.65 Cu.Ft Portable Clothes Dryer is designed for efficient and convenient laundry drying in compact spaces. With 1400W of power, it reaches temperatures up to 140°F, ensuring quick and thorough drying. Its user-friendly design, including an LCD touch panel and multiple drying modes, makes laundry simple. The dryer features a durable stainless steel tub and a multi-filter system for optimal performance.



Image: Front view of the Feelfunn 2.65 Cu.Ft Portable Clothes Dryer.

SETUP AND INSTALLATION

The Feelfunn portable clothes dryer offers versatile installation options to suit various living arrangements. It can be used freestanding, wall-mounted, stacked, or placed under a counter.

Included Components

- 1 x Dryer Machine
- 2 x Suspension Brackets (for wall mounting)
- 2 x Plastic Washers
- 1 x Exhaust Pipe Fitting
- 4 x Screws (12mm)
- 4 x Screws (25mm)
- 1 x User Manual

Power Requirements

This dryer operates on standard 110V to 120V electrical outlets. No special wiring is required.

Installation Options



Automatic Door Stop

Halts drying instantly when the door opens for safety



Stainless Steel Drum

Built to last, resistant to rust for long-term use



Air Intake Filter

Filters dust and lint, improving airflow for more efficient drying



Convenient Handles

Designed for easy lifting and simple transport

Image: Visual representation of the dryer in freestanding, wall-mounted, stacking, and under-counter configurations.



Automatic stop when the door is opened



Stainless Steel Drum



Convenient Handles



Air Intake Filter

Image: Detailed view of the dryer's dimensions (23.6" x 17.6" x 27") and features like convenient handles and the air intake filter.

OPERATING INSTRUCTIONS

The dryer features an intuitive LCD touch panel for easy operation.

Drying Modes

Select from four drying modes to best suit your laundry:

- **Strong:** Full-power drying for heavily wet items.
- **Intelligent:** Auto-detects dryness level for optimal results.

- **ECO:** Energy-saving mode.
- **Normal:** Half-power drying for everyday loads.

Note: ECO and Intelligent modes auto-sense dryness.



4 DRYING MODES

- ✓ **Strong:** Full-power drying
- ✓ **Intelligent:** Auto-detects dryness level
- ✓ **ECO:** Energy-saving mode
- ✓ **Normal:** Half-power drying

ECO and Intelligent modes auto-sense dryness



Remaining Time Display (Minutes)

Image: Close-up of the LCD touch panel showing the four drying modes and remaining time display.

Efficient Drying

The 1400W power allows the dryer to reach a maximum temperature of 140°F, ensuring quick and efficient drying. The forward and reverse tumbling action helps prevent tangles, reduces wrinkles, and keeps clothes soft and fluffy. For quicker drying, limit the load to 14.5 pounds (wet clothes).

POWERFUL AND FAST DRYING



Image: Infographic highlighting the dryer's powerful drying capabilities.

Safety Features

The transparent door window allows you to monitor the drying process. For added safety, the dryer automatically stops if the door is opened while the machine is running.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your dryer.

Lint Filter Cleaning

The multi-filter system effectively traps lint. It is recommended to clean the lint filter after each use to maintain

drying efficiency and prevent lint buildup.



Image: Detail of the air intake filter, crucial for trapping lint.

Stainless Steel Drum

The stainless steel drum is durable and resistant to rust. Wipe it clean periodically with a soft, damp cloth.

TROUBLESHOOTING

If you encounter any issues with your Feelfunn Portable Clothes Dryer, please refer to the following common problems and solutions:

Problem	Solution
Dryer does not start	<ul style="list-style-type: none"> ◦ Ensure the power cord is firmly inserted. ◦ Check the power outlet. ◦ Close the door completely. ◦ Try again after a few minutes.
Laundry is not thoroughly dried	<ul style="list-style-type: none"> ◦ Clean the lint filter. ◦ Reduce the amount of laundry in the drum (do not exceed 14.5 lbs wet clothes). ◦ Select a longer drying time or a higher heat setting. ◦ Ensure proper ventilation for the exhaust pipe.
Drum does not turn	<ul style="list-style-type: none"> ◦ Check for obstructions inside the drum. ◦ Ensure the dryer is on a flat, stable surface. ◦ Contact customer support if the issue persists.

SPECIFICATIONS

Feature	Detail
Brand Name	Feelfunn
Model Info	2.65 Cu.Ft (Touchpad Digital Control)
Item Weight	48.4 pounds
Product Dimensions	23.6 x 17.6 x 27 inches
Capacity	2.65 Cubic Feet
Voltage	120 Volts
Material Type	Stainless Steel
Form Factor	Freestanding, Front Load
Color	White

WARRANTY AND SUPPORT

The Feelfunn 2.65 Cu.Ft Portable Clothes Dryer comes with a 1-year warranty.

If you encounter any issues or require assistance, please do not hesitate to contact our professional after-sales team. We are committed to providing the best possible support.

For support, please refer to the contact information provided in your user manual or visit the official Feelfunn store.

© 2025 Feelfunn. All rights reserved.