Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FOSSIBOT S2

FOSSIBOT S2 Cell Phone User Manual

Model: S2

1. Introduction

Welcome to the FOSSIBOT S2 Cell Phone User Manual. This guide provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your new smartphone. The FOSSIBOT S2 is an unlocked Android 14 smartphone designed for seamless performance, featuring a vibrant 6.72" FHD+ display, powerful 20GB RAM, 256GB internal storage (expandable up to 1TB), a long-lasting 5000mAh battery, and advanced 50MP rear and 16MP front cameras. Enjoy enhanced security with face and fingerprint unlock, and stay connected with 4G capabilities and NFC support.

2. What's in the Box

Please check the contents of your FOSSIBOT S2 package. If any items are missing or damaged, please contact customer support.

- FOSSIBOT S2 Cell Phone
- Power Adapter
- USB Cable
- Protective Case (often included)
- SIM Ejector Tool (not explicitly listed but standard)



Figure 2.1: FOSSIBOT S2 Cell Phone (Blue variant shown).

3. Product Features

3.1 Powerful Performance & Storage

The FOSSIBOT S2 is equipped with a MediaTek G85 chipset and a robust 20GB RAM (8GB physical + 12GB virtual) for smooth, lag-free performance across all applications. With 256GB of internal storage, expandable up to 1TB via TF card, you have ample space for all your apps, photos, videos, and files.



Figure 3.1: Illustration of the FOSSIBOT S2's memory and storage capabilities.





Figure 3.2: Depiction of the powerful MediaTek G85 processor and 1TB expandable storage.

3.2 Immersive FHD+ Display

Experience vivid visuals on the 6.72" FHD+ In-cell display with a resolution of 1080 x 2340. This expansive screen offers excellent clarity and vibrant colors, making it ideal for media consumption, gaming, and browsing.



Figure 3.3: The FOSSIBOT S2's large and broad vision display.



Figure 3.4: Detailed specifications of the 6.72-inch FHD+ display.

3.3 Advanced Camera System

Capture stunning moments with the FOSSIBOT S2's 50MP main rear camera and 16MP front camera. The advanced Sony IMX471 sensor ensures crystal-clear and vibrant photos, even in challenging lighting conditions. Various modes like Beauty Mode, Night Mode, and Panorama Camera enhance your photography experience.




Figure 3.5: Overview of the FOSSIBOT S2's camera system and features.



Figure 3.6: Dual cameras for capturing beautiful moments.

3.4 Long-Lasting Battery & Fast Charging

The 5000mAh battery provides extended usage, ensuring your phone lasts all day. With 18W fast charging support, you can quickly recharge and get back to your activities. The phone also supports OTG reverse charging.



Figure 3.7: Battery and charging features of the FOSSIBOT S2.




Figure 3.8: Estimated usage times for the 5000mAh battery.

3.5 Android 14 OS & Security

Running on Android 14, the FOSSIBOT S2 offers a smooth, intuitive user experience with enhanced security features and customizable options. Unlock your device quickly and securely using both face recognition and the side-mounted fingerprint sensor.



Figure 3.9: The FOSSIBOT S2 running on Android 14.



Figure 3.10: Face and fingerprint unlock options for enhanced security.

3.6 Connectivity & Design

The FOSSIBOT S2 supports 4G cellular technology and is unlocked for all carriers. It features three card slots, allowing for two SIM cards and one TF card simultaneously. The phone boasts a slim 8.6mm design and weighs 201g, making it comfortable to hold and use. It also includes NFC for convenient mobile payments and a four-positioning system (GPS+GLONASS+GALILEO+Beidou) for accurate navigation.



Figure 3.11: An overview of the FOSSIBOT S2's key features including design, camera, storage, display, battery, and connectivity.




Figure 3.12: The FOSSIBOT S2's triple card slot design.



Figure 3.13: The FOSSIBOT S2's accurate four-positioning system for navigation.

4. Setup Guide

4.1 Inserting SIM/TF Card

1. Locate the SIM card tray on the side of your FOSSIBOT S2.
2. Insert the SIM ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM card(s) and/or TF card into the designated slots on the tray. Ensure they are correctly oriented.
4. Carefully push the tray back into the phone until it is flush with the side.

4.2 Initial Power On & Setup

1. Press and hold the Power button (located on the side) until the FOSSIBOT logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and accept the terms and conditions.
3. Sign in with your Google account to access Google services, restore backups, and download apps.
4. Set up your preferred screen lock method: PIN, Pattern, Password, Fingerprint, or Face Unlock.

5. Operating Instructions

5.1 Basic Navigation

- **Home Screen:** Swipe left or right to navigate between home screens.
- **App Drawer:** Swipe up from the bottom of the screen to access all installed applications.
- **Notifications & Quick Settings:** Swipe down from the top of the screen to view notifications and quick settings toggles.
- **Recent Apps:** Swipe up and hold from the bottom of the screen (or tap the square navigation button if enabled) to see recently used apps.

5.2 Making Calls & Sending Messages

- **Calls:** Open the Phone app, dial the number, and tap the call icon.
- **Messages:** Open the Messages app, tap 'Start chat', enter the recipient's number or select from contacts, type your message, and tap send.

5.3 Camera Usage

- Open the Camera app from your home screen or app drawer.
- Switch between front and rear cameras using the camera switch icon.
- Select different modes (Photo, Video, Portrait, Night, Pro, etc.) by swiping across the bottom of the viewfinder.
- Tap the shutter button to take a photo or start/stop video recording.

5.4 Internet & Connectivity

- **Wi-Fi:** Go to Settings > Network & internet > Wi-Fi to connect to available networks.
- **Mobile Data:** Ensure mobile data is enabled in Quick Settings or Settings > Network & internet > Mobile network.
- **NFC:** Enable NFC in Settings > Connected devices > Connection preferences > NFC for contactless payments and data transfer.

6. Maintenance

- **Battery Care:** Avoid extreme temperatures. Do not let the battery completely drain frequently. Use the provided charger for optimal charging.
- **Software Updates:** Regularly check for system updates in Settings > System > System update to ensure your device has the latest features and security patches.
- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid harsh chemicals or abrasive materials.
- **Storage Management:** Periodically clear cache, delete unnecessary files, and uninstall unused apps to maintain optimal performance.

7. Troubleshooting

Issue	Possible Solution
Phone not turning on	Ensure the battery is charged. Press and hold the Power button for 10-15 seconds to force restart.
Apps crashing or freezing	Clear app cache (Settings > Apps > [App Name] > Storage & cache > Clear cache). Restart the phone. Update the app or system software.
Poor network signal	Check SIM card insertion. Restart the phone. Try moving to an area with better coverage. Contact your carrier.
Fingerprint/Face Unlock not working	Ensure your finger/face is clean and properly positioned. Re-register your fingerprint/face in Settings > Security.
Battery drains quickly	Reduce screen brightness. Close background apps. Disable unnecessary features like GPS, Wi-Fi, Bluetooth when not in use. Check battery usage in Settings.

8. Specifications

Feature	Detail
Model Name	S2
Operating System	Android 14
CPU Model	MediaTek G85 (Kompanio 800T in some specs)
RAM Memory Installed Size	8 GB (expandable to 20GB virtual)

Feature	Detail
Memory Storage Capacity	256 GB (expandable up to 1TB TF)
Screen Size	6.72 Inches
Resolution	1080 x 2340
Battery Capacity	5000 Milliamp Hours
Rear Camera	50MP
Front Camera	16MP
Wireless Carrier	Unlocked for All Carriers
Cellular Technology	4G
Human Interface Input	Touchscreen
Product Dimensions	6.57 x 3.03 x 0.34 inches
Item Weight	7.1 ounces (201 Grams)
Connectivity Technologies	Wireless, NFC
GPS	True (GPS+GLONASS+GALILEO+Beidou)

9. Warranty and Support

The FOSSIBOT S2 comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims.
For technical assistance, troubleshooting, or warranty inquiries, please contact FOSSIBOT customer service. Our team is available 24/7 to provide prompt support.

- **Customer Service:** Refer to the contact information provided in your product packaging or visit the official FOSSIBOT website.
- **Online Resources:** Check the FOSSIBOT official store or support page for FAQs, software updates, and additional resources.

© 2025 FOSSIBOT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DP6QN2PV

More documents and user manuals: **https://manuals.plus/**