

[Manuals.plus](#) /

› [Tenpmas](#) /

› Tenpmas 10.26" Wireless Apple CarPlay & Android Auto Screen User Manual (Model T360S-1128-US5)

Tenpmas T360S-1128-US5

Tenpmas 10.26" Wireless Apple CarPlay & Android Auto Screen User Manual

Model: T360S-1128-US5

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, maintenance, and troubleshooting of your Tenpmas 10.26-inch Wireless Apple CarPlay and Android Auto Screen. Please read this manual thoroughly before using the product to ensure proper function and safety.



Image 1.1: The Tenpmas 10.26-inch display unit with its suction cup mounting bracket. Also shown are the included backup camera and the OEM-style bracket.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 10.26-inch Display Unit
- Suction Cup Bracket
- Original Style Bracket
- AHD High-Definition Reversing Camera (Rear Lens)
- 19.7ft Extension Cable for Rear Camera
- Car Charger (Power Cable)
- Instruction Manual

Accessories List & Installation Diagram

Easy to setup, no longer than 30 minutes



Image 2.1: Visual representation of the accessories included in the package.

3. SETUP AND INSTALLATION

The Tenpmas 10.26-inch screen offers two primary mounting options: the original style bracket and a retractable suction cup bracket. Installation is designed to be completed within 30 minutes.

3.1 Mounting the Display Unit

Choose between the original style bracket for a lower profile, integrated look, or the suction cup bracket for flexible positioning on your dashboard or windshield.

1. **Original Style Bracket:** Attach the display to this bracket. Position it on your dashboard to reduce line of sight obstruction.
2. **Suction Cup Bracket:** Attach the display to the suction cup bracket. Clean the desired mounting surface (dashboard or windshield) thoroughly. Press the suction cup firmly against the surface and engage the locking mechanism. Adjust the screen angle for optimal viewing.



Image 3.1: Illustration of the unique OEM style bracket and how it reduces line of sight obstruction compared to a higher suction cup mount.

3.2 Power Connection

Connect the provided car charger to the display unit's power input and then into your vehicle's 12V power outlet (cigarette lighter socket).

3.3 Rear View Camera Installation

The included AHD high-definition reversing camera requires connection for automatic switching to the rear camera screen when reversing.

1. Mount the rear lens camera at the back of your vehicle, ensuring a clear view.
2. Connect the rear lens to the 19.7ft extension cable.
3. Route the extension cable from the rear camera to the display unit, connecting it to the AV IN port.
4. Connect the reversing lamp positive lead from the camera wiring to your vehicle's reversing light power source. This enables automatic camera activation.



Image 3.2: Simplified diagram showing the connections for the display unit and rear view camera.

4. OPERATING INSTRUCTIONS

4.1 Wireless Apple CarPlay & Android Auto

The device supports wireless Apple CarPlay and Android Auto for seamless smartphone integration.

- Ensure your smartphone's Bluetooth and Wi-Fi are enabled.
- On the display unit, select either Apple CarPlay or Android Auto.
- Follow the on-screen prompts to pair your smartphone. Once paired, your phone will automatically connect upon subsequent power-ups.

- Access navigation, calls, messages, and music directly from the screen.



Image 4.1: Overview of the wireless Apple CarPlay and Android Auto interfaces.

4.2 Voice Control & GPS Navigation

Utilize voice commands for navigation and other functions through Siri or Google Assistant.

- Activate Siri or Google Assistant via the display or your smartphone.
- Speak commands such as "Hey Siri, call [contact name]" or "Hi Google, navigate home."
- Real-time GPS navigation is provided through your smartphone's mapping applications, eliminating the need for separate map updates.

Unique OEM Style Bracket

Just like the original accessories of the car, very beautiful!

Real photos of installation



Reduce line of sight obstruction




Image 4.2: Display showing active GPS navigation and voice command functionality.

4.3 Audio Output Options

The unit offers multiple ways to output audio to your vehicle's sound system.

- **Dual Bluetooth Stereo Output:** Connect the display to your car's stereo via Bluetooth for a stable, lossless audio experience.
- **FM Wireless Transmission:** Transmit audio to your car's FM radio by tuning both devices to the same frequency.
- **AUX Output:** Connect the display to your car's AUX input using an AUX cable (not included) for direct audio transfer.
- **Built-in Speaker:** The unit also features a built-in speaker for direct audio playback.



Image 4.3: Visual guide to the four available audio output options.

4.4 Phone Mirror Link

Mirror your iOS or Android phone screen to the 10.26-inch display.

- Select the Mirror Link function on the display.
- Follow the instructions to connect your smartphone via Airplay (iOS) or Android Cast (Android).
- Content from your phone, such as YouTube or TikTok videos, will be displayed on the screen. Note that Netflix is not supported, and horizontal screen playback depends on the specific application.



5. MAINTENANCE

To ensure the longevity and optimal performance of your Tenpmas display, follow these maintenance guidelines:

- **Cleaning the Screen:** Use a soft, lint-free cloth to gently wipe the screen. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaner. Avoid harsh chemicals or abrasive materials.
- **Protective Film:** The product comes with a removable protective film. If the screen appears scratched or dirty upon receipt, you may peel off the outer layer of this film.
- **Bracket Stability:** Periodically check the stability of your chosen mounting bracket. Re-secure the suction cup if it loses adhesion.
- **Cable Connections:** Ensure all cables are securely connected and not pinched or damaged.

6. TROUBLESHOOTING

If you encounter issues with your device, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not power on.	No power supply; faulty car charger.	Ensure the car charger is securely plugged into both the device and the vehicle's 12V outlet. Check if the vehicle's 12V outlet is functional.
Wireless CarPlay/Android Auto fails to connect.	Bluetooth/Wi-Fi off; incorrect pairing; interference.	Verify Bluetooth and Wi-Fi are active on your smartphone. Forget the device in your phone's Bluetooth settings and re-pair. Move away from strong signal interference.
No audio or poor audio quality.	Incorrect audio output setting; FM interference; loose AUX cable.	Check the selected audio output method (Bluetooth, FM, AUX). If using FM, try a different frequency. Ensure AUX cable is fully inserted.
Screen display is unclear or pixelated.	Protective film still on; low quality source.	Remove the outer protective film if present. Ensure the content being displayed is of sufficient resolution.
Suction cup mount loses adhesion.	Dirty surface; temperature changes; worn suction cup.	Clean the mounting surface and the suction cup thoroughly. Re-apply the suction cup firmly. Consider using the OEM style bracket if frequent detachment occurs.
Backup camera not displaying.	Loose cable; incorrect wiring; camera malfunction.	Check all connections, especially the AV IN and the reversing lamp positive lead. Ensure the vehicle is in reverse gear.

7. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Number	T360S-1128-US5
Display Size	10.26 Inches
Item Weight	2.27 pounds
Package Dimensions	11.26 x 5.63 x 4.41 inches
Connectivity Technology	Bluetooth, Wi-Fi
Special Features	Wireless Apple CarPlay, Android Auto, Phone Mirror Link, GPS Navigation, Voice Control
Audio Output Mode	Stereo (Bluetooth, FM, AUX, Built-in Speaker)
Mounting Type	Dashboard Mount, Suction Cup Mount
Included Components	Touchscreen, Rear View Camera, Cables, Brackets
Batteries	1 Lithium Polymer battery required (included)

8. WARRANTY INFORMATION

This Tenpmas product is covered by a **1-Year Manufacturer Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or improper installation.

Please retain your proof of purchase for warranty claims.

9. CUSTOMER SUPPORT

For technical assistance, warranty claims, or inquiries regarding customized boot icon services, please refer to the after-sales contact information provided in the physical instruction manual included with your product.

You may also visit the official Tenpmas website for additional support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DP6VKVY7>

More documents and user manuals: <https://manuals.plus/>