

[manuals.plus](#) /

› [EUHOMY](#) /

› [Euhomy Portable Clothes Dryer \(Model CD-9-01-VC\) User Manual](#)

## EUHOMY CD-9-01-VC

# Euhomy Portable Clothes Dryer User Manual

Model: CD-9-01-VC

## 1. INTRODUCTION

Thank you for choosing the Euhomy Portable Clothes Dryer. This manual provides essential information for the safe and efficient operation, installation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before use and retain it for future reference.



Image 1.1: Front view of the Euhomy Portable Clothes Dryer.

## 2. SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, follow these basic precautions:

- Read all instructions before using the appliance.
- Ensure the dryer is properly grounded.
- Do not dry articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, or other flammable or explosive substances.
- Do not allow children to play on or in the appliance. Close supervision is necessary when the appliance is used near children.
- Do not reach into the appliance if the drum is moving.
- Clean the lint filter before or after each load.

- Do not install or store this appliance where it will be exposed to the weather.
- Do not repair or replace any part of the appliance or attempt any servicing unless specifically recommended in this manual.
- Always disconnect the appliance from the power supply before cleaning or performing any maintenance.

### 3. PACKAGE CONTENTS

Verify that all components are present upon unpacking:

- Euhomy Portable Clothes Dryer Unit
- Exhaust Hose
- User Manual

### 4. PRODUCT OVERVIEW

The Euhomy Portable Clothes Dryer features a compact design with a stainless steel drum, an LCD display, and a 1300W heating element for efficient drying. It is designed for versatility in various living spaces.

# COMPACT LAUNDRY DRYER




Image 4.1: Key features of the dryer, including the lint filter, portable handle, transparent door, and safety auto-stop mechanism.

## Key Features:


- **High Performance:** 1300W power, reaching up to 140°F for quick drying.
- **Multi-function Drying Modes:** Smart, Strong, ECO, and Normal.
- **Easy Operation:** Intuitive LCD display and adjustable drying times (20-200 minutes).
- **Stainless Steel Drum:** Prevents clothes tangling and ensures fluffiness.
- **Safety Features:** 105° wide-angle door opening, automatic stop when door is opened, cotton lint filter.
- **Portable Design:** Embedded handle for easy movement.

## 5. SETUP AND INSTALLATION

The dryer offers flexible installation options to suit your space.

# PORTABLE DRYER


Suitable for multiple scenarios



**Freestanding**



**Stacked**



**Suspension type**



Image 5.1: Installation options: freestanding, stacked on a washing machine, or wall-mounted.

## Placement Options:

- Countertop:** Place on a stable, flat surface.
- Solid Ground:** Position on a firm, level floor.
- Stacked:** Can be stacked on a compatible washing machine (bracket not included).
- Wall-Mounted:** Can be mounted on a wall (bracket not included).

## Exhaust Hose Installation:

Connect the provided exhaust hose to the dryer's exhaust port. Ensure the hose is directed to an outdoor vent or a suitable lint trap system to prevent moisture buildup and ensure efficient drying.

## 6. OPERATING INSTRUCTIONS

Follow these steps to operate your dryer:

- Load Clothes:** Open the dryer door and load clothes. Do not overload the dryer; ensure clothes can tumble freely. The maximum capacity is 12.5 pounds (wet clothes).
- Close Door:** Securely close the dryer door. The dryer will not operate if the door is open.
- Select Drying Mode:** Use the LCD control panel to select your desired drying mode.
- Adjust Time (if applicable):** For certain modes, you can adjust the drying time between 20-200 minutes.
- Start Cycle:** Press the Start button to begin the drying cycle.



Image 6.1: LCD Control Panel displaying various drying modes and settings.

## 7. DRYING MODES

The dryer offers four distinct drying modes:

- **Strong:** This mode provides full power heating, suitable for larger items or loads requiring maximum heat to dry quickly.
- **Intelligent (Smart):** This mode automatically detects the dryness level of your clothes and adjusts the drying time accordingly, stopping when clothes are dry. Recommended for most items.
- **ECO:** Designed for energy saving and odor removal. The first 140 minutes operate with cold air. After 140 minutes, hot air is introduced to dry small pieces of clothing.
- **Normal:** This mode uses half-power heating and is suitable for clothes that need ironing or for drying smaller loads.

## 8. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and longevity of your dryer.

### Lint Filter Cleaning:

The cotton filter effectively collects lint. Clean the lint filter before or after each load to maintain drying efficiency and prevent lint buildup. To clean, remove the filter from the drum and gently brush off accumulated lint. Ensure the filter is completely dry before reinserting.



Image 8.1: Illustration of the lint filter and its function.

### Exterior Cleaning:

Wipe the exterior of the dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.

## 9. TROUBLESHOOTING

If you encounter issues with your dryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Dryer does not start	Power cord unplugged; Door not closed properly; Circuit breaker tripped.	Ensure power cord is securely plugged in; Close door firmly; Reset circuit breaker.
Clothes not drying completely	Overloaded dryer; Lint filter clogged; Incorrect drying mode selected; Exhaust hose blocked.	Reduce load size; Clean lint filter; Select appropriate drying mode; Check and clear exhaust hose.
Dryer is noisy	Dryer not level; Foreign objects in drum.	Adjust leveling legs; Check drum for loose items.
Dryer stops during cycle	Door opened; Overheating protection activated.	Ensure door is closed; Allow dryer to cool down, then restart. Check for blocked vents.

## 10. SPECIFICATIONS

Technical details of the Euhomy Portable Clothes Dryer (Model CD-9-01-VC):



● **Voltage: 120V**

● **Ratedinput: 1300W**

● **Net weight: 50 Lbs**

● **Frequency.60Hz**

● **Dimension: 28 x 24 x 18 in**

Image 10.1: Dimensions and electrical specifications of the dryer.

- **Model:** CD-9-01-VC
- **Capacity:** 2.5 Cubic Feet (approx. 12.5 lbs wet clothes)
- **Rated Input:** 1300W
- **Voltage:** 120 Volts
- **Frequency:** 60Hz
- **Item Weight:** 50.5 pounds
- **Product Dimensions:** 18 x 24 x 28 inches (Depth x Width x Height)
- **Material:** Acrylonitrile Butadiene Styrene (ABS), Stainless Steel drum
- **Form Factor:** Front Load



- **Special Features:** Adjustable Leveling Legs
- **Certifications:** DOE, ETL

## 11. WARRANTY AND SUPPORT

Euhomy products are manufactured to high-quality standards. For warranty information, product support, or service inquiries, please refer to the warranty card included with your purchase or visit the official Euhomy website. Please have your model number (CD-9-01-VC) and purchase date available when contacting support.

© 2024 Euhomy. All rights reserved.


### Related Documents - CD-9-01-VC

 The image shows the front cover of the Euhomy CD-7 Compact Dryer User Manual and Guide. It features a white background with a blue header containing the text 'SKU: CD005-160WH-USZX' and 'COMPACT DRYER Instruction Manual'. Below the header is a line drawing of a compact white front-loading dryer. At the bottom of the cover, there is a small note: 'Congratulations on purchasing your new product. To receive the best service, please keep this manual and the product serial number for future reference. To register your product, visit <a href="#">www.euhomy.com</a> . For any questions, contact us at <a href="#">support.euhomy.com</a> '.	<p><a href="#">Euhomy CD-7 Compact Dryer: User Manual and Guide</a></p> <p>User manual for the Euhomy CD-7 compact portable clothes dryer with exhaust duct. Learn about features, operation, safety, and maintenance.</p>
 The image shows the front cover of the Euhomy Compact Dryer CD002-265WH-USEH Instruction Manual & User Guide. It features a white background with a blue header containing the text 'SKU: CD002-265WH-USEH' and 'COMPACT DRYER Instruction Manual'. Below the header is a line drawing of a compact white front-loading dryer. At the bottom of the cover, there is a small note: 'Congratulations on purchasing your new product. To receive the best service, please keep this manual and the product serial number for future reference. To register your product, visit <a href="#">www.euhomy.com</a> . For any questions, contact us at <a href="#">support.euhomy.com</a> '.	<p><a href="#">Euhomy Compact Dryer CD002-265WH-USEH: Instruction Manual &amp; User Guide</a></p> <p>Comprehensive instruction manual for the Euhomy Compact Dryer (Model CD002-265WH-USEH). Includes setup, operation, maintenance, troubleshooting, and warranty information.</p>
 The image shows the front cover of the Euhomy Compact Dryer Instruction Manual. It features a white background with a blue header containing the text 'SKU: CD007-250WH-USEH' and 'COMPACT DRYER Instruction Manual'. Below the header is a line drawing of a compact white front-loading dryer. At the bottom of the cover, there is a small note: 'Congratulations on purchasing your new product. To receive the best service, please keep this manual and the product serial number for future reference. To register your product, visit <a href="#">www.euhomy.com</a> . For any questions, contact us at <a href="#">support.euhomy.com</a> '.	<p><a href="#">Euhomy Compact Dryer Instruction Manual</a></p> <p>This manual provides comprehensive instructions for the Euhomy Compact Dryer, including safety precautions, installation, setup, operation, maintenance, troubleshooting, and warranty information. Learn how to properly use and care for your compact dryer to ensure optimal performance and longevity.</p>
 The image shows the front cover of the Euhomy CD-13 Portable Cooler User Manual and Guide. It features a white background with a blue header containing the text 'SKU: ZX-CD-13-AZ-HM' and 'COMPACT DRYER Instruction Manual'. Below the header is a line drawing of a compact white portable cooler. At the bottom of the cover, there is a small note: 'Congratulations on purchasing your new product. To receive the best service, please keep this manual and the product serial number for future reference. To register your product, visit <a href="#">www.euhomy.com</a> . For any questions, contact us at <a href="#">support.euhomy.com</a> '.	<p><a href="#">Euhomy CD-13 Portable Cooler User Manual and Guide</a></p> <p>Comprehensive user manual for the Euhomy CD-13 portable cooler. Includes setup, operation, safety guidelines, maintenance, troubleshooting, and specifications for optimal use.</p>



### [Euhomy CD001-150WH-USEH Compact Dryer Instruction Manual](#)

Comprehensive instruction manual for the Euhomy CD001-150WH-USEH Compact Dryer. Learn about safety precautions, installation, setup, operation, maintenance, troubleshooting, and warranty.



### [EUHOMY CD-7 Refrigerator User Manual and Support Information](#)

Official user manual and support contact details for the EUHOMY CD-7 refrigerator. Find model information, SKU, and customer service contacts for assistance.