

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Sportneer](#) /

› [Sportneer 3-4 Season Sleeping Bag Instruction Manual \(Model Y21-80501-04-HQUK\)](#)

Sportneer Y21-80501-04-HQUK

Sportneer 3-4 Season Sleeping Bag Instruction Manual

Model: Y21-80501-04-HQUK

INTRODUCTION

Welcome to your Sportneer 3-4 Season Sleeping Bag. This manual provides essential information for the proper use, care, and maintenance of your sleeping bag, designed for adults and kids for cold weather camping, hiking, and travel. Please read these instructions carefully before use to ensure optimal performance and longevity of your product.



Image: The Sportneer 3-4 Season Sleeping Bag, showcasing its design and available color variations, along with its compact carry bag.

PRODUCT FEATURES

- **Season Versatility:** Suitable for 3-4 seasons (spring, summer, fall, and winter) with a comfort temperature range of 50-80°F (10-25°C).
- **User-Friendly Design:** Features a two-way separating zipper at the bottom for foot freedom and a semi-circular hood with an adjustable drawstring for warmth.
- **Generous Size:** Measures 31.5 x 87 inches (80 x 220 cm), accommodating various heights and sizes.
- **High-Quality Materials:** Constructed with a 190T polyester taffeta outer layer, 190T polyester

pongee inner lining, and polyester filling for durability and comfort.

- **Lightweight & Portable:** Weighs approximately 3.3 lbs (1.5 kg) and includes a carry bag for easy storage and transport.
- **Water-Repellent Fabric:** The outer material is water-repellent, allowing for easy cleaning of light moisture.

SPORTNEER 3-SEASON SLEEPING BAG

Designed for adults & Kids




Image: A detailed diagram illustrating the dimensions, packed size, weight, and seasonal suitability of the sleeping bag.

SETUP AND USAGE

Unpacking and Initial Use

1. Remove the sleeping bag from its carry bag. It will expand to its full size.

2. Lay the sleeping bag flat on your desired sleeping surface.

Adjusting for Comfort and Warmth

- **Adjustable Hood:** The semi-circular hood features an adjustable drawstring. Pull the drawstring to tighten the hood around your head, retaining warmth in colder conditions. Loosen for more ventilation.
- **Two-Way Zipper:** The main zipper is a two-way design, allowing you to open it from either the top or the bottom. This provides flexibility for ventilation and ease of entry/exit.
- **Foot Freedom:** A separate zipper at the bottom allows you to open the foot section independently. This feature is useful for temperature regulation, allowing your feet to cool down without fully unzipping the entire bag.



FAMILY OUTDOOR CAMPING



Summer Camp



Hiking



Car

Image: Details of the adjustable drawstring hood and the two-way zipper for enhanced comfort and functionality.

Converting to a Blanket

The sleeping bag can be fully unzipped to convert into a flat blanket, providing versatility for warmer nights or as an extra layer.



FREE YOUR FEET

Free your feet for better temperature control

Image: Illustrates the bottom zipper feature, allowing for foot ventilation and temperature control.

Product Video Guide

Your browser does not support the video tag.

Video: An official Sportneer video demonstrating the features and usage of the 3-Season Sleeping Bag, including unpacking, material details, and adjustable elements.

MAINTENANCE

Cleaning Instructions

- **Machine Washable:** The sleeping bag is machine washable. For best results, it is suggested to use a front-loading washing machine. Use a gentle cycle with cold water and a mild detergent.
- **Drying:** Tumble dry on low heat or air dry. Ensure the sleeping bag is completely dry before storing to prevent mildew.
- **Spot Cleaning:** For minor spills or dirt, the water-repellent fabric can be easily wiped clean with a damp cloth.

Sportneer

WATER-REPELLENT FABRIC

POLYESTER FIBER

SOFT AND SKIN-FRIENDLY FABRIC

WATER-REPELLENT FABRIC
Easily wipe-clean with a damp cloth

Image: Illustrates the water-repellent nature of the fabric, making it easy to clean with a damp cloth.

SPECIFICATIONS

Feature	Detail
Brand	Sportneer
Model Number	Y21-80501-04-HQUK
Color	Black + Light Gray
Occupancy	1 Person
Shape	Semi-Rectangular
Seasons	All Seasons (3-4 Season Comfort)
Temperature Rating	50 to 80 degrees Fahrenheit (10-25°C)
Age Range	Adult
Sport	Camping & Hiking
Special Features	Adjustable drawstring, Bottom zip closure, Hood design, Two-way zip
Outer Material	190T Polyester Taffeta
Inner Material	190T Polyester Pongee
Fill Material	Polyester
Product Dimensions (L x W)	87"L x 31.5"W (220cm x 80cm)
Item Weight	3.3 lbs (1.5 Kilograms)
Maximum Height Recommendation	7 Feet

TROUBLESHOOTING

- **Zipper Snagging:** If the zipper snags, gently pull the fabric away from the zipper teeth while slowly moving the slider. Avoid forcing the zipper.
- **Feeling Cold:** Ensure the hood drawstring is tightened around your head and the bottom zipper is fully closed. Consider wearing appropriate sleepwear for the ambient temperature.
- **Difficulty Packing:** To pack the sleeping bag efficiently, start by folding it lengthwise, then roll it tightly from the foot end towards the head end, compressing as you roll. Place it into the carry bag.

WARRANTY AND SUPPORT

For warranty information, product support, or any inquiries regarding your Sportneer Sleeping Bag, please refer to the official Sportneer website or contact Sportneer customer service directly. Keep your purchase

receipt as proof of purchase.