

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GEARit](#) /

› [GEARit Smart Video Doorbell Camera User Manual](#)

## GEARit GI-CAM-DRB-WH-001

# GEARit Smart Video Doorbell Camera User Manual

Model: GI-CAM-DRB-WH-001 | Brand: GEARit

## INTRODUCTION

Thank you for choosing the GEARit Smart Video Doorbell Camera. This wireless doorbell camera provides advanced security features including 2K QHD video resolution, motion detection, two-way audio, and a long-lasting rechargeable battery. Designed for easy setup and reliable performance, it ensures you stay connected to your home's entryway. This manual provides detailed instructions for setting up, operating, and maintaining your new doorbell camera. Please read it thoroughly before use to ensure proper functionality and safety.

## PRODUCT FEATURES

### 2K QHD Video Resolution

#### Crystal-Clear 2K QHD Resolution


View live footage in sharp HD quality from your phone, no matter where you are.



Capture every detail with razor-sharp 2K QHD (4MP) resolution. This ensures clear and crisp video footage, allowing for better identification of visitors and events


at your doorstep, day or night.

## Motion & Sound Detection



Receive real-time push alerts on your smartphone when motion or sound is detected. This feature helps you stay informed about activity at your front door, enhancing your home security.

## Two-Way Audio Communication



Communicate directly with visitors, delivery personnel, or family members at your door using the built-in microphone and speaker. This allows for convenient and secure interaction from anywhere.

## Advanced Night Vision

## Advanced Night Vision

Capture every detail, even in low lights



GEARit

Equipped with advanced night vision capabilities, the doorbell camera provides clear visibility even in complete darkness, ensuring continuous monitoring and security around the clock.

## IP64 Weatherproof Design

### IP64 Weatherproof Protection

Built to withstand dust, rain, and splashes—ideal for year-round outdoor protection



GEARit

The doorbell camera is built with an IP64 weather-proof rating, making it resistant to dust, rain, and splashes. This ensures reliable operation in various outdoor conditions throughout the year.

## Rechargeable Battery & Local Storage



Enjoy up to 6 months of battery life on a single charge, providing wireless convenience. The camera supports local storage via a microSD card (up to 256GB, not included) for secure recording of events.

### Product Overview Video

Your browser does not support the video tag.

This video provides a brief overview of the GEARit Smart Video Doorbell Camera, highlighting its key features such as 2K QHD video, human body detection, two-way audio, and secure local storage.

## SETUP GUIDE

---

### Package Contents

# Everything You Need

Control your baby monitor with the **AuraHome Control App**



GET IT ON  
Google Play

Download on the  
App Store



Doorbell Camera  
USB-C Cable  
Screwdriver  
Mounting Bracket

User Manual  
Screw Pack  
Wiring Pack  
Adhesive Tap



GEARit

Before you begin, ensure all components are present in the package:

- GEARit Smart Video Doorbell Camera
- USB Type-C Cable
- Screwdriver
- Mounting Bracket
- User Manual (this document)
- Screw Pack
- Wiring Pack (for optional wired installation)
- Adhesive Tape (for optional adhesive mounting)

## Installation Steps

1. **Charge the Battery:** Fully charge the doorbell camera using the provided USB Type-C cable before initial use. A full charge ensures optimal performance and battery life.
2. **Download the App:** Download the "AuraHome Control App" from the App Store (iOS) or Google Play Store

(Android). This app is essential for controlling and managing your doorbell camera.

### 3. Mount the Doorbell:

- **Screw Mounting:** Use the mounting bracket and screw pack to securely attach the doorbell to your desired location on the door frame or wall.
- **Adhesive Mounting:** For a drill-free option, use the included adhesive tape to attach the mounting bracket. Ensure the surface is clean and dry for strong adhesion.

4. **Connect to App:** Follow the in-app instructions to connect your doorbell camera to your home Wi-Fi network and pair it with your smartphone. This typically involves scanning a QR code displayed on your phone with the doorbell camera.
5. **Customize Settings:** Once connected, customize settings such as motion detection sensitivity, notification preferences, and video recording options within the AuraHome app.

## OPERATING INSTRUCTIONS

---

### Live View and Two-Way Audio

Open the AuraHome app on your smartphone to access the live video feed from your doorbell camera. From the live view, you can initiate two-way audio by tapping the microphone icon to speak with visitors, and hear their responses through the doorbell's speaker.

### Motion Detection and Alerts

The doorbell camera is equipped with motion and sound detection. When activity is detected, you will receive an instant push notification on your smartphone. Tap the notification to view the live feed or review recorded events.

You can adjust the sensitivity of motion detection in the app settings to minimize false alerts.

### Video Recording and Storage

The camera records video clips when motion or sound is detected. These clips are stored on a microSD card (if installed) or can be accessed via optional cloud storage services (subscription may be required).

To install a microSD card, locate the card slot on the back of the doorbell camera, typically under a protective cover. Insert the card gently until it clicks into place. Ensure the doorbell is powered off before inserting or removing the card.

### Night Vision

The doorbell camera automatically switches to night vision mode in low-light conditions, providing clear black-and-white video. No manual adjustment is required for this feature.

## MAINTENANCE

---

### Battery Charging

The doorbell camera features a rechargeable battery designed for long-term use. When the battery level is low, you will receive a notification via the AuraHome app. To recharge, simply remove the doorbell unit from its mounting bracket and connect it to a power source using the provided USB Type-C cable.

A full charge can last up to 6 months, depending on usage frequency and environmental factors.

### Cleaning

To maintain optimal performance and clear video quality, periodically clean the camera lens and the doorbell's exterior. Use a soft, damp cloth to gently wipe away dust and dirt. Avoid using harsh chemicals or abrasive materials that could damage the device.

## MicroSD Card Management

If you are using a microSD card for local storage, it is recommended to periodically review and manage your recorded footage. You can format the microSD card through the AuraHome app to clear old recordings and free up space. Ensure important footage is backed up before formatting.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Doorbell not connecting to Wi-Fi.	Incorrect Wi-Fi password, weak signal, or incompatible network (e.g., 5GHz only).	Double-check Wi-Fi password. Ensure the doorbell is within range of your 2.4GHz Wi-Fi network. Restart your router and the doorbell camera.
No motion detection alerts.	Motion detection disabled, sensitivity too low, or app notifications blocked.	Enable motion detection in the AuraHome app. Increase motion detection sensitivity. Check your phone's notification settings for the AuraHome app.
Poor video quality or blurry images.	Dirty lens, poor Wi-Fi signal, or insufficient lighting.	Clean the camera lens with a soft cloth. Ensure strong Wi-Fi signal at the doorbell's location. Verify night vision is activating in low light.
Two-way audio delay or distortion.	Network latency, weak Wi-Fi signal, or app issue.	Ensure a stable and strong Wi-Fi connection. Close and reopen the AuraHome app. Check for app updates.
Battery drains quickly.	Frequent motion detection, high live view usage, or extreme temperatures.	Reduce motion detection sensitivity if receiving too many alerts. Limit frequent live view access. Ensure the doorbell is not exposed to extreme hot or cold temperatures for prolonged periods.

## SPECIFICATIONS

Feature	Detail
Model Number	GI-CAM-DRB-WH-001
Video Resolution	2K QHD (4MP)
Power Source	Rechargeable Battery (up to 6 months)
Weather Resistance	IP64 Weather-Proof
Audio	Two-Way Audio
Storage Options	MicroSD Card (up to 256GB, not included), Cloud Storage (optional)


Feature	Detail
Connectivity	Wireless (Wi-Fi 2.4GHz)
Dimensions (L x W x H)	5.63 x 2.03 x 2.03 inches
Item Weight	11.7 ounces (0.73 Pounds)
Manufacturer	GEARit
Country of Origin	China

## WARRANTY AND SUPPORT

GEARit products are designed for reliability and performance. For specific warranty details regarding your Smart Video Doorbell Camera, please refer to the warranty information provided with your purchase or visit the official GEARit website. For technical support, troubleshooting assistance, or any inquiries about your product, please contact GEARit customer service. You can often find contact information on the official brand website or within the AuraHome app. An official User Manual PDF is also available for download: [Download User Manual PDF](#)

© 2025 GEARit. All rights reserved.

## Related Documents - GI-CAM-DRB-WH-001

	<a href="#">GEARit Smart Doorbell GI-CAM-DRB-WH-001 User Manual</a> User manual for the GEARit Smart Doorbell (Model GI-CAM-DRB-WH-001), providing detailed instructions on package contents, installation, app setup, Wi-Fi connection, product specifications, and warranty information.
	<a href="#">GEARit 4K 2-Channel Dash Cam User Manual</a> Comprehensive user manual for the GEARit 4K 2-Channel Dash Cam with Color Display. Learn about installation, setup, features, settings, and troubleshooting.
	<a href="#">GEARit Wireless Qi2 10,000 mAh Power Bank - Black User Manual</a> User manual for the GEARit Wireless Qi2 10,000 mAh Power Bank in Black (Model GI-PB10K-C2Q12-BK). Includes product specifications, package contents, operating instructions, safety warnings, and warranty information.
	<a href="#">GEARit Sport Ear-Hook True Wireless Earbuds User Manual</a> User manual for GEARit Sport Ear-Hook True Wireless Earbuds (Model: GI-TWS-SPT-HK-BK-001), covering product overview, package contents, charging, Bluetooth pairing, wearing, power functions, voice commands, music controls, and warranty information.

	<p><a href="#"><b>GEARit 240W GaN PD Charger User Manual &amp; Specifications</b></a></p> <p>Comprehensive user manual for the GEARit 240W GaN PD Charger (GI-GC240W-C3A1-BK), detailing package contents, technical specifications, protection features, material, appearance, operation instructions, and warranty information.</p>
	<p><a href="#"><b>GEARit GI-TWS-SLDR-VB07-WH Wireless Earbuds User Manual</b></a></p> <p>Comprehensive user manual for the GEARit GI-TWS-SLDR-VB07-WH wireless earbuds, detailing product specifications, operation, Bluetooth pairing, charging, case effects, warnings, warranty, and FCC compliance.</p>

Documents - GEARit – GI-CAM-DRB-WH-001

	<p><a href="#"><b>GEARit Smart Doorbell GI-CAM-DRB-WH-001 User Manual</b></a></p> <p>User manual for the GEARit Smart Doorbell (Model GI-CAM-DRB-WH-001), providing detailed instructions on package contents, installation, app setup, Wi-Fi connection, product specifications, and warranty information.</p> <p>lang: <b>score:26</b> filesize: 4.84 M page_count: 1 document date: 2024-10-31</p>
---	---