Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VASAGLE RGR119B01

VASAGLE RGR119B01 Coat Rack

Instruction Manual

Model: RGR119B01

Product Overview

The VASAGLE RGR119B01 Coat Rack is a versatile storage solution designed for organizing clothes, shoes, and accessories in various spaces such as bedrooms, hallways, and entrance areas. It features a robust steel frame, two shelves, and six S-shaped hooks, offering ample storage and hanging options. The vintage brown and black finish provides a rustic aesthetic.



Image: Fully assembled VASAGLE RGR119B01 Coat Rack with its features highlighted.

Safety Information

Please read and adhere to the following safety guidelines to ensure safe use and prevent damage to the product or injury.

- Do not overload the product. The maximum total static load capacity is 197 kg (433 lbs).
- Be aware of sharp edges and small parts during assembly and use.
- Assemble the product with care, strictly following the enclosed instructions.
- Ensure all screws and fasteners are securely tightened before use.
- Place the coat rack on a flat, stable surface to prevent tipping.

Package Contents

Before beginning assembly, verify that all components listed below are present in your package:

- 1 x VASAGLE RGR119B01 Coat Rack (disassembled components)
- 1 x Accessory Pack (containing screws, tools, and small parts)
- 1 x Instruction Manual (detailed assembly guide)

Setup and Assembly

The VASAGLE RGR119B01 Coat Rack is designed for straightforward assembly. Detailed, step-by-step instructions with illustrations are provided in the included instruction manual within the accessory pack.

1. **Preparation:** Unpack all components and lay them out on a clean, soft surface to prevent scratches. Verify all parts against the parts list in the detailed manual.
2. **Space Requirement:** Ensure you have sufficient space for assembly, as some steps may require wider maneuvering before final placement.
3. **Follow Instructions:** Refer to the dedicated assembly instructions provided in your package. Each part is marked for easy identification.
4. **Tighten Securely:** Ensure all screws and fasteners are tightened securely at each step, but do not overtighten to avoid damaging the material.
5. **Final Check:** Once assembled, gently shake the rack to confirm stability. Re-tighten any loose connections if necessary.

Note: While assembly can be done by one person, having a second person may simplify certain steps.

Operating and Usage

This coat rack offers multiple storage options to help organize your space efficiently.

- **Clothes Rail:** Use the sturdy clothes rail for hanging coats, jackets, shirts, and other garments. The maximum static load capacity for the clothes rail is 55 kg (121 lbs).
- **Storage Shelves:** The two lower shelves are ideal for storing shoes, bags, storage boxes, or decorative items. Each shelf has a maximum static load capacity of 65 kg (143 lbs).
- **S-Shaped Hooks:** Utilize the six S-shaped side hooks for hanging smaller items such as hats, scarves, keys, or umbrellas. Each hook has a maximum static load capacity of 2 kg (4.4 lbs).
- **Weight Distribution:** Distribute weight evenly across the rail and shelves to maintain stability and prevent strain on any single point.

Maintenance

Regular maintenance will help prolong the life and appearance of your coat rack.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Dusting:** Dust regularly with a dry, soft cloth.
- **Fasteners:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if any feel loose.
- **Environment:** Avoid placing the coat rack in direct sunlight or in areas with extreme temperature fluctuations or high humidity, which can affect the wood chipboard material.

Troubleshooting

If you encounter any issues with your coat rack, consider the following common solutions:

- **Instability/Wobbling:**

- Ensure the coat rack is placed on a level surface.
- Check all assembly screws and connections. Tighten any that are loose.
- Verify that all parts are correctly oriented according to the assembly manual.

- **Missing Parts:** If you find any parts missing upon unboxing, refer to the contact information in your detailed instruction manual for assistance.
- **Difficulty Assembling:** Review the assembly instructions carefully, paying close attention to diagrams. Ensure you are using the correct hardware for each step.

Specifications

Brand	VASAGLE
Model	RGR119B01
Color	Vintage brown and black
Material	Engineered Wood, Alloy Steel
Product Dimensions (D x W x H)	45 x 138 x 160 cm (17.72"D x 54.33"W x 62.99"H)
Item Weight	16.4 kg (36.16 lbs)
Clothes Rail Max. Load Capacity	55 kg (121 lbs)
Hook Max. Load Capacity (each)	2 kg (4.4 lbs)
Shelf Max. Load Capacity (each)	65 kg (143 lbs)
Total Max. Static Load Capacity	197 kg (433 lbs)
Installation Type	Free Standing

Warranty and Support

For detailed warranty information, product registration, or customer support, please refer to the specific documentation included with your VASAGLE RGR119B01 Coat Rack. You may also visit the official VASAGLE website or contact their customer service department directly for assistance with any product-related inquiries or issues.

© 2026 VASAGLE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DP8QWJBK

More documents and user manuals: **https://manuals.plus/**