

[Manuals.plus](#) /

› [OUKITEL](#) /

› OUKITEL P1 Smartphone User Manual

## OUKITEL OUKITEL P1

# OUKITEL P1 Smartphone User Manual

Model: OUKITEL P1

## 1. INTRODUCTION

This manual provides detailed instructions for the OUKITEL P1 smartphone. It covers essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and user experience. Please read this manual thoroughly before using your device.

# OUKITEL P1

## 携帯電話

薄くておしゃれ、  
強力なパフォーマンス



6.7" FHD+ AMOLED



顔認証



120Hz



Android 14



Helio G99



デュアルSIM 4G



NFC



Image: Overview of OUKITEL P1's main features including its display, security, refresh rate, connectivity, and NFC capabilities.

## 2. SAFETY INFORMATION

To prevent injury to yourself or others, or damage to your device, read all safety information before using the device.

- Do not disassemble, modify, or repair the device.
- Avoid exposing the device to extreme temperatures, direct sunlight, or high humidity.
- Use only OUKITEL-approved chargers and accessories.
- Keep the device and all accessories out of reach of small children and pets.
- Dispose of the device and its battery properly according to local regulations.

### 3. PACKAGE CONTENTS

Verify that your product package contains the following items:

- OUKITEL P1 Smartphone
- USB Type-C Cable
- Power Adapter (18W)
- SIM Ejector Tool
- Protective Case
- Screen Protector (pre-applied or in box)
- Quick Start Guide
- Warranty Card

### 4. DEVICE OVERVIEW

Familiarize yourself with the physical components of your OUKITEL P1 smartphone.



Image: Front and back view of the OUKITEL P1 smartphone, highlighting its sleek design and camera module.

### Key Components:

- **Front Camera:** For selfies and video calls.
- **Display:** 6.7-inch FHD+ AMOLED screen with 120Hz refresh rate.
- **Fingerprint Sensor:** Integrated into the display for secure unlocking.
- **Rear Cameras:** 50MP main camera and 32MP secondary camera for high-quality photos.
- **Power Button:** To turn the device on/off or wake/sleep the screen.

- **Volume Buttons:** To adjust media volume and ringtone volume.
- **USB Type-C Port:** For charging and data transfer.
- **SIM/SD Card Tray:** For inserting SIM cards and a microSD card.

## 5. SETUP

### 5.1 Inserting SIM and SD Card

The OUKITEL P1 supports dual SIM cards and expandable storage up to 2TB.

1. Locate the SIM card tray on the side of the device.
2. Insert the SIM ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM card(s) and/or microSD card into the designated slots on the tray. Ensure the gold contacts face downwards.
4. Carefully push the tray back into the device until it clicks into place.

# 24GB RAM+256GB ROM



**24GB(8+16)**  
RAM

**256GB**  
ROM

**2TB**  
拡張可能

**オクタコア**  
プロセッサ

Image: Visual representation of the OUKITEL P1's memory capabilities, including 24GB RAM (8GB physical + 16GB virtual), 256GB ROM, and 2TB expandable storage.

## 5.2 Initial Power On and Basic Setup

1. Press and hold the Power button until the OUKITEL logo appears.
2. Follow the on-screen prompts to select your language, region, and connect to a Wi-Fi network.
3. Sign in with your Google account or create a new one to access Google services and the Play Store.
4. Set up your preferred screen lock method (PIN, pattern, password, fingerprint, or face unlock).

# 6. OPERATING YOUR DEVICE

## 6.1 Navigation and User Interface

The OUKITEL P1 runs on Android 14, offering an intuitive and customizable user experience.



Image: Depiction of the Android 14 operating system interface on the OUKITEL P1, showcasing various app icons and a clean layout.

- **Touch Gestures:** Swipe up for app drawer, swipe down for quick settings and notifications, pinch to zoom, tap to select.
- **Home Screen:** Customize with widgets and app shortcuts.
- **Recent Apps:** Swipe up and hold from the bottom of the screen to view and switch between recently used applications.

## 6.2 Calls and Messaging

- **Making Calls:** Open the Phone app, enter the number, and tap the call icon.
- **Sending Messages:** Open the Messages app, start a new conversation, enter recipient and text, then send.

## 6.3 Camera Usage

The OUKITEL P1 features a 50MP main camera and a 32MP front camera for high-quality photography.



Image: Illustrates the 50MP main camera and 32MP rear camera capabilities of the OUKITEL P1, showing example photos in

various modes like HD, wide-angle, and macro.

- Open the Camera app.
- Select desired mode (Photo, Video, Portrait, Pro, etc.).
- Tap the shutter button to capture.

## 6.4 Connectivity

- **Wi-Fi:** Go to Settings > Network & internet > Wi-Fi to connect to available networks.
- **Bluetooth:** Go to Settings > Connected devices > Bluetooth to pair with other Bluetooth devices.
- **NFC:** The device supports NFC for contactless payments and data transfer. Enable it in Settings > Connected devices > Connection preferences > NFC.
- **GPS:** Built-in GPS/GLONASS/Beidou/Galileo for accurate location services.

## 6.5 Security Features

- **Fingerprint Unlock:** Register your fingerprints in Settings > Security & privacy > Device unlock > Fingerprint.
- **Face Unlock:** Set up face recognition in Settings > Security & privacy > Device unlock > Face unlock.

## 6.6 Battery Management

The OUKITEL P1 is equipped with a 5150mAh large capacity battery and supports 18W fast charging.

# 5150mAh 大容量バッテリー



Image: Diagram illustrating the 5150mAh battery capacity of the OUKITEL P1, showing estimated usage times for gaming, video playback, music, and continuous calls.

- To charge, connect the USB Type-C cable to the device and the power adapter, then plug into a power outlet.
- Utilize power-saving modes in Settings > Battery to extend battery life.
- The device supports OTG reverse charging, allowing it to act as a power bank for other devices.

## 7. MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid harsh chemicals.
- **Software Updates:** Regularly check for system updates in Settings > System > System update to ensure optimal performance and security.
- **Storage Management:** Periodically clear cache and unnecessary files to free up storage space. Go to Settings > Storage.

## 8. TROUBLESHOOTING

Problem	Solution
Device does not turn on	Ensure the battery is charged. Press and hold the Power button for at least 10 seconds to force restart.
Apps are slow or crashing	Close background apps, clear app cache, or restart the device. Ensure sufficient storage space.
Cannot connect to Wi-Fi	Restart your router and the device. Check Wi-Fi settings and ensure the password is correct.
Fingerprint/Face unlock not working	Ensure your finger/face is clean and properly positioned. Re-register your fingerprint/face if issues persist.

## 9. SPECIFICATIONS

Feature	Detail
Model	OUKITEL P1
Operating System	Android 14
Processor	MediaTek Helio G99 Octa-Core (6nm)
RAM	24GB (8GB physical + 16GB virtual)
Internal Storage	256GB
Expandable Storage	Up to 2TB via microSD card
Display	6.7-inch FHD+ AMOLED, 2400x1080 resolution, 120Hz Refresh Rate
Rear Camera	50MP Main Camera
Front Camera	32MP
Battery Capacity	5150mAh
Charging	18W Fast Charging, OTG Reverse Charging
SIM Support	4G Dual SIM
Connectivity	Wi-Fi, Bluetooth 5.2, USB Type-C, NFC

Feature	Detail
Positioning	GPS, GLONASS, Beidou, Galileo
Security	Fingerprint Unlock, Face Unlock
Dimensions	Approximately 8mm thin, 187g weight

# MediaTek Helio G99

ゲーム性能



CPU性能



バッテリー効率



Image: Diagram illustrating the MediaTek Helio G99 processor, highlighting its performance, CPU efficiency, and battery efficiency.





Image: Visual representation of the OUKITEL P1's 6.7-inch FHD+ display with 120Hz refresh rate, showing resolution, size,

brightness, and aspect ratio.

## 10. WARRANTY AND SUPPORT

OUKITEL provides comprehensive support for its products:

- **Warranty:** 2-year free warranty.
- **Returns:** 30-day no-questions-asked return policy.
- **Technical Support:** Long-term technical support and 24-hour online customer service.
- For support, please visit the official OUKITEL website or contact their customer service.