

[Manuals.plus](#) /

› [Umatoll](#) /

› Umatoll Tricycle for Toddlers (Model B0DP9RKM21) Instruction Manual

Umatoll B0DP9RKM21

Umatoll Tricycle for Toddlers

MODEL: B0DP9RKM21

Instruction Manual

Introduction

Thank you for choosing the Umatoll Tricycle. This manual provides essential information for the safe assembly, operation, and maintenance of your new tricycle. Please read these instructions carefully before use and retain them for future reference. This tricycle is designed for toddlers aged 2 to 5 years.



Image: The Umatoll Tricycle in white, featuring light-up rear wheels and a front basket.

Safety Information

WARNING: Adult supervision is required at all times when the tricycle is in use.

- Ensure all parts are securely fastened before each use.
- Do not use on public roads, near motor vehicles, or on steep inclines.
- Always wear appropriate safety gear, including a helmet.
- Keep hands and feet away from moving parts.
- The tricycle is designed for one rider only.
- Regularly inspect the tricycle for any damage or loose components.

Please refer to the included safety instructions for a complete list of guidelines.

Package Contents

Before assembly, please verify that all components listed below are present:

- Tricycle Frame
- Front Wheel Assembly
- Rear Wheel Assemblies (2)
- Handlebar
- Seat
- Front Basket
- Rear Basket
- Assembly Manual (this document)

Assembly Instructions

The Umatoll Tricycle is designed for easy, tool-free assembly. Follow these steps to set up your tricycle:

1. **Attach the Handlebar:** Insert the handlebar stem into the front fork opening until it clicks securely into place. Ensure it is firmly seated and does not wobble.
2. **Install the Seat:** Slide the seat post into the designated slot on the tricycle frame. Adjust to the desired position and secure it using the spring buckle mechanism. (Refer to 'Adjusting the Seat' for details).
3. **Attach the Front Basket:** Clip the front basket onto the handlebar stem, ensuring it is stable.
4. **Attach the Rear Basket:** Secure the rear basket to the designated area at the back of the tricycle.

EVERY DETAIL PERFECTED

Built for Comfort, Designed with Care

- Stylish Look
- Ergonomic
- Fun to Ride



Anti-slip Footrest



Non-slip Handle



Sturdy Steel Design



Glow Rear Wheel

Image: Close-up view of the non-slip handle, anti-slip footrest, sturdy steel frame, and the light-up rear wheel, highlighting key design elements.

Operating Instructions

Familiarize your child with the tricycle's features for a safe and enjoyable riding experience.

Riding the Tricycle

Encourage your child to sit comfortably on the seat, place their feet on the pedals, and grasp the handlebars. The tricycle's wide wheelbase and extended rear wheels provide stability, aiding in balance and muscle development.

TODDLER TRICYCLE



UMATOLL

- < Confidence
- < Independence
- < Strength



Image: A young child riding the Umatoll Tricycle, demonstrating its use and promoting confidence and independence.

Adjusting the Seat

The tricycle features a 3-position adjustable seat to accommodate your child's growth. To adjust, locate the spring buckle mechanism beneath the seat, release it, slide the seat to the desired position (forward or backward), and re-engage the buckle firmly. Ensure the seat is locked in place before riding.

3-POSITION ADJUSTABLE SEAT

ADAPTABLE

Fits growing kids with 3 seat positions

COMFORT

Ergonomic height for easy, happy rides

STABLE

Keeps kids steady and secure



Image: An illustration detailing the three adjustable seat positions, designed for adaptability, comfort, and stability as a child grows.

Using the Baskets

The tricycle includes a removable front basket and a rear storage basket. These are ideal for carrying small toys, snacks, or other treasures during rides. Ensure items are securely placed to prevent them from falling out during movement.

REAR BASKET

Room for the big stuff and more fun.



FRONT BASKET

Snacks and toys within easy reach.



Image: Close-up of the front and rear baskets, showing their capacity for toys and other small items.

Light-Up Wheels

The rear wheels feature integrated lights that illuminate automatically when the wheels spin. No batteries are required for this feature. This adds a fun visual element to rides, especially in low-light conditions.

CLOSED-DESIGN TYRE

EVA FOAM TIRE

SAFETY

Topography

Suitable for various terrains

Stability

Solid and durable

Quiet

Low noise, no disturbance

LIGHT-UP REAR WHEEL

No batteries required



Image: A detailed view of the EVA foam tire and the light-up rear wheel, highlighting the battery-free illumination feature.

Maintenance

Regular maintenance ensures the longevity and safe operation of your Umatoll Tricycle.

- **Cleaning:** Wipe down the tricycle with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners. Dry thoroughly after cleaning.
- **Inspection:** Periodically check all bolts, screws, and connections to ensure they are tight. Inspect the wheels and tires for wear or damage.
- **Storage:** Store the tricycle in a dry, covered area away from direct sunlight and extreme temperatures to prevent material degradation.

Troubleshooting

Problem	Possible Cause	Solution
Wheels not lighting up	Wheels not spinning fast enough or obstruction.	Ensure wheels spin freely. Check for any debris or friction points. The lights activate with wheel rotation.
Seat feels loose	Seat adjustment buckle not fully engaged.	Re-engage the spring buckle mechanism firmly after adjusting the seat position.
Tricycle wobbles	Loose connections or uneven assembly.	Check all assembly points, especially the handlebar and seat connections, to ensure they are securely fastened.

Specifications

- **Product Dimensions:** 26.38 x 18.11 x 21.26 inches
- **Item Weight:** 9.59 pounds
- **Recommended Age:** 24 months and up (2-5 years)
- **Material:** Carbon Steel frame, EVA Foam Tires
- **Features:** 3-position adjustable seat, light-up rear wheels (battery-free), front and rear storage baskets, non-slip handles, anti-slip footrests.

THOUGHTFUL DESIGN FOR AGES 2 TO 5 YRS

21.2"



Lightweight

Easy to lift and move

Comfortable Seats

Cushioned for happy rides

Easy Build

Tool-free, hassle-free setup

Image: A diagram illustrating the overall dimensions of the Umatoll Tricycle, including height, width, and length.



Explore the Outdoors

Suitable for various road surfaces



Safe indoor Play

Gentle on Floors



GRASS PAVEMENT

Fun rides on grass or sidewalks

CONCRETE ROAD

Steady on concrete every time

WOODEN FLOOR

Indoor floors stay scratch-free

Image: Visual representation of the tricycle being used on different surfaces, including grass, concrete, and wooden floors, highlighting its versatility for indoor and outdoor play.

Warranty and Support

Umatoll is committed to providing quality products. For any questions, concerns, or assistance with your tricycle, please contact Umatoll customer support through the retailer where the product was purchased. Please retain your proof of purchase for warranty claims.

© 2025 Umatoll. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DP9RKM21>

More documents and user manuals: **<https://manuals.plus/>**