

LEFXMOPHY RC-200 Compatible Remote Cover

LEFXMOPHY Remote Cover User Manual

Model: RC-200 Compatible Remote Cover

Brand: LEXMOPHY

1. INTRODUCTION

The LEXMOPHY Remote Cover is a protective silicone sleeve designed for specific SuperBOX TV voice remotes. This manual provides comprehensive instructions for the proper installation, use, and maintenance of your remote cover, ensuring optimal protection and enhanced usability for your device.

2. FEATURES

- **Compatibility:** Specifically designed for SuperBOX S5 PRO, S4 PRO, S5 Max 2024, S 5 MAX, S6 MAX 2025, S 6-Ultra, and S 6-MAX Voice Remotes.
- **Enhanced Visibility:** Features a vibrant GLOW BLUE color that glows in the dark, making your remote easy to locate in low-light conditions. The glow intensity and duration depend on exposure to light.
- **Precise Fit:** Engineered with precise cutting to ensure full access to all buttons, ports, and functions of the remote without obstruction.
- **All-around Protection:** Made from soft, lightweight, and elastic silicone rubber, providing protection against slipping, cracking, scratching, and dust. The thickened design on the bottom and sides offers enhanced drop protection.
- **Comfortable & Hygienic:** Offers a skin-friendly feel, is non-toxic, non-stick fingerprint, and washable for easy cleaning.

3. COMPATIBILITY

This remote cover is compatible with the following SuperBOX TV voice remote models:

- SuperBOX S5 PRO
- SuperBOX S4 PRO
- SuperBOX S5 Max 2024
- SuperBOX S 5 MAX
- SuperBOX S6 MAX 2025

- SuperBOX S 6-Ultra
- SuperBOX S 6-MAX Voice Remote (RC-200)

Please ensure your remote matches one of the listed models for a proper fit.

4. SETUP (INSTALLATION)

Installing the LEFXMOPHY Remote Cover is a simple process. Follow these steps to ensure a secure and proper fit:

1. Gently stretch the silicone cover to widen the opening.
2. Align the top of your SuperBOX remote with the top opening of the cover.
3. Carefully slide the remote into the cover, ensuring all buttons and ports align with the corresponding cutouts.
4. Adjust the cover as needed to ensure a snug fit and full accessibility to all remote functions.

Your browser does not support the video tag.

Video: Demonstrates the step-by-step installation process of the LEFXMOPHY Remote Cover onto a SuperBOX remote, followed by a demonstration of its glow-in-the-dark feature.

Easy to Access to Buttons




Image: A side-by-side comparison illustrating the remote's appearance before and after the Lefxmophy cover is applied, highlighting the precise fit and improved button access.

5. OPERATING INSTRUCTIONS

Once installed, the Lefxmophy Remote Cover allows for normal operation of your SuperBOX remote while providing enhanced protection and grip.

5.1 General Use

The cover is designed to maintain full functionality of all remote buttons and features. Simply use your remote as you normally would. The soft silicone material provides a comfortable and secure grip, reducing the chance of accidental drops.

Comfortable Grip

Made of high quality silicone material, durable and soft, more comfortable grip.



Skin-friendly feel



Safe non-toxic



Non-stick fingerprint



Washable



Image: A hand holding the SuperBOX remote with the LEXMOPHY cover, demonstrating the comfortable and secure grip provided by the high-quality silicone material.

5.2 Luminous Feature

The GLOW BLUE remote cover contains luminous material that absorbs light and then emits a glow in the dark. To activate the glow feature:

1. Expose the remote cover to a light source (e.g., room light, sunlight) for several minutes.
2. The longer the exposure time, the brighter and longer the glow will last.
3. In a dark environment, the cover will emit a soft blue glow, making your remote easy to find.



Image: The LEXMOPHY Remote Cover in GLOW BLUE, illuminated in a dark setting to demonstrate its luminous properties, making the remote easily visible.

6. MAINTENANCE

To keep your LEXMOPHY Remote Cover in optimal condition and ensure its longevity, follow these maintenance guidelines:

- **Cleaning:** The silicone cover is washable. You can rinse it with water and mild soap if it becomes dirty. Ensure it is completely dry before re-installing it on your remote.
- **Dust Removal:** Periodically remove the cover and wipe down both the remote and the inside of the cover to prevent dust buildup.
- **Storage:** If removing the cover for extended periods, store it in a clean, dry place away from direct sunlight to prevent material degradation.


7. TROUBLESHOOTING

If you encounter any issues with your LEFXMOPHY Remote Cover, refer to the following common problems and solutions:

Problem	Solution
Cover does not fit properly.	Ensure your remote model is listed under the "Compatibility" section. Gently stretch and adjust the cover to align with all buttons and ports.
Glow feature is dim or not working.	The cover needs to absorb light to glow. Expose it to a bright light source for a longer duration (e.g., 10-15 minutes) before placing it in the dark.
Buttons are difficult to press.	Ensure the cover is correctly aligned and not shifted. The precise cutouts should allow for normal button operation. If misaligned, remove and re-install the cover.
Remote feels slippery with the cover.	The cover features a diamond non-slip texture. Ensure your hands are dry and clean for optimal grip.

All-around Drop Protection

Made of elastic silicone, it can cushion and rebound when dropped, effectively shock absorption and fall prevention.



Diamond non-slip texture



Image: A detailed view of the remote cover's diamond non-slip texture, which enhances grip and provides additional drop protection.



Drop Protection

The remote control case is thickened on the bottom and sides to prevent scratches, breakage and daily damage.

Image: An illustration depicting the remote cover's ability to absorb impact and protect the remote from damage during accidental drops.

8. SPECIFICATIONS

Attribute	Detail
Brand	LEFXMOPHY
Color	GLOW BLUE
Compatible Devices	SuperBOX S5 PRO, S4 PRO, S5 Max 2024, S 5 MAX, S6 MAX 2025, S 6-Ultra, S 6-MAX Voice Remotes (RC-200)
Form Factor	Case

Attribute	Detail
Shell Type	Soft Silicone
Item Weight	1.41 ounces
Package Dimensions	7.91 x 2.99 x 0.87 inches

9. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your LEFXMOPHY Remote Cover, please contact the manufacturer directly through the retailer's platform or their official website. Please refer to your purchase documentation for specific warranty details, as terms may vary.

We are committed to providing high-quality products and customer satisfaction.

© 2025 LEFXMOPHY. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question