



[Manuals.plus](#) /

› [Tangkula](#) /

› Tangkula Patio Rattan Daybed with Retractable Canopy (Model 72406BN-HW) User Manual

Tangkula 72406BN-HW

Tangkula Patio Rattan Daybed with Retractable Canopy (Model 72406BN-HW) User Manual

Model: 72406BN-HW | Brand: Tangkula

INTRODUCTION

This manual provides essential information for the assembly, operation, maintenance, and troubleshooting of your Tangkula Patio Rattan Daybed with Retractable Canopy. Please read these instructions carefully before assembly and use to ensure safe and proper operation of your product.



Image: The Tangkula Patio Rattan Daybed with its retractable canopy extended, situated on a wooden deck in a garden. The daybed features black rattan weaving and beige cushions.

SAFETY INFORMATION

- Ensure all parts are securely fastened before use. Regularly check for loose screws or components.
- Do not exceed the maximum weight capacity of 800 lbs for the daybed.
- Keep cushions dry to prolong their service life. Store them indoors during inclement weather.
- Exercise caution when operating the retractable canopy to avoid pinching fingers or clothing.
- Keep children and pets away from moving parts during operation.
- Place the daybed on a flat, stable surface to prevent tipping.

PACKAGE CONTENTS

Verify that all components listed below are present before beginning assembly:

- 1 x Daybed Frame
- 2 x Seat Cushions

- 4 x Back Cushions
- All necessary hardware (screws, bolts, tools)
- Assembly Instruction Manual

SETUP (ASSEMBLY INSTRUCTIONS)

The outdoor rattan daybed comes with all required hardware and an easy-to-follow instruction. Please follow these steps carefully for proper assembly:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify all parts according to the parts list in the included manual.
3. Begin assembling the main frame sections as indicated in the detailed diagrams.
4. **Important:** Do not tighten all screws completely until all holes are aligned and all components are loosely fitted. This allows for easier adjustment and prevents misalignment.
5. Once all parts are in place, gradually tighten all screws and bolts using the provided tools.
6. Attach the retractable canopy mechanism to the frame, ensuring it moves smoothly.
7. Place the seat and back cushions onto the daybed.




Image: A detailed diagram illustrating the dimensions of the daybed (65" x 60.5" x 54.5" with canopy expanded) and its 800 lbs weight capacity.

OPERATING INSTRUCTIONS

Retractable Canopy

The daybed features a retractable canopy for adjustable shade. To operate:

- To extend the canopy: Gently push the canopy upwards until the pneumatic rods engage and hold it in the desired position.
- To retract the canopy: Gently pull the canopy downwards. The pneumatic rods will assist in a smooth retraction. Secure the canopy with the fixing ropes to keep it in place when retracted.



Image: Details of the retractable canopy, highlighting the pneumatic rod for easy adjustment and the fixing ropes to secure the canopy when not in use.

Foldable Side Tables

The daybed includes two retractable side tables for convenience:

- To deploy a side table: Gently pull the table panel outwards from the side of the daybed. It will extend and lock into a horizontal position.
- To retract a side table: Push the table panel inwards until it folds neatly back into the daybed frame.

Retractable Trays in Two Sides

Provide additional space for you to store drinks or snacks



Image: The daybed with one of its retractable side tables extended, providing a surface for drinks or small items.

Official Product Video

Your browser does not support the video tag.

Video: An official product video from Tangkula demonstrating the features and functionality of the Patio Rattan Daybed with Retractable Canopy, including its adjustable canopy and side tables.

MAINTENANCE

Proper maintenance will extend the life and appearance of your daybed:

- **Cushions:** Always keep cushions dry to prolong service time. The cushion covers feature smooth zippers for easy removal and washing. Hand wash or machine wash on a gentle cycle with cold water and mild detergent. Air dry only.
- **Rattan and Frame:** Clean the PE rattan and metal frame with a soft cloth, mild soap, and water. Rinse thoroughly and dry completely to prevent water spots and corrosion.
- **Canopy Fabric:** Spot clean the canopy fabric with a mild soap solution and a soft brush. Rinse well and allow to air dry completely before retracting or storing.
- **Storage:** During off-season or prolonged periods of non-use, store the daybed in a dry, covered

area. If storing outdoors, use a weather-resistant cover.

Cozy Seat & Back Cushions



Elastic & Soft Sponge

Offer you optimal comfort to sit



Smooth Zippers

Easy to remove or wash the cushion cover

- Please always keep cushions dry to prolong the service time
- Due to the light avoidance and light exposure, the color of the cushions is slightly different

Image: A close-up view of the daybed's thick, elastic sponge cushions and the smooth zippers on their covers, indicating ease of removal for cleaning.



Image: Detailed view of the daybed's construction, showcasing the durable black PE Rattan, aluminum feet for stability, and additional support legs for enhanced strength.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Canopy not retracting/extending smoothly.	Obstruction in the mechanism or pneumatic rod issue.	Check for any obstructions. Ensure pneumatic rods are clean and free of debris. If issues persist, contact customer support.
Daybed feels unstable or wobbly.	Loose screws or uneven placement.	Check and tighten all assembly screws. Ensure the daybed is placed on a level surface. Adjust anti-slip footpads if necessary.
Cushions appear discolored or stained.	Exposure to sunlight, moisture, or spills.	Remove cushion covers and wash according to maintenance instructions. Store cushions indoors when not in use to prevent prolonged exposure.

SPECIFICATIONS

Model Number	72406BN-HW
Brand	Tangkula
Overall Dimension (canopy expanded)	65" (L) x 60.5" (W) x 54.5" (H)
Seating Area	58" (L) x 48.5" (W)
Weight Capacity	800 lbs
Material	PE Rattan, Metal, Sponge, Polyester
Item Weight	57.5 lbs
Color	Beige
UPC	798470087842

WARRANTY & SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official Tangkula website. Keep your proof of purchase for any warranty claims.

For additional assistance, you may contact Tangkula customer service through their official channels. Please have your model number (72406BN-HW) and purchase date ready when contacting support.