

IBELL YO1900

IBELL YO1900 High Pressure Washer Instruction Manual

Model: YO1900

INTRODUCTION

The IBELL YO1900 High Pressure Washer is designed for efficient and powerful cleaning tasks around your home, car, and outdoor areas. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your pressure washer. Please read all instructions carefully before use.

PACKAGE CONTENTS

Verify that all items listed below are included in your package. If any parts are missing or damaged, contact customer support.

- Main Unit (Pressure Washer)
- Spray Gun & Nozzle
- Extension Rod
- Foam Bottle (500 ml)
- Inlet Connector
- Bucket Filter
- Inlet Filter
- Tap Connector
- 3-meter Inlet Hose
- 8-meter Outlet Hose

Accessories



Main Unit



Spray Gun & Nozzle



Extension Rod



**Foam
Bottle**



**Inlet
connector**



**Bucket
Filter**



**Inlet
Filter**



**Tap
connector**



**3M Inlet
hose**



**8M outlet
hose**

Image: All components of the IBELL YO1900 High Pressure Washer, including the main unit, spray gun, hoses, and various connectors and filters.

SETUP INSTRUCTIONS

Follow these steps to assemble and prepare your pressure washer for first use.

1. **Connect Inlet Pipe:** Attach the inlet pipe connector to the designated inlet port on the pressure washer. Ensure a secure fit.
2. **Connect Outlet Pipe:** Attach the outlet pipe connector to the designated outlet port on the pressure washer. Tighten securely.
3. **Install Inlet Filter:** Connect the inlet filter to the 3-meter inlet hose. This prevents debris from entering the pump.
4. **Connect Water Source:** Attach the 3-meter inlet hose (with filter) to your water supply using the tap connector. Ensure the water supply is turned on before starting the unit.
5. **Assemble Spray Gun:** Connect the extension rod to the spray gun. Then, attach the 8-meter outlet hose to the spray gun.
6. **Power Connection:** Plug the power cord into a suitable electrical outlet.

Your browser does not support the video tag.

Video: Demonstrates the step-by-step assembly and connection of the IBELL YO1900 High Pressure Washer

components, including hoses, connectors, and the spray gun.



Image: Detailed view of the pressure washer's main unit, highlighting the power switch, 1900W indicator, and the inlet and outlet hose connection points.

OPERATING INSTRUCTIONS

Before operating, ensure all connections are secure and the water supply is open.

1. **Turn On:** Press the ON/OFF switch to power on the pressure washer.
2. **Prime the Pump:** Squeeze the trigger on the spray gun to release air from the system until a steady stream of water emerges. This primes the pump and prevents damage.
3. **Adjust Nozzle:** The adjustable nozzle allows for different spray patterns. Rotate the nozzle to select between:
 - Low Speed Foam Spray: Ideal for applying detergent.
 - Medium Speed Foam Spray: For general cleaning with foam.
 - Jet Speed (Hard & Detailed Cleaning): For stubborn dirt and precise cleaning.
4. **Apply Detergent (Optional):** Fill the foam bottle with appropriate pressure washer detergent. Attach the foam bottle to the spray gun. Apply detergent to the surface, allowing it to soak as recommended by the detergent manufacturer.

5. **Rinse:** After applying detergent, remove the foam bottle and switch to a suitable spray pattern for rinsing. Hold the spray gun at a safe distance from the surface and move steadily to rinse thoroughly.
6. **Turn Off:** When finished, turn off the pressure washer using the ON/OFF switch. Release any remaining pressure by squeezing the spray gun trigger.



Image: Illustrates the three adjustable spray patterns available with the nozzle: low foam, medium foam, and jet speed for focused cleaning.

Soap Application with 500 MI Bottle



Image: The pressure washer in action, demonstrating soap application to a car using the included 500 ml foam bottle.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your pressure washer.

- **Clean Filters:** Regularly inspect and clean the inlet filter and bucket filter to prevent blockages and maintain water flow.
- **Drain Water:** After each use, disconnect the water supply and run the pressure washer for a few seconds to drain any remaining water from the pump and hoses. This is crucial for preventing freezing damage in cold climates.
- **Store Properly:** Store the pressure washer in a dry, frost-free environment. Coil hoses neatly and store accessories in a safe place.
- **Inspect Hoses and Connections:** Periodically check hoses for kinks, cuts, or leaks. Ensure all connections are tight and free from damage.

TROUBLESHOOTING

If you encounter issues, refer to these common solutions before contacting service.

Problem	Possible Cause	Solution
No power	Power cord unplugged, circuit breaker tripped, ON/OFF switch off.	Check power connection, reset circuit breaker, ensure switch is ON.
No water flow or low pressure	Water supply off, inlet filter clogged, air in pump, kinked hose.	Turn on water supply, clean inlet filter, prime the pump, straighten hose.
Motor runs but no pressure	Air in pump, clogged nozzle, water supply restricted.	Prime the pump, clear nozzle, check water supply for adequate flow.

SPECIFICATIONS

Key technical details for the IBELL YO1900 High Pressure Washer.

Feature	Detail
Brand	IBELL
Model Number	YO1900
Power Source	Corded Electric
Motor Power	1900W Induction Motor
Maximum Pressure	130 Bar
Maximum Flow Rate	8 Liters Per Minute
Hose Length	8 Metres (Outlet) / 3 Metres (Inlet)
Item Weight	5 Kilograms
Product Dimensions (L x W x H)	30L x 30W x 30H Centimeters

DIMENSION



Image: Visual representation of the IBELL YO1900 pressure washer with its key dimensions labeled.

WARRANTY AND SUPPORT

The IBELL YO1900 High Pressure Washer comes with a **1-Year Warranty**. This includes a 6-month standard warranty and an additional 6-month warranty upon registration. Registration must be completed within 30 days from the date of purchase to avail the extended warranty.

For technical assistance, warranty claims, or to register your product, please refer to the contact information provided with your purchase or visit the official IBELL website.