

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Dioche](#) /

› [Dioche 5-in-1 Electric Epilator & Hair Removal Device \(Model: Dioche0kmsy1ndcw\) - User Manual](#)

Dioche Dioche0kmsy1ndcw

Dioche 5-in-1 Electric Epilator & Hair Removal Device (Model: Dioche0kmsy1ndcw) - User Manual

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your Dioche 5-in-1 Electric Epilator and Hair Removal Device, model Dioche0kmsy1ndcw. Please read this manual thoroughly before first use and retain it for future reference.

The device is designed for versatile hair removal across various body parts, offering multiple functions in one compact unit.

2. IMPORTANT SAFETY INFORMATION

To ensure safe operation and prevent injury or damage to the device, always adhere to the following safety precautions:

- Always use the shaver with caution to avoid cuts or skin irritation.
- Keep the shaver away from water while charging.
- Allow the device to dry completely after wet use to prevent electrical shorts or bacterial growth.
- Replace the shaver head when it becomes dull to ensure safe and effective use.
- Never use the shaver while it is charging.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Electric Shaver Body
- 1 x Nose Hair Cutter Head
- 1 x Shaving Head

- 1 x Long Hair Trimming Head
- 1 x Eyebrow Trimming Cutter Head
- 4 x Limit Combs (1mm, 2mm, 4mm, 6mm)
- 1 x Cleaning Brush
- 1 x USB Charging Cable
- 1 x Eyebrow Trimming Cutter Head Protective Cover
- 1 x User Manual (this document)





Image: The Dioche 5-in-1 Electric Epilator device with its various interchangeable heads and limit combs. This image shows the main shaver body, the nose hair trimmer head, the long hair trimming head, the eyebrow trimming head, the shaving head, and four different sized limit combs, along with a small cleaning brush.



Image: A close-up view of the various interchangeable heads and limit combs included with the Dioche 5-in-1 Electric Epilator. From left to right, the image displays the nose hair trimmer head, the long hair trimming head, the eyebrow trimming head, and the shaving head, along with the four limit combs and a cleaning brush.

4. PRODUCT SPECIFICATIONS

Feature	Specification
Model Name	Dioche0kmsy1ndcw
Power	3W
Working Time	Approximately 55 minutes
Charging Time	Approximately 8 hours

Feature	Specification
Battery Type	Ni-MH battery 600mAh (AA)
Power Source	Battery Powered (USB Rechargeable)
Functions	Full body shaving, nose hair trimming, eyebrow trimming, long hair trimming
Usage	Wet and Dry Use
Dimensions	7.87 x 5.12 x 1.97 inches
Weight	9.1 ounces

5. SETUP AND CHARGING

5.1 Initial Charging

Before first use, fully charge the device for approximately 8 hours. Ensure the device is switched OFF during charging.

1. Insert the USB charging cable into the charging port at the bottom of the shaver body.
2. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer USB port.
3. The charging indicator light will illuminate (typically red) to indicate charging is in progress.
4. Once fully charged, the indicator light may change color (e.g., green) or turn off, depending on the model.



Image: A close-up view of the charging port located at the base of the Dioche 5-in-1 Electric Epilator. This port is where the USB charging cable is inserted to power the device.



Image: A hand holding the Dioche 5-in-1 Electric Epilator, showing the charging indicator light. The light is illuminated, indicating the device is currently charging.

5.2 Attaching/Detaching Cutter Heads

The device comes with multiple interchangeable cutter heads for different grooming needs.

1. To attach a head: Align the desired cutter head with the main body and gently twist or push until it clicks securely into place.
2. To detach a head: Hold the main body firmly and twist or pull the cutter head off. Refer to the specific head's design for the correct removal method.



Image: The Dioche 5-in-1 Electric Epilator disassembled, showing the main body, all interchangeable heads (nose hair, shaving, long hair trimming, eyebrow trimming), limit combs, USB cable, and cleaning brush laid out. This illustrates the complete set of components.

6. OPERATING INSTRUCTIONS

Ensure the device is fully charged before use. Select the appropriate cutter head for your desired function.

6.1 Powering On/Off

- To turn ON: Slide the power switch located on the main body upwards.
- To turn OFF: Slide the power switch downwards.



Image: A close-up of the Dioche 5-in-1 Electric Epilator's power switch, clearly showing the "OFF" position and the power button. This highlights the control for turning the device on and off.

6.2 Using the Shaving Head

Attach the shaving head for general body hair removal.

- For best results, hold the device at a 45-degree angle against the skin.
- Move the shaver gently against the direction of hair growth.
- Can be used on dry skin or with shaving foam/gel for wet shaving.



Image: A hand holding the Dioche 5-in-1 Electric Epilator, demonstrating its ergonomic design and compact size for comfortable use. The shaving head is attached, showing how it would be held during operation.

6.3 Using the Nose Hair Cutter Head

Attach the nose hair cutter head for safe and effective nose and ear hair trimming.

- Gently insert the trimmer tip into the nostril or ear canal.
- Move the device in a circular motion to trim unwanted hair.

- Do not insert too deeply to avoid injury.

Your browser does not support the video tag.

Video: This video demonstrates the Dioche 5-in-1 Electric Epilator's multi-site hair removal capabilities, including its use for nose and ear hair trimming. It shows the device in action, highlighting its versatility and ease of use for various grooming needs.

6.4 Using the Eyebrow Trimming Cutter Head

Attach the eyebrow trimming head for precise shaping and trimming of eyebrows.

- Use the protective cover or a limit comb (e.g., 1mm or 2mm) for even trimming.
- Gently move the trimmer against the direction of eyebrow growth.
- Trim small sections at a time to avoid over-trimming.

6.5 Using the Long Hair Trimming Head

Attach the long hair trimming head for areas requiring longer hair removal or shaping.

- Select an appropriate limit comb (1mm, 2mm, 4mm, or 6mm) and attach it to the trimming head.
- Move the device smoothly over the skin in the desired direction.

7. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and hygiene of your device.

1. **Turn Off and Disconnect:** Always switch off the device and disconnect it from the charging cable before cleaning.
2. **Remove Cutter Head:** Detach the used cutter head from the main body.
3. **Brush Cleaning:** Use the provided cleaning brush to remove hair clippings from the cutter head and the inside of the main body.
4. **Rinsing (Wet & Dry Use Heads):** For heads designed for wet use (shaving head, long hair trimming head), you can rinse them under running water. Ensure they are completely dry before reattaching or storing. *Do not rinse the main body or the nose/eyebrow trimmer heads unless explicitly stated as waterproof.*
5. **Drying:** Allow all parts to air dry completely before reassembling or storing the device.
6. **Storage:** Store the device and its attachments in a clean, dry place, away from direct sunlight and extreme temperatures.



Image: The Dioche 5-in-1 Electric Epilator's shaving head being rinsed under running water, demonstrating its wet-use capability for easy cleaning. This shows how to clean the waterproof heads after use.

8. TROUBLESHOOTING

If you encounter issues with your device, refer to the following table:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device for 8 hours.
Device does not turn on.	Power switch is not fully engaged.	Ensure the power switch is slid completely to the ON position.
Poor trimming/shaving performance.	Cutter head is dull or clogged with hair.	Clean the cutter head thoroughly. Replace the cutter head if it remains dull.
Skin irritation after use.	Improper technique or sensitive skin.	Ensure gentle pressure and proper angle. Consider using the device on wet skin with shaving cream. If irritation persists, discontinue use.

Problem	Possible Cause	Solution
Charging indicator not working.	Faulty USB cable or power source.	Try a different USB cable or power adapter. Ensure the cable is securely connected.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Dioche customer service through the retailer where the product was purchased or visit the official Dioche website. Please have your model number (Dioche0kmsy1ndcw) and purchase date available when contacting support.

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is intended for personal grooming purposes only.