

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [dreazu](#) /

› [Dreazu Electric Spin Scrubber G2 User Manual](#)

dreazu G2

Dreazu Electric Spin Scrubber G2 User Manual

Model: G2

INTRODUCTION

This manual provides instructions for the safe and effective use of your Dreazu Electric Spin Scrubber Model G2. Please read this manual thoroughly before first use and retain it for future reference.

IMPORTANT SAFETY INFORMATION

- Read all instructions before use.
- This appliance is designed for household cleaning tasks only.
- Do not immerse the main unit in water beyond its IPX7 rating. Ensure the charging port cover is securely closed during use.
- Keep out of reach of children.
- Do not operate the scrubber if it is damaged or malfunctioning.
- Use only the provided charging cable.
- Avoid using abrasive cleaners or harsh chemicals that may damage the device or brush heads.
- Disconnect from power before cleaning or performing maintenance.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Dreazu Electric Spin Scrubber (Main Unit)
- 1 x Extension Handle
- 1 x Main Handle
- 7 x Replaceable Brush Heads (various types)
- 3 x Crevice Cleaning Brushes
- 1 x USB-C Charging Cable
- 1 x User Manual (this document)
- 2 x Hooks (for storage)

- 1 x Storage Bag



Image: The Dreazu Electric Spin Scrubber main unit, extension handle, various brush heads, charging cable, storage bag, and wall hooks.

PRODUCT FEATURES

Powerful Motor with Two Speed Settings

The scrubber features a robust motor with two adjustable speeds:

- **350 RPM:** Suitable for regular, everyday cleaning tasks.
- **450 RPM:** Provides increased power for deep cleaning and stubborn stains.



Image: Illustration showing the scrubber operating at 350 RPM for daily cleaning and 450 RPM for deep cleaning, with a close-up of the internal motor.

IPX7 Waterproof Design

The device is designed with IPX7 waterproof protection, allowing safe use in damp environments such as bathrooms. The sealed structure helps prevent internal rust and short circuits.



Image: The electric spin scrubber head partially submerged in water, with "IPX7 Waterproof" text overlay, illustrating its water resistance.

Retractable and Detachable Handle

The telescopic handle can be adjusted in length from 41 inches to 48 inches, or used as a shorter 11-inch handheld unit. This design allows for cleaning hard-to-reach areas without excessive bending or kneeling.

Retractable & Detachable Handle

Easily adjust the handle to reach difficult areas



Image: The electric spin scrubber handle shown in three configurations: short (11 inches), extended (41 inches), and fully extended (48 inches), demonstrating its adjustability.

Long-Lasting Battery

Equipped with a 2500mAh battery, the scrubber provides 60 to 90 minutes of continuous cleaning on a full charge. A full charge takes approximately 3 hours using the included USB-C cable. A power display indicates battery status.



Image: The electric spin scrubber connected to a wall charger via its USB-C cable, with an infographic detailing its 2500mAh battery capacity, 60-90 minutes working time, and 3 hours charging time.

SETUP

Charging the Device

1. Locate the USB-C charging port on the main unit.
2. Connect the provided USB-C cable to the scrubber and a compatible USB power adapter (not included).
3. The power indicator lights will illuminate during charging and turn off when fully charged.
4. A full charge takes approximately 3 hours.

Assembling the Handle

1. To use as a handheld scrubber: Attach a brush head directly to the main unit.
2. To use with the extension handle:
 - Connect the main handle to the extension handle by rotating it until secure.
 - Attach the assembled handle to the main scrubber unit by rotating it until secure.
 - To adjust the length, loosen the inner lock on the extension pole, extend or retract to the

desired length (41-48 inches), and then tighten the lock.



Image: A step-by-step diagram illustrating the installation of a brush head onto the scrubber and the assembly process for the telescopic handle, including locking and unlocking mechanisms.

Attaching Brush Heads

1. Select the appropriate brush head for your cleaning task.
2. Align the brush head with the rotating base of the scrubber.
3. Push and twist the brush head clockwise until it clicks securely into place.
4. To remove, twist counter-clockwise and pull off.

OPERATING INSTRUCTIONS

Power On/Off and Speed Adjustment

1. Press the power button once to turn on the scrubber at the lower speed (350 RPM).
2. Press the power button a second time to switch to the higher speed (450 RPM).
3. Press the power button a third time to turn off the scrubber.

Cleaning Recommendations

Apply a suitable cleaning solution to the surface or directly to the brush head.

Gently press the rotating brush against the surface to be cleaned. Avoid excessive force, as the motor is designed to do the work.

Move the scrubber slowly and steadily over the area.

For optimal results, allow the brush to work for a few seconds on stubborn spots before moving on.

Using Different Brush Heads

The Dreazu Electric Spin Scrubber comes with 7 interchangeable brush heads and 3 crevice brushes, each designed for specific cleaning applications:

- **Large Flat Brush:** Ideal for large flat surfaces like floors, tile walls, and bathtubs.
- **Small Flat Brush:** Suitable for smaller flat areas such as sinks, cooktops, and cabinets.
- **Corner/Pointed Brush:** Designed for cleaning corners, gaps, grout lines, and edges.
- **Fibre Sponge/Sponge:** For gentle scrubbing and polishing on delicate surfaces.
- **Wool Cloth/Cloth:** For polishing and drying surfaces.
- **Crevice Brushes:** For very narrow gaps, keypads, thresholds, and detailed cleaning.

7 Replacement Brushes & 1 Crevice Cleaning Brushes




Image: A display of the seven interchangeable brush heads and three crevice cleaning brushes included with the scrubber, showing their various shapes and sizes.



Image: A collage demonstrating the use of various brush heads for different cleaning applications, including large brush for floors, small brush for sinks, pointed brush for corners, and sponge/cloth pads for other surfaces.

MAINTENANCE

Cleaning the Scrubber

1. After each use, remove the brush head.
2. Rinse the brush head and the rotating base of the main unit under running water.
3. Wipe the main unit and handle with a damp cloth. Do not immerse the entire main unit in water.
4. Ensure the charging port cover is sealed before rinsing.
5. Allow all parts to air dry completely before storage.

Storage

Store the scrubber in a cool, dry place.

Use the provided hooks to hang the scrubber for convenient storage and to save space.



Image: The electric spin scrubber hanging on a wall hook in a modern bathroom, demonstrating convenient storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Scrubber does not turn on.	Battery is depleted.	Charge the scrubber for at least 3 hours.
Brush head stops spinning or spins slowly.	Low battery; excessive pressure applied; brush head obstructed.	Recharge the battery; reduce pressure; check for and remove any obstructions.
Water enters the charging port.	Charging port cover not securely closed.	Ensure the charging port cover is always securely closed before using the scrubber in wet conditions. If water has entered, allow the device to dry completely before attempting to charge or use again.
Handle feels loose.	Handle sections not securely tightened.	Ensure all handle sections are rotated and locked securely. For the telescopic handle, ensure the inner lock is tightened after adjusting length.

SPECIFICATIONS

Feature	Detail

Feature	Detail
Model	G2
Brand	Dreazu
Battery Capacity	2500mAh Lithium Ion
Charging Time	Approx. 3 hours
Working Time	60-90 minutes
Speed Settings	2 speeds (350 RPM, 450 RPM)
Waterproof Rating	IPX7
Handle Length	11 inches (handheld), 41-48 inches (extended)
Material	Acrylonitrile Butadiene Styrene (ABS), Stainless Steel (handle)
Item Weight	1.45 Pounds
Included Components	Scrubber unit, extension handle, main handle, 7 brush heads, 3 crevice brushes, USB-C cable, user manual, 2 hooks, storage bag

WARRANTY AND SUPPORT

Dreazu is committed to customer satisfaction. If you encounter any issues with your Electric Spin Scrubber, please contact our dedicated after-sales support team. Refer to your purchase documentation for specific warranty details and contact information.

For further assistance, visit the official Dreazu store or contact customer service through your retailer.

© 2025 Dreazu. All rights reserved.

This manual is subject to change without notice.

Related Documents - G2

	<p>RUBI SLIM CUTTER G2 - Manual Tile Cutting System for Large Porcelain Slabs</p> <p>Detailed information on the RUBI SLIM CUTTER G2, a manual tile cutting system for large porcelain slabs. Features include cutting capacity, components, technical specifications, and packaging details.</p>
	<p>Guardian Bariatric Bath Bench with Back - User Instructions and Warranty</p> <p>User instructions, warranty information, and safety warnings for the Guardian Bariatric Bath Bench with Back, designed for enhanced stability and support. Includes details on installation, adjustment, cleaning, and product specifications.</p>
	<p>Dreame Z40 Station Cordless Stick Vacuum User Manual</p> <p>Comprehensive user manual for the Dreame Z40 Station Cordless Stick Vacuum with Auto Empty. Learn about setup, operation, maintenance, and safety instructions.</p>
	<p>HOBBYWING QUICRUN WP 10BL120 G2 ESC User Manual</p> <p>Detailed user manual for the HOBBYWING QUICRUN WP 10BL120 G2 Brushless Electronic Speed Controller, covering setup, features, specifications, and troubleshooting for RC applications.</p>
	<p>Autopmall G2 GPS Speed Meter User Manual</p> <p>User manual for the Autopmall G2 GPS Speed Meter, detailing display functions, wave button operation, settings calibration, and troubleshooting for vehicle speed, alarms, and time.</p>
	<p>IZZY Rechargeable Stick Vacuum Cleaner 29.6V G2 Instructions Manual</p> <p>This document provides comprehensive instructions for the IZZY Rechargeable Stick Vacuum Cleaner 29.6V G2, covering safety precautions, assembly, usage, maintenance, and technical specifications. Learn how to effectively use and care for your IZZY vacuum cleaner.</p>