

[Manuals.plus](#) /

› [DEMIQON](#) /

› DEMIQON Stainless Steel Kitchen Dish Rack User Manual

DEMIQON dmqnv hh

DEMIQON Stainless Steel Kitchen Dish Rack

USER MANUAL

Brand: DEMIQON | Model: dmqnv hh

1. INTRODUCTION

Thank you for choosing the DEMIQON Stainless Steel Kitchen Dish Rack. This multi-functional, wall-mounted rack is designed to provide an efficient and organized solution for drying and storing your kitchenware. Crafted from 100% non-magnetic stainless steel with a five-layer decorative rust-proof plating, it offers durability and a modern aesthetic. This manual provides essential information for proper setup, operation, and maintenance to ensure long-lasting performance.



Figure 1: The DEMIQON Stainless Steel Kitchen Dish Rack, showcasing its capacity for various kitchen items like plates, bowls, and pots.

2. SETUP AND INSTALLATION

2.1 Unpacking

Carefully unpack all components from the packaging. Verify that all parts are present before proceeding with installation. The package includes the main rack structure and add-on units.

2.2 Wall Mounting

This dish rack is designed for secure wall mounting. All necessary accessories for installation are included.

1. **Select Location:** Choose a suitable wall in your kitchen, preferably near a sink, ensuring sufficient space for the rack (dimensions: 65D x 25W x 10H Centimeters).
2. **Mark Drilling Points:** Hold the rack against the wall at the desired height and use a pencil to mark the positions for the mounting holes. Ensure the rack is level before marking.
3. **Drill Holes:** Using an appropriate drill bit for your wall type, drill holes at the marked positions.
4. **Insert Wall Plugs:** Insert the provided wall plugs (if applicable) into the drilled holes.
5. **Secure the Rack:** Align the rack's mounting holes with the drilled holes and secure it firmly to the wall using the provided screws.



Figure 2: Illustration of the dish rack highlighting the designated holes for wall mounting.

3. OPERATING INSTRUCTIONS

The DEMIQON Kitchen Dish Rack is designed for versatile storage and organization of various kitchen items. It

features a spacious 5-shelf design and multiple specialized holders.

3.1 Organizing Your Kitchenware

- **Plate and Bowl Sections:** Utilize the dedicated sections for plates and bowls to allow for efficient drying and easy access. The rack includes sections for both big and small plates.
- **Utensil Holders:** The rack comes with a spoon holder for organizing your cutlery.
- **Glass Holder:** Hang your glasses upside down on the designated glass holder for quick drying and storage.
- **Cup Holder:** Hooks are provided for hanging cups, keeping them dry and within reach.
- **Chakla Belan Holder:** A specific holder is included for traditional Indian rolling pins and boards (chakla belan).
- **General Shelves:** The remaining shelves can be used for storing other kitchen essentials, containers, or small appliances.




Figure 3: An overview of the dish rack with labels indicating the 'Spoon Holder', 'Glass Holder', 'Chakla Belan Stand', 'Big Plate Space', 'Small Plate Space', and 'Cup Holder'.



Figure 4: Detail of the integrated spoon holder.



Figure 5: Detail of the chakla belan (rolling pin and board) holder.



Figure 6: Detail of the glass holder.



Figure 7: Detail of the cup holder hooks.

4. CARE AND MAINTENANCE

4.1 Cleaning

To maintain the shine and hygiene of your stainless steel dish rack, follow these cleaning instructions:

1. **Regular Cleaning:** Wash the rack regularly using a small amount of mild dish soap (like Vim bar) and a wet scrubber.
2. **Rinse Thoroughly:** Rinse the rack thoroughly with clean water to remove all soap residue.
3. **Wipe Dry:** Immediately wipe the rack thoroughly with a clean, dry cloth. This prevents water spots and helps maintain its polished finish and rust-proof properties.

4.2 Rust Prevention

While the rack features rust-proof plating, proper care enhances its longevity:

- Avoid using abrasive cleaners or steel wool, which can damage the protective plating.
- Ensure good ventilation around the rack to facilitate drying.
- Promptly clean any food residue or acidic spills to prevent potential staining or corrosion.

5. TROUBLESHOOTING

5.1 Common Issues and Solutions

Issue	Possible Cause	Solution
Rack appears unstable after mounting	Improper installation; loose screws or inadequate wall plugs.	Ensure screws are tightened securely. Verify wall plugs are appropriate for your wall material and installed correctly. Re-drill if necessary.
Water spots or dull finish	Water residue left to dry on the surface.	Always wipe the rack dry immediately after cleaning or after dishes have dried. Use a soft, dry cloth.
Difficulty organizing specific items	Items not placed in designated sections.	Refer to Section 3.1 for optimal placement of different kitchenware items. Utilize the specialized holders.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	DEMIQON
Model Number	dmqnv hh
Material	Stainless Steel
Colour	STEEL
Special Feature	Dish Drainer
Product Dimensions (D x W x H)	65D x 25W x 10H Centimeters (Note: Product title mentions 31x30 inch, please verify actual dimensions)
Shelf Type	Hanging Shelf
Number of Shelves	5

Feature	Detail
Room Type	Kitchen
Finish Type	Polished
Assembly Required	Yes
Mounting Type	Wall Mount
Recommended Uses	Dishware
Included Components	Add-on Units
Item Weight	4 Kilograms
Style	Modern
Shelf Weight Capacity	35 Kilograms
Indoor/Outdoor Usage	Indoor




Figure 8: The dish rack displaying its approximate dimensions of 30 inches in width and 31 inches in height.

7. WARRANTY AND SUPPORT

For any product-related inquiries, support, or warranty information, please contact DEMIQON customer service. While specific warranty details are not provided in this manual, DEMIQON is committed to customer satisfaction. You can also visit the official DEMIQON store for more information and product range [DEMIQON Store on Amazon.in](#)

