

[Manuals.plus](#) /

> [TEENFON](#) /

> TEENFON Farmhouse Storage Cabinet 43.3"H - Instruction Manual

TEENFON cabinet

TEENFON Farmhouse Storage Cabinet 43.3"H - Instruction Manual

Model: cabinet

INTRODUCTION

Thank you for purchasing the TEENFON Farmhouse Storage Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new cabinet. Please read these instructions carefully before beginning assembly and retain them for future reference.

Product Dimensions: 11.8"D x 23.6"W x 43.3"H

Included Components: Doors, Adjustable Shelves

Material: Engineered Wood

IMPORTANT SAFETY INFORMATION

- Ensure the cabinet is properly secured to the wall using the provided anti-tip kit to prevent tipping.
- Do not exceed the weight limit on shelves.
- Keep fingers and hands away from door edges to avoid pinches.
- Assembly should be performed by adults. Keep small parts away from children.
- Place the cabinet on a flat, stable surface.
- Regularly check all fasteners to ensure they remain tight.



Door Magnetic Holder



Black Metal Decor



Metal Handles



Adjustable Shelf

Figure 1: Anti-tip kit secures the cabinet to the wall for safety. This prevents accidental tipping, especially important in households with children or pets.

PACKAGE CONTENTS

Before assembly, verify that all parts are present and undamaged. Refer to the assembly diagram for a complete list of components.



Figure 2: An exploded view showing all individual components and hardware included in the package. Please check against the parts list in your physical manual.

SETUP AND ASSEMBLY

Assembly is required for this product. It is recommended to have two people for assembly. Follow the step-by-step instructions provided in the accessory kit. An assembly video may also be available online for visual guidance.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.
2. **Identify Hardware:** Separate and identify all screws, dowels, and other hardware using the provided hardware list.
3. **Assemble Frame:** Begin by assembling the main frame of the cabinet according to the diagrams. Ensure all connections are secure.
4. **Install Shelves:** Insert the adjustable shelves into the desired positions. The shelves can be moved to different heights to accommodate various items.
5. **Attach Doors:** Mount the four doors to the cabinet frame. Ensure they open and close smoothly and align correctly.

6. **Install Handles:** Attach the metal handles to the doors.

7. **Secure Anti-Tip Kit:** Crucially, install the anti-tip kit to secure the cabinet to a wall stud. This prevents the cabinet from falling over.

Adjustable Shelves

Make it easy to customize the space according to your needs



Figure 3: The cabinet with its doors open, illustrating the adjustable shelves. The shelves can be repositioned to customize storage space.



Figure 4: A detailed view of the adjustable shelf mechanism, showing how to change shelf height.

Anti- Tip Kit

Secures the cabinet to the wall for a safer space






Figure 5: Close-up of the door magnetic holder and metal handles, highlighting the hardware details.

OPERATING INSTRUCTIONS

The TEENFON Farmhouse Storage Cabinet is designed for organizing various items in your home. Its four doors provide hidden storage, and the adjustable shelves allow for flexible organization.

- **Opening/Closing Doors:** Use the metal handles to gently open and close the cabinet doors. The magnetic holders will keep the doors securely shut.
- **Adjusting Shelves:** To adjust a shelf, remove all items from it. Lift the shelf slightly and slide it out. Reinsert the shelf into the desired set of pre-drilled holes. Ensure it is level and securely seated before placing items back on it.
- **Weight Distribution:** Distribute weight evenly across shelves. Avoid placing excessively heavy items on a single shelf or concentrating weight in one area.



Figure 6: The TEENFON Farmhouse Storage Cabinet with its doors open, demonstrating its storage capacity and how items can be organized on the shelves.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Dusting:** Regularly dust the cabinet to prevent buildup.

- **Moisture:** While the cabinet has moisture-resistant properties, avoid prolonged exposure to excessive moisture. Wipe up spills immediately.
- **Fasteners:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **Sunlight:** Avoid placing the cabinet in direct sunlight for extended periods to prevent fading or warping.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cabinet wobbles or is unstable.	Uneven floor; loose fasteners; anti-tip kit not installed.	Ensure cabinet is on a level surface. Tighten all assembly screws. Install the anti-tip kit securely to the wall.
Doors do not close properly or are misaligned.	Hinges are loose or misaligned; cabinet frame is not square.	Check and tighten hinge screws. Ensure the cabinet frame is assembled squarely. Adjust hinges if they have adjustment screws.
Shelves are not level.	Shelf pins not fully inserted; shelf not seated correctly.	Ensure all four shelf pins are fully inserted into the corresponding holes. Reseat the shelf firmly.
Damage during shipping.	Product arrived with damaged parts.	Contact customer support immediately with details and photos of the damage.

SPECIFICATIONS

Brand: TEENFON

Model: cabinet

Product Dimensions: 11.8"D x 23.6"W x 43.3"H

Color: Black

Material: Engineered Wood

Number of Shelves: 2 (adjustable)

Door Style: Flat Doors (Barn Door design elements)

Special Feature: Anti-Tipping Kit included

Assembly Required: Yes

Item Weight: 36.9 pounds

Country of Origin: China

WARRANTY AND SUPPORT

For any questions, missing parts, or issues with your TEENFON Farmhouse Storage Cabinet, please contact our customer support. We are committed to ensuring your satisfaction.

Customer Support: Refer to your purchase documentation or the seller's contact information for support details. If you are dissatisfied with the product you received, please contact us immediately and we will help you resolve the issue and ensure your satisfaction.

Warranty Information: Specific warranty details may vary by retailer or region. Please retain your proof of purchase for any warranty claims.



© 2025 TEENFON. All rights reserved.