

amazon basics AB-TWS-J68-BLU-CT

amazon basics True Wireless in-Ear Earbuds User Manual

Model: AB-TWS-J68-BLU-CT

Brand: amazon basics

1. INTRODUCTION

Thank you for choosing amazon basics True Wireless Earbuds. These earbuds are designed to provide an immersive audio experience with comfort and convenience. Featuring advanced Bluetooth 5.3 technology, smart touch controls, and IPX5 water resistance, they are ideal for daily use, whether for music, calls, or workouts. This manual provides detailed instructions to help you get the most out of your earbuds.



Image: amazon basics True Wireless Earbuds in their charging case, showcasing the blue color and compact design.

2. KEY FEATURES

- **Extended Playback:** Enjoy up to 55 hours of music playback with the charging case.
- **Fast Charging:** Get 100 minutes of playtime with just 10 minutes of charging.
- **Enhanced Audio:** Dual 10 mm dynamic drivers deliver immersive sound and clearer calls.
- **IPX5 Water Resistance:** Protection against water splashes and perspiration, suitable for workouts.
- **Smart Touch Controls:** Manage music, calls, and voice assistant with intuitive touch gestures.
- **Bluetooth 5.3 Connectivity:** Ensures stable and efficient wireless connection.



Image: An infographic illustrating the key features including in-built mic, 10mm diaphragm, 55 hours play time, smart touch control, sweat resistance, Bluetooth 5.3, and fast charging.

3. SETUP GUIDE

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB cable to the charging port on the case and a compatible USB power source. The indicator light on the case will show the charging status. A full charge provides up to 55 hours of combined playtime with the case.

55 HRS
PLAY TIME WITH CASE




Image: The earbuds resting in their charging case, with visual cues indicating 55 hours of play time and fast charging capability.

3.2 Pairing with Your Device

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing light on the earbuds.
3. On your device (smartphone, tablet, etc.), go to the Bluetooth settings.
4. Search for available devices and select "amazon basics Earbuds" from the list.
5. Once connected, the indicator light on the earbuds will stop flashing, and you will hear a confirmation tone.
6. For subsequent uses, the earbuds will automatically connect to the last paired device when taken out of the case.

BLUETOOTH 5.3 CONNECTIVITY



Image: A close-up of the earbuds, emphasizing their Bluetooth 5.3 connectivity feature with a radiating signal graphic.

4. OPERATING INSTRUCTIONS

4.1 Smart Touch Controls

The earbuds feature intuitive touch controls on their outer surface. Refer to the table below for common functions:

Action	Function
Single Tap (Left/Right Earbud)	Play/Pause Music, Answer/End Call
Double Tap (Right Earbud)	Next Track
Double Tap (Left Earbud)	Previous Track

Action	Function
Hold (Right Earbud)	Increase Volume
Hold (Left Earbud)	Decrease Volume
Triple Tap (Left/Right Earbud)	Activate Voice Assistant
Hold (during incoming call)	Reject Call



Image: A detailed view of an earbud highlighting the smart touch control area and its IPX5 sweat resistant capability, along with quick tap voice assistant function.

4.2 Voice Assistant

To activate your device's voice assistant (e.g., Siri, Google Assistant), simply triple tap either earbud. This allows you to control your device hands-free.

5. MAINTENANCE

5.1 Cleaning

Regular cleaning helps maintain optimal performance and hygiene. Use a soft, dry, lint-free cloth to wipe the earbuds and charging case. For ear tips, you may gently remove them and clean with a damp cloth, ensuring they are completely dry before reattaching. Do not use harsh chemicals or abrasive materials.

5.2 Water Resistance (IPX5)

The earbuds are rated IPX5, meaning they are resistant to water splashes from any direction. This makes them suitable for workouts and light rain. However, they are not designed for submersion in water. Avoid exposing them to high-pressure water jets or prolonged immersion.

6. TROUBLESHOOTING

If you encounter issues with your earbuds, please refer to the following common solutions:

- **Earbuds Not Pairing:**
 - Ensure both earbuds are in the charging case and have sufficient charge.
 - Turn off Bluetooth on your device, then turn it back on.
 - Forget the device from your Bluetooth settings and attempt to pair again.
 - Try pairing with a different device to rule out device-specific issues.
- **No Sound from One Earbud:**
 - Place both earbuds back into the charging case, close the lid, wait a few seconds, then take them out again.
 - Ensure both earbuds are charged.
 - Clean the charging contacts on the earbuds and inside the case.
- **Charging Issues:**
 - Ensure the charging cable is securely connected to both the case and the power source.
 - Try a different USB cable and power adapter.
 - Clean the charging port on the case to remove any debris.
- **Poor Sound Quality:**
 - Ensure the earbuds are properly seated in your ears for a good seal.
 - Clean any earwax or debris from the earbud nozzles.
 - Move closer to your connected device to avoid interference.

7. SPECIFICATIONS

Feature	Detail
Model Name	Earbuds

Feature	Detail
Model Number	AB-TWS-J68-BLU-CT
Connectivity Technology	Wireless (Bluetooth 5.3)
Earpiece Shape	In-Ear
Control Method	Touch Control
IP Rating	IPX5 (Water and Perspiration Resistant)
Battery Life	Up to 55 Hours (with charging case)
Fast Charging	10 mins charge = 100 mins playtime
Driver Size	10 mm Dynamic Drivers
Material	Plastic
Item Weight	35 Grams
Product Dimensions	4.7 x 6 x 2.3 cm
Included Components	Cable
Manufacturer	DONGGUAN ARCHER TECHNOLOGY LIMITED
Country of Origin	China

8. WARRANTY AND SUPPORT

amazon basics products are designed for reliability and performance. For information regarding warranty coverage and customer support, please refer to the warranty card included with your product or visit the official amazon basics support page. You may also contact the manufacturer directly:

Manufacturer: DONGGUAN ARCHER TECHNOLOGY LIMITED

Importer: IRIS TECH G-1/G-2, DHARAM COMPLEX, PHASE-1, ANJUR MANKOLI ROAD, BHIWANDI, MAHARASHTRA - 421302

For further assistance, please visit the [amazon basics Store on Amazon.in](#).

Related Documents



インイヤ型有線 USB-C マイク付きイヤホン
B0CY5SF1CP

EN	Page 2	ML	Pageina
FR	Page 7	PL	Strona
DE	Seite 12	SV	Seite
IT	Pageina 17	日本語	ページ
ES	Página 21		

EN	Página	2	ML	Página
FR	Página	7	PL	Sinistra
DE	Seite	12	SV	Stato
IT	Pagina	17	CS	←
ES	Página	21			

User manual and specifications for Amazon Basics Wired USB-C Earbuds with Microphone (Model BOCYSSF1CP, AMZ-E8090A). Includes safety, usage, and troubleshooting information.



Portable BT Speaker
AB-BT-8001

Comprehensive user manual for the Amazon Basics Portable BT Speaker (Model AB-BT-8001), covering safety tips, operation, controls, charging, Bluetooth connectivity, TWS mode, FAQs, specifications, and warranty information.



User manual and safety information for the Amazon Basics Qi Certified Wireless Charging Pad (10W/15W). Covers important safety instructions, operation, indicator light status, technical specifications, RF exposure, FCC compliance, EU declaration, disposal guidelines, and customer feedback channels.



組み立てマニュアル
ハイブリッドアクティブノイズキャンセリングヘッド
フォン、ワイヤレス、オーバーイヤー、Bluetooth
Instrukcja obsługi
Hybrydowe słuchawki z aktywną redukcją
szumów, bezprzewodowe, nauszne, Bluetooth
Bruksarvslinje
Hybrid hörlurar med aktivt brusreducering,
trådlös, över-ear, Bluetooth



Comprehensive user manual for Amazon Basics Hybrid Active Noise Cancelling Headphones, covering setup, usage, troubleshooting, and specifications. Learn how to pair, use noise cancellation, and maintain your headphones.